



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MAKITA RST210. You'll find the answers to all your questions on the MAKITA RST210 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual MAKITA RST210**  
**User guide MAKITA RST210**  
**Operating instructions MAKITA RST210**  
**Instructions for use MAKITA RST210**  
**Instruction manual MAKITA RST210**




English / Italiano / Spanish

**String Trimmer**  
**Tagliabordi**  
**Cortabordes**

**RST210**

**INSTRUCTION MANUAL**  
**ISTRUZIONI D'USO**  
**MANUAL DE INSTRUCCIONES**



**RST210**

**Important:**  
Read this instruction manual carefully before putting the String Trimmer into operation and strictly observe the safety regulations!  
Preserve instruction manual carefully!

**Importante:**  
Prima di mettere in funzione il tagliabordi, leggere attentamente il presente manuale, rispettare rigorosamente le norme di sicurezza!  
Conservare il manuale delle istruzioni per l'uso!

**Importante:**  
Leer cuidadosamente este manual de instrucciones antes de poner en marcha la máquina y observar estrictamente las normas de seguridad.  
Conservar este manual de instrucciones con cuidado.



[You're reading an excerpt. Click here to read official MAKITA RST210 user guide](http://yourpdfguides.com/dref/2702952)  
<http://yourpdfguides.com/dref/2702952>

**Manual abstract:**

@@@ You will note the following symbols when reading the instruction manual. Keep the area of operation clear of other persons and pets. Wear eye and ear protection. To ensure correct operation, user has to read this instruction manual to make himself familiar with the handling of the string trimmer. Users insufficiently informed will risk danger to themselves as well as others due to improper handling. It is recommended only to lend the string trimmer to people who have proven to be experienced with string trimmers. always hand over the instruction manual. First users should ask the dealer for basic instructions to familiarize oneself with the handling of an engine powered trimmer. Children and young persons aged under 18 years must not be allowed to operate the string trimmer. Persons over the age of 16 years may however use the device for the purpose of being trained only whilst under supervision of a qualified trainer. Use string trimmers with the utmost care and attention. Operate the string trimmer only if you are in good physical condition. Never use the string trimmer after consumption of alcohol or drugs, or if feeling tired or ill. The String Trimmer is only intended for cutter grass, weeds, Bushes, undergrowth it should not be used for any other purpose such as Edging or hedge cutting as this may cause injury. It should be tight-fitting but not cause hindrance. Do not wear either jewelry or clothing which could become entangled with bushes or shrubs. In order to avoid either head-, eye-, hand- or foot injuries as well as to protect your hearing the following protective equipment and protective clothing must be used during operation of the string trimmer. Always wear a helmet where there is a risk of falling objects. ( ). The work overalls (4) protect against flying stones and debris. we strongly recommend that the user wears work overalls. Special gloves (5) made of thick leather are part of the prescribed equipment and must always be worn during operation of the string trimmer.

When using the string trimmer, always wear safety shoes (6) with a nonslip sole. This protects against injuries and ensures a good footing. Please make sure that there are no children or other people within a working range of 15 meters (50ft), also pay attention to any animals in the working vicinity. Before use always check that the string trimmer is safe for operation: Check the security of the nylon cutting head, the control lever for easy action. Rotation of the nylon cutting head during idling speed is not allowed. check with your dealer for adjustment if in doubt. Check for clean and dry handles and test the function of the start/stop switch. Start the string trimmer only in accordance with the instructions. Do not use any other methods for starting the engine! Use the string trimmer and the tools only for such applications as specified. Only start the string trimmer engine, after the entire assembly is done.

Operation of the device is only permitted after all the appropriate accessories are attached. Before starting make sure that the nylon cutting head has no contact with hard objects such as branches, stones etc. as the cutting tool will revolve when starting. The engine is to be switched off immediately in case of any engine problems. Should the nylon cutting head hit stones or other hard objects, immediately switch off the engine and inspect the nylon cutting head. Always ensure a safe footing. Never run the engine in enclosed rooms (risk of gas poisoning). carbon monoxide is an odorless gas. Never run the trimmer without this guard. Never operate the engine with faulty exhaust muffler.

Shut off the engine during transport. During transport over long distances the tool protection included with the equipment must always be used. Ensure safe position of the string trimmer during car transportation to avoid fuel leakage. When transporting the string trimmer, ensure that the fuel tank is completely empty. When unloading the String Trimmer from the truck, never drop the Engine to the ground or this may severely damage the fuel tank. Except in case of emergency, never drop or cast the String Trimmer to the ground or this may severely damage the String Trimmer Remember to lift the entire equipment from the ground when moving the equipment. Dragging the fuel tank is highly dangerous and will cause damage and leakage of fuel, possibly causing fire. Shut off the engine during refuelling, keep away from open flames and do not smoke. Avoid skin contact with mineral oil products. do not inhale fuel vapor.

Always wear protective gloves during refuelling. change and clean protective clothing at regular intervals. Take care not to spill either fuel or oil in order to prevent soil contamination (environmental protection). Clean the string trimmer immediately after fuel has been spilt. Avoid any fuel contact with your clothing. change your clothing instantly if fuel has been spilt on it (to prevent clothing catching fire). Inspect the fuel cap at regular intervals making sure that it can be securely fastened and does not leak. Carefully tighten the fuel tank cap. Change location to start the engine (at least 3 meters away from the place of refuelling). Make sure the fuel stored is not accessible to children.

Only use the string trimmer in good lighting and visibility. During the winter season beware of slippery or wet areas, ice and snow (risk of slipping). Always ensure a safe footing. Found within the working range. Employ only the correct nylon cutting head for the job in hand. All the other work is to be done by an Authorized Service Agent. Immediately replace any item taken from the first aid box. \* WARNING: MODEL RST210 must not be used with a metal blade. always wear protective gloves.

CAUTION: Start the string trimmer only after having assembled it completely.

Be sure the bolts are tight, but do not over tighten. Adjust the handle to the desired position over 200mm away from the rear grip (3) and tighten the three screws (2). To meet the applicable safety provisions, only the tool/protector combinations as indicated in the table must be used. Be sure to use genuine MAKITA nylon cutting head. Handling fuel Utmost care is required when handling fuel.

fuel may contain substances similar to solvents. Refuel either in a well-ventilated room or outdoors. Mineral oil products degrease your skin.

Various skin diseases may result. in addition, allergic reactions may occur.

Eyes can be irritated by contact with oil.



**[You're reading an excerpt. Click here to read official MAKITA RST210 user guide](http://yourpdfguides.com/dref/2702952)**  
<http://yourpdfguides.com/dref/2702952>

If oil comes into your eyes, immediately wash them with clear water. If your eyes are still irritated, see a doctor immediately! observe the Safety Instructions on page 4. @@@@Low speed (under 4,800min-1) is not suitable, the nylon cord will not feed out properly at low speed. If the nylon cord does not feed out automatically proceed as follows: 1. Release the control lever to run the engine idle and then squeeze the control lever fully. Repeat this procedure until the nylon cord feeds out to the proper length. 2. If the nylon cord is too short to feed out automatically with the above procedure, bump the knob of the nylon cutting head against the ground to feed out the nylon cord. 3.

If the nylon cord does not feed out with procedure 2, rewind/replace the nylon cord by following the procedures described under "Replacing the nylon cord".

Â Press on the housing latches inward to lift off the cover, then remove the spool. Â Hook the center of new nylon cord into the notch in the center of the spool, with one end of the cord extending about 80mm (3-1/8") more than the other. Then wind both ends firmly around the spool in the direction of the head rotation (left-hand direction indicated by LH and right-hand direction by RH on the side of the spool). Spool Â Wind all but about 100mm (3-15/16") of the cords, leaving the ends temporarily hooked through a notch on the side of the spool. Keep the side with letters on the spool visible on the top. Now, unhook the ends of the cord from their temporary position and feed the cords through the eyelets to come out of the housing. Then push cover firmly onto the housing to secure it. @@ always wear protective gloves! @@@@Â Perform the following work daily after use: Â When working under extremely dusty conditions, clean the filter the several times a day. â Check the nylon cutting head for damage and make sure it is firmly mounted.

â Check that there is sufficient difference between idling and engagement speed to ensure that the nylon cutting head is at a standstill while the engine is idling (if necessary, reduce idling speed). If under idling conditions the tool should still continue to run, consult your nearest Authorized Service Agent. Clogging of the element (1) may sometimes make it difficult or impossible to start up the engine or increase the engine speed. @@ â Remove the air cleaner cover screw. @@@@@NOTE:If there is excessive dust or dirt adhering to the air cleaner, clean it every day.

A clogged air cleaner may make it difficult or impossible to start the engine or increase the engine rotational speed. Â The gap between the two electrodes of the spark plug should be 0. If the gap is too wide or too narrow, adjust it. If the spark plug is .



[You're reading an excerpt. Click here to read official MAKITA](#)

[RST210 user guide](#)

<http://yourpdfguides.com/dref/2702952>