



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MAXDATA PRO 6000T. You'll find the answers to all your questions on the MAXDATA PRO 6000T in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual MAXDATA PRO 6000T**  
**User guide MAXDATA PRO 6000T**  
**Operating instructions MAXDATA PRO 6000T**  
**Instructions for use MAXDATA PRO 6000T**  
**Instruction manual MAXDATA PRO 6000T**

---

***User Guide -***

***Multimedia Notebook Computer***

37



[You're reading an excerpt. Click here to read official MAXDATA PRO 6000T user guide](http://yourpdfguides.com/dref/2876593)  
<http://yourpdfguides.com/dref/2876593>

*Manual abstract:*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*... 48 Removing the Battery ..*

.....  
.....  
.....  
.....

.....  
.....  
.....

*..... 48 Power Supply Hardware .....*

.....  
.....  
.....

.....  
.....  
.....

*... 49 Switching the Computer On .....*

.....  
.....  
.....  
.....  
.....  
.....

*..... 50 Power Management .....*

.....  
.....  
.....  
.....  
.....

.....  
.....

*.... 51 SYSTEM OVERVIEW .*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... *52 Left and Right Sides ...*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*. 52 Rear View .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 53 Underside .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 53 Explanation of LED Indicators .....*

.....  
.....  
.....  
.....

.....  
.....  
.....

*. 54 Hot Keys .....*

.....  
.....  
.....  
.....

.....  
.....

.....

.....

.....

.....

.....

... 55 The Quick Launch Keys .....

.....

.....

.....

.....

.....

.....

.....

.....

.. 56 The Keyboard .....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 56 The TouchPad ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. @@@@59 INSTALLATION INSTRUCTIONS .....

.....

.....

.....

.....

.....

.....

.....

.. 60 Restoring the Drivers .....

.....

.....

.....

.....

.....

.....

.....

.....

..... 60 Windows XP .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

. 60 Modem Installation .....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

... 61 Windows 2000 .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

62 Modem Installation .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 62 Audio Installation ...

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 63 REGIONAL SETTINGS .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*.... 63 SPECIFICATIONS .*

.....

.....  
.....  
.....

.....  
.....  
.....

.....

*.. 64 FAULT DIAGNOSIS AND TROUBLESHOOTING ...*

.....  
.....

.....  
.....

*.... 67 39 40 NOTE The company reserves the right to make unadvertised modifications to this document.*

*Information contained in this document is intended solely for reference purposes and in no way constitutes a basis for asserting obligations on the part of the manufacturer or vendor. Neither the manufacturer nor the vendor accept liability for any errors or inaccuracies that this document may contain. Nor is liability accepted for damages or losses that arise from the incorrect application of this guide. No part of this document and the accompanying software may be copied, translated, or distributed without the prior permission of the dealer, manufacturer, or authors. Archive copies for private use are excepted from this rule. @@@@ In certain jurisdictions these trademarks may be registered. Intel and Pentium are registered trademarks of Intel Corporation. @@@@41 Note: Some or all system configurations may have been made already. If this is not the case or if parts of the system need to be reconfigured, please refer to the "Installation Instructions" section for the relevant instructions. Declaration: This device meets the EN 55022 product standard for interference emissions, the EN 50082-1 basic standard for interference, and the EN 60950 low voltage directive standard.*

*If any modification that has not been agreed with the manufacturer is made to the device, adherence to these standards can no longer be guaranteed. To ensure electromagnetic compatibility (EMC), please observe the information given in the handbook. Sound Power Level The workplace-based sound power level is less than 55 dB A. Federal Communications Commission (FCC) Note This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Operator Note: This device has been carefully RF suppressed and tested to avoid radio interference. However, please pay attention to the following concerning external data cables: If it becomes necessary to replace a data cable specified by the manufacturer, then for correct radio interference suppression the operator must ensure that replacement cables match the original cable also as pertains to screening quality. Use only screened cables and external devices that are identical with this product in safety level and EMC behavior. In case of non-observance, compliance with the standards mentioned above is no longer guaranteed! 42 Laser (Service Information) Laser radiation when the cover is open! This laser radiation is contained in the CD drives. When dismantling and / or opening this drive, be careful: · Not to look into the beam, not even with optical instruments · Not to become exposed to the beam WARNING · To avoid eyes or skin being exposed to direct or scattered beam. Failure to observe these guidelines can lead to permanent blindness.*

*CD-ROM Drive: The built-in CD drives contain no user-serviceable or repairable parts. CD drives are to be repaired solely by the manufacturer. Laser products of laser classes 1 to 3B may be used in the product. With the housing unopened, the device meets the requirements of laser class 1. By opening the device, laser devices up to laser class 3B may be accessible.*

*Unless the drive is expressly designated for the simultaneous use of more than one CD, never insert more than one CD into the drive. Field of Application This product is not intended for use in medical, life-saving or life support applications. Returning the Device We offer a return guarantee: We use materials that allow professional reprocessing or disposal. This means that your notebook is fully recyclable. The outside packaging and all inner parts of the box can be disposed of as waste paper.*

*43 Safety Information IMPORTANT SAFETY INFORMATION Although the notebook is highly robust, it is not indestructible. To prevent damage from occurring, please pay attention to the following: · Avoid exposing the notebook to strong shocks or vibrations. · Keep it away from intense heat (radiators, direct sunlight). · Protect the notebook from electromagnetic interference. This will also prevent data loss. · Do not expose it to moisture. This is an electrical*

device! · Be sure to use the correct power supply. Always use an approved power adapter. The power adapter requires a fluctuation-free and WARNING uninterrupted power supply. If you have any questions, consult your local electricity supply company.

The power adapter must be fitted with a grounded (earthed) plug. Never pull the cable to unplug the power supply always pull the plug itself.

@@@Recharge batteries via the notebook. Do not attempt to repair faulty batteries yourself. Entrust repairs to your dealer or qualified service personnel.

@@Exercise caution in handling damaged batteries. @@The battery is recyclable. @@@@If servicing is required, consult qualified service personnel. Disconnect the computer from the power supply. @@- Liquid has entered the computer.

@@@Use only a soft, lint-free cloth. @@@@Slide the catch (1) to the right and open the display. (1) Catch 1 Fig. @@@This battery is only partially charged. Take the new battery out of its packaging.

@@The battery can now be charged up. Fig. 3 PLEASE NOTE Make sure that you allow the battery to charge for TWO hours if the computer is switched off, or for FIVE hours if the computengs must be kept free from obstructions at all times. If not, the device is liable to overheat. @@If not, the device is liable to overheat.

PLEASE NOTE 3 1 6 5 4 Fig. @@You can use these to launch frequently used applications. @@The path is Operating System\SwiftButton. e.g.: D:\WinXP\SwiftButton\setup.exe. 1234 Fig. 11 THE KEYBOARD Typewriter Function keys - Special keys - Your notebook's keyboard has all the functions of a normal AT-compatible keyboard plus some extras: These keys correspond to a typewriter's keys. In many operating systems (and applications), special functions are available via these keys.

@@@@@The path is Operating System\Touchpad. @@@@@@Push the CD tray back in until it locks into place. The CD is now ready to read. Some CDs have an autostart function. @@14 THE PC CARD SLOT The computer is provided with two PC card slots. These are 2x type II or I PCMCIA slots or 1 x type III. To insert a PC card (3), push it into the slot (2) until it locks into place.



[You're reading an excerpt. Click here to read official MAXDATA](#)

[PRO 6000T user guide](#)

<http://yourpdfguides.com/dref/2876593>

To remove it, push the eject button (1) next to the slot. 1 3 2 Fig. 15 58 System Overview THE DATA/FAX MODEM The system automatically sets up the integrated analog modem.

To use the modem functions, connect the modem socket to an analog telephone socket (not ISDN) using the telephone cable. Proper Use: The modem can be connected to a device driver update assistant. Select: <Search for a suitable driver for my device (recommended)> <Next> <Optional search locations> <CD-ROM Drives> <Next><Next><Finish> <Close> You can now close the device manager and the control panel. REGIONAL SETTINGS Depending on the version of the Windows 2000™ driver for the modem, the basic settings for the location may be set to "United States of America". To check/modify this, do the following: Click with the left mouse button, in this order, on: <Start> <Settings> <Control Panel> You can set the telephone and modem options here. On the Dialing Rules tab, select New Location and click <Edit>. @@Click <Apply> to save this setting. Click <OK> to leave this menu. @@@@o If the problem cannot be solved in this way, you can find additional information in the advanced service handbook (on the device drivers and utilities CD-ROM). If the problem persists, switch off the system for several minutes and then restart it.

You will lose all unsaved data, but the system may work properly again. Subsequently contact your dealer or customer support agent. Although I'm pressing the power switch the computer stays switched off Possible cause of the problem: The battery is missing or is incorrectly installed Note: The power on LED is not lit. Troubleshooting: o Make sure that the battery is in the battery compartment and is inserted properly. o Check that the battery terminals are making direct contact. o Connect your notebook to the power adapter so that the battery (if present) can recharge. Possible cause of the problem: battery level low Note: The battery display LED flashes. Troubleshooting: Operate the computer using the power adapter. @@Note: The suspend LED flashes. @@@@o If an external monitor is connected, switch it on.

@@Troubleshooting: o Press the Fn + F10 key combination. o If an external monitor is connected, connect this to a power source and switch it on. Also check the brightness and contrast settings (you can find additional information on this topic in the advanced service handbook). The system stops working. Possible cause of the problem: An energy saving function has been activated. Note: The screen switches itself off. Troubleshooting: Press any key or press the on/off button if none of the status LEDs are lit. 68 Appendix B - Troubleshooting Possible cause of the problem: A software error has caused a system crash.

Troubleshooting: o Additional information is available in the operating system handbook. o If you cannot remedy the problem, then restart the system. You will lose any unsaved data! If this doesn't work either, briefly switch off the computer and then switch it back on again. Warnings Each time the system starts, it carries out a self-test (POST). If an error occurs, an error message appears, briefly describing the problem. You can find information on what to do next in the advanced service handbook. 69 Appendix B - Troubleshooting 70 .



[You're reading an excerpt. Click here to read official MAXDATA PRO 6000T user guide](http://yourpdfguides.com/dref/2876593)  
<http://yourpdfguides.com/dref/2876593>