



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MAXTOR SHARED STORAGE II. You'll find the answers to all your questions on the MAXTOR SHARED STORAGE II in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MAXTOR SHARED STORAGE II
User guide MAXTOR SHARED STORAGE II
Operating instructions MAXTOR SHARED STORAGE II
Instructions for use MAXTOR SHARED STORAGE II
Instruction manual MAXTOR SHARED STORAGE II

The Maxtor logo, featuring the word "Maxtor" in a bold, sans-serif font with a registered trademark symbol.

Quick Start Guide

MAXTOR SHARED STORAGE™ II



[You're reading an excerpt. Click here to read official MAXTOR SHARED STORAGE II user guide](http://yourpdfguides.com/dref/2944261)
<http://yourpdfguides.com/dref/2944261>

Manual abstract:

Your drive will now start. Plug the round female connector from the power adapter into the drive's power connector. Plug the two-pin female connector on the power cord into the power adapter. Plug the standard electrical plug from the power adapter into your power source. Press the round black button on the back panel of your Maxtor Shared Storage II drive. The green LED (light) will illuminate in the center of the power button. @@Other trademarks are the property of their respective holders. Follow the on-screen prompts to complete the installation. When the Home screen appears, click on the Create a user account button. Choose an account type (Public Account or Private Account / Home or Business), provide the necessary information and click Create.

The EasyManage™ software will now create the new user account and the appropriate folders for the account. @@@@Follow the on-screen prompts in your browser to configure your Shared Storage drive. Upon restart, Maxtor EasyManager searches for Shared Storage drives on your network. When found, you will see the Network ID number and IP address for the located drive(s). When the installation is complete, click Finish to restart your PC. Plug the other end of the Ethernet cable into the Ethernet port on your Shared Storage II drive. Your drive will now start. Plug the round female connector from the power adapter into the drive's power connector. Plug the two-pin female connector on the power cord into the power adapter. Plug the standard electrical plug from the power adapter into your power source.

Press the round black button on the back panel of your Maxtor Shared Storage II drive. The green LED (light) will illuminate in the center of the power button. @@Other trademarks are the property of their respective holders. When finished, close your browser to return to the EasyManage screen. + 10. When the main menu appears, click on the Plus (+) icon of the EasyManage screen to create a new user account. 13. Enter a Name for the new account and click Create. Upon restart, double-click EasyManage located on your desktop. easyManage searches for Shared Storage Drives on your network.

When found, you will see the Network ID number and IP address for the located drive(s). Choose an account type (Public Account or Private Account) and click Next. Note: Maxtor EasyManage software must be installed on each Macintosh computer in order for each user to take advantage of a Personal folder. Note: If no Shared Storage Drives were found, click Help for more information and troubleshooting tips. The EasyManage - Shared Storage Administrator Password window will appear, allowing you to set administrative security on the Shared Storage II drive. When the installation is complete, click Restart. The EasyManage software will now create your new user account and the appropriate folders for the account. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@@@Other trademarks are the property of their respective holders.

@@Other trademarks are the property of their respective holders. @@@@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders.

@@@@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. @@Other trademarks are the property of their respective holders. Create a user account), Private Account), EasyManage™ @@Other trademarks are the property of their respective holders. @@Please note that Maxtor products are distributed outside the United States and Canada through local authorized distributors and resellers ("Resellers"). these Resellers generally offer a consumer warranty , and associated warranty services , to consumer purchasers. Maxtor recommends that consumers in these jurisdictions first contact the Reseller from whom they purchased the Maxtor product for all issues with regard to product defects and the applicable product warranty.

Maxtor warrants to the original consumer purchaser ("you") that new Maxtor disk drive products ("New Products") will be free from defects in material and workmanship for the Standard Warranty Period for the relevant New Product. The Standard Warranty Period for the various New Products marketed by Maxtor and for the geographies in which they are sold is detailed on www. To the extent that Maxtor so designates a warranty period for the Refurbished Product, Maxtor warrants to the original consumer purchaser that the Refurbished Product will be free from defects in material and workmanship for the associated Refurbished Warranty Period. The Products are manufactured from parts and components that are new or equivalent to new in accordance with industry standards. The warranty period on replacements for New Products is the remainder of the warranty on the original New Product or 90 days from the date of shipment of the replacement product, whichever is longer. New Products and Refurbished Products are together referred to as "Products." The start of the Standard Warranty Period or Refurbished Warranty Period (together referred to as the "Warranty Period"), as the case may be, is the documented date of your purchase of the Product from Maxtor or Maxtor's authorized reseller. In the absence of a documented purchase date, the start of the Warranty Period will be deemed the date of original shipment by Maxtor from its point of new or refurbish manufacture, as the case may be, to Maxtor's customer. If Maxtor elects to repair a Product, Maxtor owns all parts removed from the repaired Product. Maxtor uses new and reconditioned parts made by various manufacturers in conjunction with warranty repairs and replacement Products.

Repair parts or replacement Products may, at Maxtor's option, include an equal or better model or features. Maxtor has no responsibility whatsoever with regard to any content or data on returned Products. If you discover a defect in material or workmanship during the Warranty Period, and Maxtor agrees that the defect exists, Maxtor will, at its option, repair or replace the Product at no charge to you, provided it is returned during the applicable Warranty Period, with transportation charges prepaid, to the facility designated by Maxtor.



[You're reading an excerpt. Click here to read official MAXTOR](http://yourpdfguides.com/dref/2944261)

[SHARED STORAGE II user guide](http://yourpdfguides.com/dref/2944261)

<http://yourpdfguides.com/dref/2944261>

The Product must be properly packaged in Maxtor or Maxtorapproved packaging, with the Return Material Authorization clearly displayed on the outside of the packaging, to obtain warranty service. Products that fail within the first 30 days after purchase will be replaced with a new Product.

Maxtor may require proper proof of purchase documentaurt of competent jurisdiction, the balance of this Limited Warranty will remain in full force and effect. In addition, should a translation of this Limited Warranty deviate from the English language version, only the English language version shall apply and be binding. @@ Maxtor owns all parts removed from the repaired Products. @@@@@Please note that Maxtor makes the source code for the GPL software available through www. Abuse, unreasonable use, mistreatment, or neglect Unusual physical or electrical stress or power fluctuations Damage caused during installation of the Product Damage or capacity/performance/operational resetting caused by the equipment or system with which the Product is used Damage caused by modification or repair not made or authorized by Maxtor Products whose Maxtor Serial Number and/or Material Number label have been removed, torn or defaced Damage caused by use of non-Maxtor packaging Damage caused by improper or improperly used packaging Damage caused by lack of ESD protection Products that are determined to be stolen.

Changes are periodically made to the information herein which will be incorporated in revised editions of this publication. Maxtor may make changes or improvements to the product(s) described in this publication at any time and without notice. maxtor is a registered trademark of Maxtor Corporation. All other brands or products are trademarks or registered trademarks of their respective holders. .



[You're reading an excerpt. Click here to read official MAXTOR](#)

[SHARED STORAGE II user guide](#)

<http://yourpdfguides.com/dref/2944261>