



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MCCULLOCH M 340. You'll find the answers to all your questions on the MCCULLOCH M 340 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MCCULLOCH M 340
User guide MCCULLOCH M 340
Operating instructions MCCULLOCH M 340
Instructions for use MCCULLOCH M 340
Instruction manual MCCULLOCH M 340

PNC	Type-Prefix/nd	Model	Brand
3150012-52	07	ELECTRAMAC 312 SCHJKO	MCCULLOCH
952900175			
33150014-52	07	ELECTRAMAC 314 SCHJKO	MCCULLOCH
952900176			
952900286	07	ELECTRAMAC 314 - GILET	MCCULLOCH
3150016-52	07	ELECTRAMAC 316 SCHJKO	MCCULLOCH
952900177			
952900610			
952900287			
3140012-32	07	ELECTRAMAC 330 SCHJKO	MCCULLOCH
952900183			
952900309	07	ELECTRAMAC 335 ASSY UK	MCCULLOCH
3140014-52	07	ELECTRAMAC 335 SCHJKO	MCCULLOCH
952900183			
952900237	07	ELECTRAMAC 340 ASSY UK	MCCULLOCH
3140016-52	07	ELECTRAMAC 340 SCHJKO	MCCULLOCH
952900184			
952900665			
952900708			
952900731			
952900730	07	ELECTRAMAC 340 SUPER	MCCULLOCH
952900608	07	ELECTRAMAC 340 AUSTRALIA	MCCULLOCH
952900558	07	ELECTRAMAC MES 1950	MCCULLOCH
952900484	07	ELECTRAMAC MC EX 16	MCCULLOCH
952900498	07	MES 316 - CHAIN OIL	MCCULLOCH
952900499	07	M 325 - CHAIN OIL	MCCULLOCH
952900500	07	M 340 - CHAIN OIL	MCCULLOCH

Number of Pages 1 of 3

Factory: IIQ - Valmadrera	Product Group: OP 93
Publication Number: EIPL2004_VP0411004	Petrol Portable
Publication Date: 5/11/04	Sub Group 9434



[You're reading an excerpt. Click here to read official MCCULLOCH M 340 user guide](http://yourpdfguides.com/dref/3603366)
<http://yourpdfguides.com/dref/3603366>

Manual abstract:

8 washer 10x15x1 gear washer 10x30x0,8 seeger D.8 screw self threading 4x18 washer 4,5x16x0,8 trigger lock slide spring seeger D.8 pinion lever screw
brake metal stripping brake spring brake lever ass'y toggle pin pin C C C C C A B A 43 44 45 46 47 48 49 50 51 53 54 55 56 241037 229082 235367
241167 241036 240862 248317 241066 241067 242501 243017 FIGURE 2 241035 538241037 538229082 538235367 538241167 538241036 538240862
538248317 538241066 538241067 538242501 538243017 538241035 1 1 1 1 1 8 1 1 2 2 1 2 tensioner nut screw seeger ring screw spiked bumper screw self
threading 4x18 pinion cover ass'y pinion cover plate bushing nut M6 cap bar bolt C B C B B B FIGURE 2 C C C C C 1 2 3 4 5 243033 00248956 00248957
00216400 00216404 538243033 538048956 538048957 538216400 538216404 1 2 1 1 1 motor ass'y brushes brushes holder bearing bearing C A C B C C C
B A=ALTA ROTAZIONE B=MEDIA ROTAZIONE C=ALTA ROTAZIONE NUOVI CODICI A=HIGH MOVING B=MEDIUM MOVING C=SLOW MOVING
NEW P. .



[You're reading an excerpt. Click here to read official MCCULLOCH
M 340 user guide
http://yourpdfguides.com/dref/3603366](http://yourpdfguides.com/dref/3603366)