

Le damos las gracias por la confianza que nos ha demostrado al comprar nuestro cortacesped. Estamos seguros de que podr apreciar con el tiempo y con satisfaccin la calidad de nuestro producto. Le rogamos lea atentamente este manual preparado expresamente para informarle sobre el uso correcto con arreglo a los requisitos bsicos de seguridad. Attenzione! Leggere il manuale di istruzioni prima dell'uso Attention! Lire le manuel d'instructions avant utilisation. Caution! Read the instruction manual before use.

Achtung! Vor der Verwendung ist die Bedienungsanleitung zu lesen. Tenere le persone estranee fuori dalla zona di pericolo! Eloigner toute personne etrangere de la zone dangereuse! Keep other people well away from the danger area! Unbefugte drfen nicht in den Gefahrenbereich gelangen! Atencin! Leer el manual de instrucciones antes del uso. Pas op! De gebruiksaanwijzing voor het gebruik nauwkeurig doorlezen. Ateno! Ler o manual de instrues antes do uso. Uwaga! Przed uyciem przeczytac> instrukcj obsługi.

Mantener al personal ajeno fuera de la zona de peligro! Zorg ervoor dat andere personen buiten de gevarezone blijven! Manter pessoas estranhas fora da zona de perigo Osoby postronne nie powinny przebywac> w zasie%gu pracy urza%dzenia. Atencin: peligro heridas a manos y pies. Let op, gevaar voor verwondingen aan handen en voeten. Ateno, perigo machucamento mos e ps. Uwaga, wirujcy n niebezpieczen>stwo zranienia ra%k i ng. Peligro de aspiracin de gases txicos! No utilizar el aparato en ambientes cerrados o poco ventilados. Gevaar voor inademing van giftige gassen! Gebruik het apparaat niet in gesloten of niet goed geventileerde ruimtes. Perigo de aspirao de gs tossicos! No utilizar o aparelho em lugares fechados ou pouco ventilados. Niebezpieczen>stwo wdychania gazw truja%cych! Nie uz>ywac> urza%dzenia w pomieszczeniach zamknie%tych lub o slabym przewietrzeniu. Peligro de explosin! No rellenar con carburante cuando el motor est encendido Gevaar voor explosie! Vul geen brandstof met draaiende motor bij.

Perigo de explosio! No juntar o carburante com o motor em funo Niebezpieczen>stwo wybuchu! Nie przelewac> paliwa przy zapalonym silniku Atencin! Superficie caliente Pas op! Warm oppervlak Ateno! Superficie quente Uwaga! Powierzchnia gora%ca Atencin! Apagar el motor y extraer la buja antes de efectuar cualquier manutencin Pas op! De motor uitzetten en de bougie ontkoppelen alvorens enige onderhoudshandeling uit te voeren. Ateno! Desligar o motor e a vela antes de qualquer manuteno Uwaga! @@Manter pessoas estranhas fora da zona de perigo. Przewd zasilajcy nie moe znajdowa si w zasigu pracy noa. Atencin! Proteger de la lluvia de la humedad. Voorzichtig! Beschermen tegen regen an vocht. Ateno! Proteger contra a chuva e a humidade. UWAGA! Zabezpieczy przed deszczem i wilgoci. @@@@Elolvashi az utatsokot a hasznlat elott. Upozornn! Ne zanete sekaku pouvat, pozorn si prostudujte nvod k pouvn. Forsigtig! Ls vejledningn igennem inden ibrugtagning.

Varning! @@V nebezpen vzdlenosti se nesm zdrovat ciz osoby! Hold uvedkommende personer p sikker afstand af farezonen! Hll alla obehriga p avstnd frn riskomrdet! Figeylem, veszly: kezek s lbak megsebze. Pozor, nebezpe porann rukou a nohou. Forsigtig: Fare for tilfelse af sr p hnder og fdder. Varning: risk fr skada p hnder och fiter. Mrgezo szak belgze veszly! Ne hasznlni a gpet zrt vagy kevsb szelloztetetett helysgekben.

Nebezpe vdechovn toxickch plyn! Vrobek nesm bt pouvn v uzavench nebo nedostaten vtranch prostorch. Fare for if the engine and disconnect the spark plug before undertaking any maintenance work. Achtung! @@Tenere il cavo di alimentazione lontano dall'utensile tagliente. Ecarter le cble d'alimentation de l'outil tranchant. Keep the power supply cable well away from the cutting tool.

@@@Attenzione! Proteggere dalla pioggia e dall'umidit. Attention! Protger de la pluie et de l'humidit. Caution! Shelter from rain and humidity. Achtung! Vor Regen und Nsse schtzen. @@Ne hajtani vgre az uzemanyag tolstst amikor a motor mukodsben van. Nebezpe vbuchu! Pohonn hmoty je zakzno doplovat pokud je motor v chodu. Eksplosionsfare! Fyld aldrig brndstof p med motoren tndt. Risk fr explosion! Utfr inte pfyllning av brnsle med motorn igng. Figeylem! Meleg felulet. Vstraha! Hork povrch.

Forsigtig! Varm overflade. Varning! Mycket het yta. Figeylem! @@Vstraha! @@Forsigtig! @@Varning! @@A veszlyes terleten ne tartzkodjanak idegenek! Zkaz zdrziavania sa cudzch osb v nebezpečnej oblasti. Strmtilfrselskabelt m ikke vre i nrheden af skreretskabet. Hll matningskabeln p skert avstnd frn klippningsverktget. Figeylem! vni az estl s a nedvessgtl. POZOR! Chrate ped detm a vlhkem. BEMRK!Skal beskyttes mod regn og fugtighed Varning! @@Tag stikket ud af stikkontakten, inden der rres ved kniven. @@@@ Start engine. MANUAL STARTING: (While holding the engine stop lever (14)).

@@Return the starter rope slowly then pull the handle firmly towards you to its full extent. M M N MOWING IJ=HJI=JF=CA!' Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops. MOWING To cut the grass, push the lawn mower manually IJ=HJI=JF=CA!' How to insert automatic advance: Lift up the clutch handle (16) and keep it pressed in position. CAUTION: Engage the gear only when the engine is running.

How to disengage advance: Release the clutch handle. Keep the engine stop lever (14) depressed during machine operation. When the lever is released, the engine stops. To cut the grass, push the lawn mower manually or insert the automatic advance gear. O IJ=HJI=JF=CA!' Important: If, when you press the clutch lever, the automatic advance gear does not engage, the clutch cable should be adjusted by inserting the spring (P) in one of the subsequent holes (R). 7 ENGLAND P AUTOMATIC ADVANCEMENT IJ=HJI=JF=CA!' Periodically check the automatic advance assembly and make sure to keep it clean. In particular, the pinion (17) and the gear (18) must be kept perfectly clean. To carry out this check, you must remove the wheel (19) by unscrewing the screw (20). IMPORTANT - Once the product has fuel or oil in the tanks do not tilt the machine at an angle of more than 30. SAFETY RULES Training a)Persons under 16 years of age and persons who are not familiar with the user instructions must not use the lawn mower. b)The operator is responsible for the safety of other people in the working area. Keep children and domestic animals at a safe distance when the lawn mower is in use. c)This machine is to be used exclusively for cutting natural grass. Never use the mower for other purposes (e.g.

, for flattening out bumps in the ground, such as mole-hills or ant- hills). d)Work only when there is sufficient light. e)Before mowing, remove all foreign objects from the lawn which may be thrown by the machine. @@l Refuel outdoors only and do not smoke while refuelling. l Fill up the fuel tank before starting the engine.



You're reading an excerpt. Click here to read official MCCULLOCH M3540P user guide
<http://yourpdfguides.com/dref/933272>

Under no circumstances open the fuel tank cap or add petrol when the engine is running or when it is still hot. l If the petrol has overflowed, do not under any circumstances start up the engine. Move the mower away from the area where fuel has been spilt and avoid any source of possible ignition until the petrol fumes have dissipated. l Replace the fuel tank cap and tighten it down firmly. e) Do not operate the engine in a confined space where dangerous carbon monoxide fumes can collect.

. f) When mowing, never run; you must always walk. g) Exercise extreme caution when turning or when pulling the lawn mower towards you. h) Particular precautions must be taken when mowing on slopes or downhill stretches: l Use appropriate antislip footwear. l Always be sure of your footing. l Mow across the face of slopes, never up or down. l Take great care when changing direction. l Do not mow on excessively steep slopes. i) Never use the lawn mower unless the guards and safety devices (e.g. deflector, grass catcher) are securely in position and in good condition. j) Ensure that the grass catcher and deflector are correctly located. failure to do so may result in foreign objects being ejected by the blade. k) For reasons of safety, the engine must never exceed the speed. (r.p.m.) indicated on the label. l) Take care when starting the engine and be sure to follow the user instructions. Never place your hands or feet underneath the deck or into the rear discharge chute while the engine is running.

m) Never lift the rear of the mower while starting the engine or during normal operation. n) If the blade happens to hit any obstacle, stop the engine at once and remove the spark plug cap. Then get an expert to examine the blade. Maintenance and storage a) Make sure that all nuts, bolts, and screws are kept well tightened to keep the mower in a safe operating condition. b) Never leave the machine with fuel in the tank within an enclosed area where the fuel vapours could reach naked flames or sparks. c) Allow the engine to cool before storing in any enclosure. d) Keep the engine, silencer, battery compartment and petrol tank free from grass, leaves and excess lubricant, in order to reduce the danger of fire. e) Frequently check the grass catcher for wear or deterioration f) For safety reasons, be sure to replace worn-out or damaged parts in due time. g) If the fuel tank has to be drained, it is essential that this be done outdoor. h) Assemble the blades following the corresponding instructions and use only blades bearing the maker's name or the trademark of the manufacturer or supplier and marked with the reference number.

i) To protect hands during disassembly or assembly of the blades, it is absolutely essential to wear suitable protective gloves. Setting up and operating the lawn mower a) When mowing, wear strong footwear (boots or heavy shoes) and long trousers. b) Before you start mowing, make sure that the blade and blade fixing screw are securely fastened. If the blade is damaged, it must be replaced. @@ Caution! The blade starts turning as soon as the engine is started d) Caution! @@@@ For further explanation, see ENGINE INSTRUCTION BOOK.

@@ l Never clean the mower by pouring water over it: this may seriously damage the electric start system. l Take care, the exhaust muffler may be very hot. l Frequently remove the wheel screws clean whith petroleum and oil before replacing. Ball bearings must be greased before remounting. l Frequently check the blade for damage.

l The lawn mower must be checked by a SERVICE DEALER. Q BLADE I J = H J I = J F = C A ! ' l When reassembling, make sure that the key (25) is correctly seated in the shaft and that the cutting edges face in the direction of the engine rotation. The blade screw (22) must be torqued to 5,34 Kgm (52,4 Nm). l To remove the blade (21) unscrew the screw (22). l Check the conditions of the blade-support (23), the washer (24), the key (25) and the washer (26) and replace any parts which are damaged. 8 A B C D 35 E 36 F 37 G H I J K 38 L M N O P Q 39 .



[You're reading an excerpt. Click here to read official MCCULLOCH M3540P user guide](http://yourpdfguides.com/dref/933272)
<http://yourpdfguides.com/dref/933272>