




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MIELE S2121 OLYMPUS. You'll find the answers to all your questions on the MIELE S2121 OLYMPUS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MIELE S2121 OLYMPUS
User guide MIELE S2121 OLYMPUS
Operating instructions MIELE S2121 OLYMPUS
Instructions for use MIELE S2121 OLYMPUS
Instruction manual MIELE S2121 OLYMPUS

Miele

Operating Instructions



Vacuum Cleaner
S 2000

To prevent accidents
and machine damage,
read these instructions
before
installation and use.

HS12

en, fr, es - US, CA, MX

M.-Nr. 07 821 170



[You're reading an excerpt. Click here to read official MIELE S2121 OLYMPUS user guide](http://yourpdfguides.com/dref/4311092)

<http://yourpdfguides.com/dref/4311092>

Do not alter the plug in any way. danger of overheating and damage. Rewinding ^ Unplug the vacuum from the outlet. Hold the plug so that it does not whip around when rewinding. By reducing the suction power the floor brush can be pushed easier. g. When moving from a carpet to an area rug. ^ Open the air inlet valve far enough to reduce the suction power. Opening the air inlet valve reduces the power to the tool being used.

The Park system allows you to conveniently park the wand and floor brush on the vacuum cleaner during brief pauses. ^ Insert the lower clip on the floor brush into the slot on the end of the vacuum cleaner from above. Put the connection piece of the upper wand into the lower wand. A new Air Clean exhaust filter is included in every box of Miele dustbags. Replacing the Air Clean filter Do not use more than one filter at a time.

Open the dust compartment lid. ^ Open the filter frame until it clicks, grasp the clean corner (see arrow) and remove the used filter a. 20 Maintenance and care Exchanging exhaust filters Depending on the model, there may also be an Active HEPA exhaust filter included which can be used instead of the standard Air Clean exhaust filter. In order to use the Active HEPA filter the Air Clean filter and filter frame must be removed. When to change the Active HEPA exhaust filter Change this filter approximately once a year.

You can make a note of the date directly on the exhaust filter. Replacing the Active HEPA exhaust filter ^ Open the dust compartment lid. 21 Maintenance and care When to change the thread catcher on the standard floor brush The thread catcher on the floor brush should be replaced as soon as they appear worn. Changing the thread catcher Depending on model, your vacuum has one of the following floor heads. ^ Insert a new thread catcher into the slots b. ^ Insert a new thread catcher into the slots. 22 Cleaning and care ,Turn off the vacuum and unplug it from the outlet before performing any maintenance work. Vacuum cleaner and accessories The vacuum cleaner and other plastic accessories can be cleaned with a damp cloth or a cleaner suitable for plastics. ,Do not use abrasive, glass or all purpose cleaners! They will damage the surface. Dust compartment The dust compartment can, if necessary, be cleaned using a dry cloth, dusting brush or a second vacuum to remove any dust.

monitor the airflow indicator and inspect all filters regularly. Clean or replace them when necessary according to these Operating Instructions. ,Do not submerge the vacuum in water. If moisture gets into the appliance there is the risk of an electric shock. 23 Frequently asked questions ,Turn off and unplug the vacuum cleaner before performing any maintenance work. What if the vacuum turns off automatically? the vacuum has overheated. The temperature limiter automatically turns the vacuum off. This can occur if, for instance, large articles block the suction tube or when the filter bag is full or contains particles of fine dust. A heavily soiled exhaust or dust compartment filter can also be the cause of overheating. Turn the vacuum off s and pull the plug from the outlet.

Check for any bloc.



[You're reading an excerpt. Click here to read official MIELE S2121 OLYMPUS user guide](http://yourpdfguides.com/dref/4311092)
<http://yourpdfguides.com/dref/4311092>