




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MIELE S4282. You'll find the answers to all your questions on the MIELE S4282 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MIELE S4282
User guide MIELE S4282
Operating instructions MIELE S4282
Instructions for use MIELE S4282
Instruction manual MIELE S4282

Miele

Operating instructions



Vacuum cleaner
S 4002

To prevent accidents
and appliance damage,
read these instructions
before
installation and use.

HS10

en - US, CA

M.-Nr. 07 368 440



[You're reading an excerpt. Click here to read official MIELE S4282 user guide](#)

<http://yourpdfguides.com/dref/4311066>

.....
.....
.....
.....

.....
..... 21 Maintenance and care .

.....
.....

.....
.....
.....

..... 22 Purchasing new dustbags and filters .

.....
.....
.....
.....

... 22 Which dustbags and filters are the right ones?

.....
.....
.....

22 When to change the dustbag

.....
.....
.....

.....
23 Replacing the dustbag

.....
.....
.....

..... 24 Replacing the exhaust filter

.....
.....
.....
.....

..... 25 Exhaust filter change indicator ...

.....
.....
.....

.....
..... 26 Replacing the "Air Clean" filter

.....
.....
.....

..... @@

..... 28 Exchanging exhaust filters. .

.....
.....
.....

.....
.....

.....
.. 29 When to change the dust compartment filter (motor protection)

..... 30 Replacing the dust compartment filter (motor protection)

.....
.....
.... 30 When to change the radio handpiece battery

.....
.....
.....
... 30 How to change the radio handpiece battery

.....
.....
.....
.. @@

.....
.....
.....
.....
.. 31 Replacing the thread catchers ...

.....
.....
.....
.....
.. 31 Servicing the floor roller of the SBD 450-3 floor tool

.....
.... 31 Cleaning and care .

.....
.....
.....
.....
.....
.. 32 Frequently asked questions

.....
.....
.....
.....
.....
.. 33 Optional accessories ...

.....
.....
.....
.....
.....
..... 34 Caring for the environment ..

..... @@ Your power source should correspond with the voltage rating plate located on the underside of the vacuum.
Use only household AC outlets. Never use DC power sources. If you are not sure of your home's voltage supply, consult a qualified electrician. Connecting the vacuum cleaner to a higher voltage than indicated in these instructions may result in damage to the vacuum cleaner or injury. this appliance has a polarized plug (one blade is wider than the other).

) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not alter the plug in any way. dangerous.

Check the packaging, vacuum cleaner and accessories for any signs of damage. Do not use a damaged appliance. ~ A damaged vacuum cleaner can be ~ Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors or submerged in water, bring it to a service center. with a 15 A fuse. ~ The electrical outlet must be fitted 3 IMPORTANT SAFETY INSTRUCTIONS Use surfaces. Only dry surfaces should be vacuumed. manual with Miele recommended accessories. ~ Do not use on people or animals. ~ Do not use outdoors or on wet ~ Use only as described in this ~ Unwind the cord completely to aid the vacuum in dissipating heat.

entrap or retain any hazardous materials. ~ This vacuum should not be used to ~ Do not use the vacuum cleaner to ~ This appliance is intended strictly for household use only. ~ Do not allow the vacuum cleaner to be used as a toy. Close attention is necessary when used near children. ~ Never use the vacuum cleaner without the dustbag or filters in place. Otherwise it could be damaged. ~ If a dustbag is not inserted, the dust compartment lid will not close. Do not force it shut. ~ Do not leave the vacuum plugged in. Unplug it from the outlet when not in use and before servicing.

handpiece is a metal insert designed to absorb static electricity. @@This could impair the electrical safety of the vacuum cleaner. Wait for freshly shampooed carpets to dry. burning or smoking, such as cigarettes, matches, or hot ashes. The vacuum cleaner could catch fire.

@@@The vacuum cleaner could explode. heavy, hard or have sharp edges. They could cause a blockage and damage the appliance. @@Do not run the appliance over the cord. Keep the cord away from heated surfaces.

~ Do not vacuum anything that is ~ Do not vacuum toner dust. Toner, ~ Do not use to pick up flammable or ~ On the underside of the vacuum ~ Do not vacuum items which are ~ Do not pull or carry by the cord, use ~ Persons which lack physical, sensory or mental abilities or experience with the machine should not use it without supervision or instruction by a responsible person. 4 IMPORTANT SAFETY INSTRUCTIONS ~ Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord. ~ Do not handle the plug or vacuum with wet hands. ~ Keep the power cord, hair, loose clothing, fingers and all parts of the body away from openings and moving parts. ~ Do not place anything into the openings of the vacuum cleaner. Do not use if any openings are blocked; keep them free of dust, lint, hair, or anything that may reduce air flow. ~ This appliance is equipped with a power cord reel. Hold the plug when rewinding onto cord reel.

Do not allow the plug to whip when rewinding. ~ Turn off all controls before unplugging. stairs. ~ Monitor the dustbag change indicator and inspect all filters regularly. @@@@ Using accessories ~ The hose and the telescopic wand contain electrical wires. Do not use the vacuum cleaner if these parts are damaged, cut or punctured. Avoid picking up sharp objects. Danger of electric shock! accessories, especially the Turbobrush, and Powerbrush. vacuuming with a Miele Power or Turbobrush do not touch the rotating roller brush. Danger of injury.

~ Unplug the vacuum when changing ~ To avoid the risk of injury when ~ Use extra care when cleaning on ~ Floor attachments, accessories and wands must not be used at head level to avoid injury to eyes and ears. 5 IMPORTANT SAFETY INSTRUCTIONS ~ The socket on the vacuum cleaner (depending on model) must only be used for the Miele Powerbrush specified for use with this appliance. ~ Danger of injury. The Miele Powerbrush is a motor driven accessory for use only with Miele vacuum cleaners. The vacuum cleaner must not be used with another manufacturer's powerbrush.

accessory attached. @@@@Unauthorised repairs could cause injury or machine damage. The manufacturer cannot be held responsible for unauthorised work. @@Do not attempt to reuse. @@@@Pull the plug from the outlet.

~ Never submerge the vacuum cleaner in water. @@@@Ensure the appliance presents no danger to children while being stored for disposal.



[You're reading an excerpt. Click here to read official MIELE S4282 user guide](http://yourpdfguides.com/dref/4311066)

<http://yourpdfguides.com/dref/4311066>

The parquet floor brush can be cleaned with the vacuum cleaner using the crevice nozzle if necessary. Floor brush - Parquet Twister with swiveling head For cleaning all hard flooring, e.g. parquet and tiles.

Especially suitable for vacuuming niches and tight spaces. @ @parquet and tiles. @ @ @ @ @The "ActiveAirClean" filter can be used in place of the "Air Clean" filter. There is no difference in the fine dust performance of the "ActiveAirClean" and the "Air Clean" filter. Active HEPA Filter The "Active HEPA" filter combines activated charcoal and HEPA filtration in one.

The active charcoal layer absorbs odors from the dust collected in the dustbag. Vacuum cleaners equipped with this exhaust filter are particularly suitable for allergy sufferers and those concerned with a high level of hygiene because of its ability to trap respirable particles and allergens. Filter frame The filter frame is needed if you would like to exchange an Air Clean filter with an Active air Clean or HEPA filter, see "Maintenance and care Exchanging exhaust filters".

39 Caring for the environment Disposal of the packing materials The cardboard box and packing materials protect the appliance during shipping. They have been designed to be biodegradable and recyclable. Ensure that any plastic wrappings, bags, etc. are disposed of safely and kept out of the reach of children.

These items pose a danger of suffocation. Disposing of the dustbag and filters Genuine Miele dustbags and filters are made of environmentally friendly materials. They can be thrown out with the household trash provided the vacuum cleaner has been used only for normal household dust.

40 41 42 43 Alteration rights reserved/0410 M.-Nr. 07 368 440 / 03 INFORMATION IS SUBJECT TO CHANGE. PLEASE REFER TO OUR WEBSITE TO OBTAIN THE MOST CURRENT PRODUCT SPECIFICATIONS, TECHNICAL & WARRANTY INFORMATION. .



[You're reading an excerpt. Click here to read official MIELE S4282 user guide](http://yourpdfguides.com/dref/4311066)

<http://yourpdfguides.com/dref/4311066>