



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MITSUBISHI EASY02-K60. You'll find the answers to all your questions on the MITSUBISHI EASY02-K60 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MITSUBISHI EASY02-K60
User guide MITSUBISHI EASY02-K60
Operating instructions MITSUBISHI EASY02-K60
Instructions for use MITSUBISHI EASY02-K60
Instruction manual MITSUBISHI EASY02-K60

OPERATOR USER'S MANUAL



DPS TERMINAL
Model MT1 series



**MITSUBISHI
ELECTRIC**
www.mitsubishi-photo.com
Easyphoto v2.4.0 User's Manual
ENGLISH
Rev 1.9

For more information please visit www.mitsubishi-photo.com and www.easyphotosystem.com.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>

.....
.....

.....
.....
.....

.....
.....

..... 8 2.

1.4 Input images via Bluetooth

.....
.....
.....

.....
.....
.....

.... 8 2.2 Photography services.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 9 2.

2.1 Instant Prints

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 9 2.2.2 DVD/CD Burning..

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 9 2.2.3 Compositions .

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....

... 9 2.2.

4 Photo ID (Optional)

.....
.....
.....
.....

.....
.....
.....

.....

9 2.2.5 Calendars (Optional) ...

.....
.....

.....
.....
.....

.....
.....
.....

.. 10 2.2.6 Collage (Optional)

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 10 2.

2.7 Frames and greetings (Optional).....

.....
.....
.....
.....

.....
.....
.....

... 10 2.2.8 Mosaic Poster (Optional)

.....
.....
.....

.....
.....
.....
.....

.....

..... 10 2.

2.9 ONLINE Kioskgifts (Optional)

.....
.....
.....
.....

.....
.....
.....

..... 11 2.3 Picture Retouch .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 11 3 SCREEN FLOW .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... 12 3.1 Services: What do you want to do? ..

.....
.....
.....
.....

.....
.....
.....

.....
.....
.....
.....

..... 16 3.3 Selection of images: Picture loading options ..

.....
.....
.....

.....
.....
.....

..... 16 3.4 Instant prints and retouch: What do you prefer?

.....
.....
.....
.....

..... 17 3.4.

1 Instant prints: 1 copy of all and 2 copies of all

.....
.....

.....
.....
.....

. 18 3.4.2 Additional services: Would you like to burn a dvd or cd?

.....
.....

.. 18 3.4.3 Additional services: Would you like to add an indexprint? .

.....

.....

.. 19 3.4.4 Additional services: select the print finish.

.....
.....

.....
.....
.....
.....

.. 20 3.4.5 Order summary

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

... 20 3.4.6 Retouch: View and adjust my pictures

.....
.....
.....

.....
.....

.....
..... 22 3.4.

6.1 3.4.6.2 3.4.6.3 3.4.6.
4 Red eyes removal

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.... 23 Brightness and contrast

.....
.....
.....
.....
.....
.....
.....
.....

..... 23 Sepia and black/white .

.....
.....
.....
.....
.....
.....
.....
.....

..... 25 Automatic levels ...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.... 25 2/84 Operator users manual 3.4.6.5 Zoom and crop. ..

.....
.....
.....
.....
.....
.....
.....
.....

. 26 3.5 Burning DVD/CD ...

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
. 27 3.5.1 Selecting photos ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
27 3.6 Compositions....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

. 28 3.7 Photo ID (Optional)

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

*... 29 3.7.
1 Taking the pictures*

.....
.....
.....
.....
.....

.....
.....
.....

.....
... 29 3.7.

2 *Selecting the service*

.....
.....
.....
.....
.....
.....
.....
.....
.....

..... 29 3.7.3 *Selecting the picture source* ...

.....
.....
.....
.....
.....
.....
.....
.....

. 30 3.7.4 *Selecting the layout* ..

.....
.....
.....
.....
.....
.....
.....
.....

.....
31 3.7.5 *Selecting and working with the pictures* ...

.....
.....
.....
.....
.....

... 32 3.7.6 *Printing*

.....
.....
.....
.....
.....
.....
.....

.....
.....
.....
.....

..... 38 3.10 Frames & Greetings (Optional)

.....
.....
.....

.....
.....
.....
.....

.....
..... 40 3.

11 Mosaic poster (Optional)

.....

.....
.....
.....
.....

.....
.....
.....
.....

.. 41 3.12 ONLINE Kioskgifts (Optional)

.....
.....
.....

.....
.....
.....
.....

.....

... 42 4 ADMINISTRATION ..

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 45 4.1 System Status ...

.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....
.....
46 4.2 Settings

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.... 48 4.2.1 Main

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. 49 4.2.1.

1 4.2.1.2 4.2.

1.3 4.2.1.4 Installing the system as an Order Terminal

.....
.....
.....

..... 51 Select Kiosk Languages .

.....
.....
.....
.....

.....
.....
.....
.....

... 55 Select Country

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.. 55 Date /Time

.....
.....
.....

.....
.....
.....

.....
.....
.....

. 56 4.2.2 User's administration ..

.....
.....
.....

.....
.....
.....

..... 56 4.2.
3 Devices

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

. 57 4.2.3.1 Devices. Photo printer

.....
.....
.....

.....
.....
.....

... 58 4.2.
3.2 Devices. DVD/CD burner ...

.....
.....

.....
.....
.....
.....
.....
.....
.....

59 4.2.3.3 Devices. Ticket printer

.....
.....
.....
.....
.....
.....

.. 60 4.2.3.3.1. Product barcode settings ...

.....
.....
.....
.....
.....
.....

60 4.2.3.3.2. Order barcode settings

.....
.....
.....
.....
.....
.....

. 61 4.2.4 Services ..

.....
.....
.....
.....
.....
.....
.....

... 62 4.2.4.1 4.2.4.2 4.

2.4.3 4.2.4.4 4.2.4.5 4.2.

4.6 4.2.4.7 4.

2.4.8 Prints. ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 63 Index Print.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 64 Photo ID. ..

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 65 Calendars....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 66 Collage. .

.....

.....

.....

.....

.....

.....

.....
.....
.. 73 5.3 Printer model ..

.....
.....
.....
.....

.....
.....
.....

.....
.....
.....

... 73 6 Recovery USB and easyphoto backups

.....
.....
.....

. 74 6.1 Creation of the recovery tool in a USB drive ...

.....
.....

.....
.....
.....

74 3/84 Operator users manual 6.2 Using the recovery tool

.....
.....
.....

.....
.....
.....

.....
.....
.....

77 6.2.1 Software update.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

78 6.2.2 Create Partial backup

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
. 78 6.2.3 Create Total Backup ..

.....
.....

.....
.....
.....

.....
.....
.....
.....

.... 78 6.2.4 Restore Partial Backup

.....
.....
.....

.....
.....
.....

.....
.....
.....

... 79 6.2.5 Restore Total Backup

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
*.... 79 6.
2.6 Shutdown*

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.... 79 7 ACTIVATING ADDITIONAL LICENSES.....

.....
.....
.....
.....

.....
.....

80 7.1 Register and Getting the Activation KEY

.....
.....
.....
.....
.....

..... 80 7.

2 Activating licenses in the easyphoto application.

.....
.....
.....
.....
.....

.. 81 8 9 TICKET PRINTER INSTALLATION (OPTIONAL)

.....
.....
.....

..... 83 CONTACT ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 84 4/84 Operator users manual 1 INTRODUCTION 1.1 The best choice Easyphoto is the most suitable photographic equipment for the specific necessities of every professional. It has a flexible system of software which allows to set it in function of the real purposes and necessities. Order Terminal is an additional licence. Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter.

The MTI-EVO system already includes this licence from the 2.4. software version. Order Terminal Mode is the mode intended to be used by the end user, like in Kiosk mode, but in this case the easyphoto system doesn't use a local printer. The easyphoto is connected to a Flexilab system (Click5000): this means that many of the printing sizes of the Flexilab system are available for the end user.

The MTI terminal needs to be connected to the Click5000 through a network cable. 1.4 System Users Easyphoto is characterized for the possibility to be open option. 2.2.

3 Compositions The customer can prepare a composition of pictures using only one picture. It's possible to choose the layout from a maximum of 4 different layouts available, and those depending on printer media size. The MTI-ID system does not have this service. 2.2.4 Photo ID (Optional) NOTE Photo ID is an additional licence. Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter. This service allows printing a composition of photos for identity cards, passports, wallet size portraits, etc..

. and its only available for the operator. Even in Kiosk mode, this service is protected under password, and needs to be used by the shop-staff. Easyphoto offers different compositions among which the operator may choose one. 9/84 Operator users manual The advantage of using this service instead of basic Compositions service for ID purposes is the fastest way (express workflow) to get the pictures from the source, the possibility to mix 2 different pictures in the same print, the use of biometrics masks, the direct print button, the refresh button for continuous shooting and printing, the better accessibility to different tools to adjust zooming, cropping and pan of the picture, and the automatic biometrics detection. The automatic biometrics detection processes the picture of the customer and helps the operator to fit the face inside the biometrics mask that follows each country regulations. This saves time to the operator to get the right ID print. 2.2.5 Calendars (Optional) NOTE Calendars is an additional licence.

Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter. The MT1-EVO system already has this licence. This service allows printing a customized calendar of the whole year in separate prints (one per month) or the whole year in one print. This service is available in all working modes.

2.2.6 Collage (Optional) NOTE Collage is an additional licence. Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter.

The MT1-EVO system already has this licence. This service allows printing a composition of several pictures of the customer (in a decorative manner) over a selected a background. This service is available in all working modes. 2.2.7 Frames and greetings (Optional) NOTE Frames and greetings is an additional licence. Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter. The MT1-EVO system already has this licence. This service allows printing a picture into a decorated frame with some additional editable text.

This service is available in all working modes. 2.2.8 Mosaic Poster (Optional) NOTE Mosaic Poster is an additional licence. Contact with your dealer to acquire this licence.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>

See also „ACTIVATING ADDITIONAL LICENSES chapter. The MT1-EVO system already has this 10/84 Operator users manual licence. This service allows printing a poster composed by several sheets of paper. There are different mosaic poster sizes depending on the available printing sizes. This service is available in all working modes.

2.2.9 ONLINE Kioskgifts (Optional) NOTE ONLINE Kioskgifts is an additional licence. Contact with your dealer to acquire this licence. See also „ACTIVATING ADDITIONAL LICENSES chapter.

The MT1-EVO system already has this licence. The end customer can print orders prepared at home using the online application found at www.kioskgifts.com. At www.kioskgifts.com

customers can order different types of products such as calendars, greetings cards or albums from any PC or MAC, save the order on a digital card or USB drive and take it to the Kiosk where it will be printed. 2.3 Picture Retouch This is a range of tools offered to the customer in order to be able to make adjustments to the pictures in the development services. Black and white: Transforms colour images to black and white. Sepia: Transforms colour or black and white images to sepia. Brightness and contrast: To increase or decrease the brightness and contrast in order to improve the quality of the image. Zoom and crop: Uses the "+" and "-" icons to decrease or increase the cropping area. Use the arrows to move the image. Automatic: Automatic adjustments to improve the quality of the image.

Very useful for pictures taken by non professional photographers. Red eyes removal: Allows to remove the red eyes effect from the images. Rotate: Allows the image to be rotated. Restore: Restores the original image as it was before the changes. 11/84 Operator users manual 3 SCREEN FLOW NOTE For accessing to the services of Easyphoto: Before switching on the equipment, make sure that there is no additional USB storage devices connected. It may cause problems when detecting the different devices later. 1. Touch the red button to switch on the Easyphoto terminal. Access to services by touching the screen with your finger. The flow of the screens and the meaning of each one are explained on this chapter.

When the system is inactive for 60 seconds in the main screen, appears a screensaver on the monitor. When the monitor is touched, Easyphoto can be used again. In Kiosk mode, if the system is left at any point of the workflow, after 100 seconds it appears a message asking for confirmation. If the message is not answered, the system closes the current session and goes back to main screen. NOTE PLEASE ALWAYS SWITCH OFF THE SYSTEM USING SHUTDOWN SOFTWARE FUNCTION, AVAILABLE AT ADMINISTRATION SCREEN.

USING BACK PANEL RED BUTTON TO SHUTDOWN THE SYSTEM IS NOT RECOMMENDED. 12/84 Operator users manual 3.1 Services: What do you want to do? Once the Easyphoto has been switched on, you can see the first screen: On this screen you can: Use the arrows to select the desired language. Press the "Price list" button to display the price list. Access to the services of Easyphoto.

For accessing to any service: 1. Press the required Easyphoto service (Copies, DVD/ CD burning, Compositions, Photo ID...). Photo ID software is only visible in Operator mode. See Photo ID chapter for more details. 2. Press "I accept the conditions". NOTE It is strongly recommended to keep enabled the "Terms and conditions" screen when the system works in Kiosk mode and is being used by end customers.

13/84 Operator users manual 3.2 Input of images: Where do you have your pictures? Once any service has been selected, the following screen is displayed: Choose the option in which your images are saved. The system can open only these kinds of picture files: JPG, BMP, TIF, PNG and GIF. 3.2.1 Memory Card If your images are saved in a memory card: 1. Press the "Media card" button. The following screen appears, indicating how and where to introduce the memory card. Introduce the memory card as indicated on the screen. Press "Next".

14/84 Operator users manual 3.2.2 USB pendrive If your images are saved in a USB pendrive: 1. Press the "USB pendrive" button. The following screen appears, indicating how and where to introduce the USB pendrive.

Introduce the USB pendrive as indicated on the screen. Press "Next". 3.2.3 DVD/CD If your images are saved in a DVD/CD: 1. Press the "DVD/CD" button. The device opens automatically. The following screen appears, indicating how and where to introduce the CD/DVD. Insert the DVD/CD as indicated on the screen. Press "Next" or push the tray. 15/84 Operator users manual 3.2.4 Bluetooth If your images are saved in a Bluetooth device: 1. Press the "Bluetooth" button. The following screen appears, indicating how to transfer the images.

Transfer the images as indicated on the screen. Press "Next". 3.3 Selection of images: Picture loading options Once the pictures from the source have been correctly detected, a new screen is displayed: You can choose: "Choose folders" to select the folders where you have the pictures that you want to use. This option is useful to avoid spending too much time loading hundreds of pictures. "All pictures" to select all the folders and images detected. If "Choose folders" is selected, a new screen is displayed: 16/84 Operator users manual 1. Use the arrows to navigate through all the folders. Every folder shows a sample of pictures contained in the folder. 2.

Press the desired folder or folders to select them. For deselecting folders: Press the selected folders for deselecting. Press "Continue". 3.4 Instant prints and retouch: What do you prefer? Once the folders containing pictures have been selected, you have the following possibilities: On this screen, you can choose: 1 copy of all: Select it to print one copy of all detected pictures in the selected folders.

This is the fastest option when there is no intention of retouching or previewing the pictures. Many customers want to print all the pictures contained in the source, and this option saves time for them. 2 copies of all: Same than before but printing 2 copies per each picture. View and adjust my pictures: Select it to view, select and retouch the detected pictures. 17/84 Operator users manual 3.

4.1 Instant prints: 1 copy of all and 2 copies of all Once the "1 copy of all" or "2 copies of all" buttons have been selected, a new screen is displayed: 1. Press the button/ buttons which indicates the desired sizes to select them. Also these buttons shows the prices. The green tic indicates the selected print size. Press the "Finish order" button for printing the order. This button also indicates the number of copies and the total price of the order. For changing the size: 1. Press the selected size for deselecting.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>

Press the button with the new required size.

The screen shows a sample of the customer pictures. The real print area is shown over the picture, changing each time the customer selects a different print format. 3.4.2 Additional services: Would you like to burn a dvd or cd? This option appears after pressing the "Finish order" button. Choose this option if you want to burn a DVD or CD. On this screen you can see the price of burning a DVD/CD. Select "Yes, save all files" if you want to save all files. 18/84 Operator users manual NOTE If "save all files" is selected: All the files (movies, mp3, etc..

) included in the device will be burned on the CD/DVD. The original images will be burned on the CD/DVD and not the edited ones. Select "Yes, only selected pictures" if you want to save only the selected pictures. NOTE If "Yes, only selected pictures" is selected, the edited images will be burned on the CD/DVD in the root of the DVD/CD, and also the original ones (keeping file structure).

For the edited pictures, the original filename will be changed and the picture will be saved as BMP. . Select "No" if you do not want to burn a CD/DVD. NOTE If the "Burning DVD/CD services is disabled this additional service wont be available. 3.

4.3 Additional services: Would you like to add an indexprint? This option appears after answering "Would you like to burn a dvd or cd?" On this screen you can see the price of adding an indexprint and DVD/CD burning services, and the customer choice. Choose "Would you like to add an indexprint?" if you want to add an indexprint. Select "Yes, all memory card" if you want to add an indexprint with all the images. Select "Yes, only selected pictures" if you want to add an indexprint with only the selected images. Select "No" if you do not want to add an indexprint. NOTE Only one sheet of paper is used to print an indexprint.

When there is not enough space to show all selected pictures in the indexprint, a summary of all pictures is shown. 19/84 Operator users manual 3.4.

4 Additional services: select the print finish. This option is shown after responding to the question "Do you want to add an indexprint?". In this screen, customers are asked whether they want a glossy or a satin paper print finish. This will only be shown when the printed installed is a CPD70 or a K60, if the equipment is configured to show that option. 3.4.5 Order summary After answering "Would you like to add an indexprint?" the following screen is showed: This screen lists all the services requested up to this moment and their cost. Press "Next" to confirm the order summary. In Kiosk mode an screen keypad is shown: its necessary to validate the order by entering the operator password. It starts the process of printing and the following screen is showed: 20/84 Operator users manual In this screen is possible to see the progress of several services execution.

There is a possibility of pausing the printing service (not the DVD burning) by pressing both top corners and entering the operator password. Then, a new screen is shown where you can choose between cancel the order or retry (continue). This order status screen is also automatically shown when a critical error occurs: if the operator can recover the system from the error (when the systems runs out of media, or the printer is accidentally disconnected, as instance), he can try to press „retry button to allow the order execution going on. 21/84 Operator users manual 3.4.

6 Retouch: View and adjust my pictures Once the "View and adjust my pictures" button has been selected, a new screen is showed: Choose this option to retouch the selected image before printing. 1. Use the arrows which are on the top of the screen to select the image. Choose the size and quantity. You can see the price.

Press "Rotate" if you need to rotate the picture view. NOTE The original picture is not rotated; this is only a „preview rotation. Even when the rotated picture is used for Retouch operations, the original picture wont be rotated. This is noticeable when you rotate a picture, retouch it and then burn it into a DVD. The picture in the DVD shows retouch operations, but preserves original rotation. Press "Retouch" to retouch the image. Once is pressed "Retouch", you can see the following screen where you can select the different options of retouching. The function of each option is explained in point 2.3 („Picture retouch). NOTE There is a limitation in the number of images allowed to be changed by retouch functions, depending on the size of the picture.

When the limit is reached, the customer sees a warning message under the main picture of the Ordering screen. 22/84 Operator users manual Press "Finish order" to print. In this moment the screens explained from point 3.4.2 (Additional services: Would you like to burn a dvd or cd?) will be displayed. 3.4.6.1 Red eyes removal Once the "Red eyes removal" button is pressed, the following screen is showed: For removing the red eyes effect: 1. Press the "Remove" button, as many times as you need until you see a nice result.

Press the "Keep press to compare" button to display the original image without changes. Press the green tic to save the changes. Press the red cross to not remove the red eyes effect and escape this screen. 3.4.

6.2 Brightness and contrast Once the "Brightness and contrast" button is pressed, the following screen is showed: For increase or decrease brightness and contrast effects: 1. Press the "-/+ brightness" button. 2. Press the "-/+ contrast" button.

Press the "Keep press to compare" button to display the original image without changes. Press the green tic to save the changes. Press the red cross to not save the changes and escape this screen. 23/84 Operator users manual 24/84 Operator users manual 3.4.6.3 Sepia and black/white Once the "Sepia, black and white" button is pressed, the following screen is showed: For changing the image to black and white: 1. Press the "Black and white" button. Press the "Keep press to compare" button to display the original image without changes. Press the green tic to save the changes.

Press the red cross to not save the changes and escape this screen. For changing the image to sepia: 1. Press the "Sepia" button. Press the "Keep press to compare" button to display the original image without changes. Press the green tic to save the changes. Press the red cross to not save the changes and escape this screen. 3.4.6.4 Automatic levels Once the "Automatic levels" button is pressed, the following screen is showed: For improving the image automatically: 1.

Press "Auto" button Press the "Keep press to compare" button to display the original image without changes.



[You're reading an excerpt. Click here to read official MITSUBISHI](http://yourpdfguides.com/dref/4210477)

[EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)

<http://yourpdfguides.com/dref/4210477>

Press the green tic to save the changes. Press the red cross to not save the changes and escape this screen. 25/84 Operator users manual 3.4.6.5 Zoom and crop. Once the "Zoom and crop" button is pressed, the following screen is showed: For increasing or decreasing the image: 1. Use the arrows to select the part of the image you are interested in. Press "-/+ zoom controls" buttons.

Press the green tic to save the changes. The images can be cropped in two formats: Portrait. Landscape. For cropping the image: 1. Use the arrows to select the part of the image you want to crop. 2. Press "Portrait/Landscape" buttons. 3. Press the green tic to save the changes. Press the red cross to not save the changes and escape this screen.

26/84 Operator users manual 3.5 Burning DVD/CD Once the "DVD/CD burning" service button is pressed, the following screen is showed: Press "Burn all" button if you want to burn not only pictures but also all the files found in the original media. In this moment the screens explained from point 3.4.2 (Additional services: Would you like to burn a dvd or cd?) will be displayed. Press "Select photos" if you want to burn it with the selected pictures. 3.5.1 Selecting photos Once the "Select photos" button is pressed, the following screen is showed: For selecting the images: 1. Use the arrows to display all the images. 2. Press the desired image to select it. Press "Yes" to copy it and "No" to deselect it. Press "Back" button to escape this screen. Press "Finish order" to burn it.

In this moment the screens explained from point 3.4.3 (Additional services: Would you like to add an indexprint?) will be displayed. NOTE The DVD/CD burning service doesnt allow using a DVD/CD as a picture source. This one is disabled.

27/84 Operator users manual 3.6 Compositions Once the "Compositions" button is pressed, the Compositions service is started. The customer is asked to insert the picture source and after following the usual workflow, the pictures can be seen at the Ordering screen. In the right panel of the screen a maximum of 4 different layouts can be shown. The available layouts depend on the selected country (in settings of the system) and the paper size of the printer. Only one picture can be selected, and also only one layout can be chosen by the end customer. When the picture is selected, its automatically allocated in the selected layout to the right panel. In the center area is possible to check the cutting area of the layout rectangle. In order to fit better the picture inside every frame or rectangle, sometimes is better to rotate the picture. After pressing the "Finish order" button, a pop-up will appear in order to determine the amount of copies desired 28/84 Operator users manual 3.

7 Photo ID (Optional) Its highly recommended to follow the next steps to make an ID service. 3.7.1 Taking the pictures Before selecting the PhotoID service at the main screen, the operator should take the pictures to the customer. When using a digital camera with an USB cable connected to easyphoto: If an USB switch is being used between the camera and the easyphoto, this must be switched to the position where the connection between both devices is disabled, in order to allow the camera to take pictures. When an USB switch is not being used, the digital camera USB cable should be disconnected from the easyphoto. NOTE The behaviour of the camera when the USB cable is connected or disconnected may vary depending on the camera brand/model used. Also, the use of an USB switch is not always necessary. Please ask for more information to your dealer or installer. 3.

7.2 Selecting the service Once the "Photo ID" button (in operator mode) is pressed, or the hidden area between language selection (flags) and prices is pressed, the Photo ID service is started. 29/84 Operator users manual 3.7.3 Selecting the picture source After this, depending on the system setup, its necessary to follow the source selection workflow or it can be avoided if the operator is using always the same digital picture files source (see the Administration and Settings chapter for more information).

@@It will search the pictures from the camera directly. @@@@There are two kind of layouts, standard and split. @@When selecting any of them, the picture will be loaded to be shown in the central area. In this screen, its also possible to change the layout by clicking on the preview placed on the topright corner. The select layout screen will appear again to restart the workflow.

32/84 Operator users manual Once in the Photo ID screen again, its possible to select another picture. 3.7.6 Printing After pressing the "Print" button, a pop-up will appear in order to determine the amount of copies desired. When pressing the refresh button, the latest images from the picture source are reloaded. When using a camera with PTP connection, only the latest 8 images from the device are loaded. 33/84 Operator users manual 3.7.7 Automatic biometrics detection When automatic biometrics detection is active in the settings (see Administration chapter), it will take some more time and the picture could appear centred and zoomed. @@@@In this case please make final adjustments manually.

You can use several buttons to change: Rotation. @@@@Refresh. @@@@Zoom. Position. Steps: 1. Select the picture in the top area. @@@@2. @@ Press "Back" button to escape this screen. @@@@The system then will automatically calculate the following 11 months. e.

g. @@@@There is a help guide shown in the right part of the screen. Its required to select a picture in the top section of the screen in order to combine it with the calendar shown in the central area. Monthly option uses twelve different photos, one for each month. After selecting the picture for the first month of the year, its required to use the arrow buttons shown in the part 3 of the help guide, in order to move to the next month, and select later the next picture to be combined.

It is recommended to follow the process in order, month after month, so there wont be any „empty month when the operator is about to complete the whole year calendar (its not possible to use the same photo in two different months). Anyway, a warning will be displayed if one month does not have a picture when pressing „Next button in order to proceed with the following steps. Afterwards, the standard workflow is followed. Before confirming the order, the user is asked to choose the print size and the number of copies per each print size. 36/84 Operator users manual 3.

8.2 Full year calendars This option makes it possible to create a calendar of a specific year and using only one sheet. To do so, both the "Full year" option and the desired year will be selected. Pressing „Next, the thematic and design of the calendar can be chosen among several types.



[You're reading an excerpt. Click here to read official MITSUBISHI](http://yourpdfguides.com/dref/4210477)

[EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)

<http://yourpdfguides.com/dref/4210477>

Pressing „Start calendar creation the „Full year calendar making is started. Its required to select a picture in the top section of the screen in order to combine it with the calendar shown in the center. 37/84 Operator users manual „Full year calendar option uses only one picture for the whole year (only 1 sheet of paper). After selecting the picture and adjusting the position in the calendar, „Next button must be pressed to go on. Before confirming the order, the user is asked to choose the print size and the number of copies per each print size. 3.

9 Collage (Optional) Once the "Collage" button is pressed, the Collage service is started. First of all, the printsize is required to be chosen. After this, the browser screen is shown. To select a picture in order to include it in the collage, the right panel buttons are being used. There is a minimum and a maximum amount of pictures to be selected. Both figures depend on the previously selected printsize. After that, is required to select the layout among the different displayed. The photos of the collage can be rotated by selecting them one by one and pressing the "rotate" button. The colour of the background can be selected in the same screen. 38/84 Operator users manual After that, is required to select size and number of prints to follow the standard workflow.

39/84 Operator users manual 3.10 Frames & Greetings (Optional) Once the "Frames & greetings" button is pressed, the Frames & greetings service is started. The theme and design selection screen appears. Once the design is selected, the photo must be chosen and the resultant greeting will be displayed. Some designs can show an specific text like „Happy christmas, „Happy holidays and so on, or a default text like „Enter your text here.

Whatever the text is, it always can be changed by the end user. In the text edit menu, its possible to change the font type, font size and font color. After that, the number of copies can be chosen in order to end the process. 40/84 Operator users manual 3.11 Mosaic poster (Optional) NOTE The pictures used for this service must be carefully selected in order to avoid undesirable results.

The subtle separation between the pieces of the mosaic can hide important parts of the picture, as instance in people portrait photos, hiding part of the face. The zoom and pan adjustments, together with the poster size, have a great influence in the final result. Once the "Mosaic Poster" button is pressed, the service is started. Depending on the paper sizes configured there will appear different mosaic sizes. After choosing the mosaic size, a picture browser appears just showing a preview of the mosaic using the selected picture. 41/84 Operator users manual 3.12 ONLINE Kioskgifts (Optional) This service offers the possibility of printing the orders created at www.kioskgifts.com. The Kiosk doesnt require an Internet connection for this service: the website allows the user to create a product anywhere using a PC or MAC and an Internet access and take the order saved on a memory card, USB or DVD/CD to the store.

NOTES Many different products can be created at www.kioskgifts.com. @@@@This is the list of possible error codes. @@Software update is recommended. @@Order is damaged and cant be processed. Order is damaged and cant be processed. @@@@In order to avoid confusions, the letters are shown in black and the numbers in green. 45/84 Operator users manual For acceding to "Settings": Introduce the supervisor password. The default password from factory is empty.

It is highly recommended to change supervisor password once the system is installed. 4.1 System Status In this option operators and supervisor can access to technical information of the equipment. This information is useful for service or remote support purposes. The information is divided into 3 different areas: Printers: the information about the MITSUBISHI photo printer and ticket printer is shown in this area.

Device proper connection or available media information is available. Sources: all information about picture source hardware devices is shown. Device manufacturer/model and other information like memory card inserted or CD/DVD inserted is also available. When using a PTP compatible Digital Camera, the identification provided by the camera is also shown here. General: general hardware & software information is shown, like MTI hardware model, available memory, total free space in disk, network information, and O.

S version and build date. 46/84 Operator users manual 47/84 Operator users manual 4.2 Settings Once the "Settings" button is pressed, the supervisor password is requested and the following screen is showed: Supervisor can enter to the following options: Main. Users administration. Devices. Services. Statistics. Import/export settings. Screenshots. Orders In some parts of "Settings" it is necessary to enter a text.

The on-screen keyboard can then be used. Its composed by two layers: The first one shows the alphanumeric keyboard and the second one appears when pressing "Others" button showing a keyboard with special characters. With the second layer alphabets with more than 26 letters such as Hebrew or Russian are supported. 48/84 Operator users manual 4.2.1 Main Once the "Main" button is pressed, the following screen is showed: On this section you can choose:

Workflow mode: Kiosk mode / Operator mode / Order Terminal mode Available languages for the end customer in mode Kiosk („Kiosk language) Current country Date and time setting (for ticket printer) Enable/disable ticket printer (if available) NOTE Please choose: „Operator mode when Easyphoto has to be used by operators and the supervisor. „Kiosk mode when Easyphoto has to be used by end users (end customers) as a semiattended photo system. „Order Terminal mode when Easyphoto is attached to a Flexilab system. THIS ONE REQUIRES AN ADDITIONAL LICENSE. Once the Kiosk mode, Order Terminal or Operator mode have been selected: Press the "Show available languages at first screen" button to show the available languages at fist screen.

Press the "Show disclaimer" button to show the legal disclaimer at the beginning of the operation of Easyphoto. Press the "Use password for order validation" to introduce the password at the "Order summary" screen. In Operator mode the main screen should be shown like this (with default values): no language selection is available. There is no need for the operator to choose a different language than default one, and also prices list and disclaimer have no sense to be shown. 49/84 Operator users manual In both Kiosk Mode and Order Terminal Mode the main screen should be shown like this when default values are not changed: 50/84 Operator users manual 4.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>

2.1.1 Installing the system as an Order Terminal In order to use the easyphoto as an Order Terminal, its necessary to change the working mode and set the network parameters after activating the license, in the equipment in which this is necessary. This can be done in 2 different ways: Basic and Advanced Mode.

For a basic lan connection (using a crossover network cable or ethernet hub), its recommended to use the Basic Mode, because of the easier setup.

When the system is attached to a corporate lan, its better to use the Advanced Mode. NOTE The Click5000 of the Flexilab system needs to run software version 2.4.0 or above in order to support an attached easyphoto working as an Order Terminal. The shared resources of Click5000 must allow file writing operations to the client machines: D:\APPLICATIONS\ORDER_TERMINAL shared as „OTFOLDER

D:\KERNELSERVICE_MODULES\DP\SLAB_LISTENER\INCOMING_ORDERS shared as „ERequest Steps to follow for installing the easyphoto as Order Terminal (Basic mode) a) Please connect both Click5000 and easyphoto systems with a crossover network cable or Ethernet hub, and switch on both systems.

b) If the easyphoto system was never activated as an Order Terminal before, please be sure that you have your Activation Key, and proceed to next step. See chapter 6 for more information about licensing. If you are not sure if the system was already activated in the past, please proceed to next step anyway. c) Go to Settings Main and select the „Order Terminal Mode. If any Activation Key is asked, please enter it now.

For more information please see chapter 6 of this manual. d) Now its necessary to configure Network settings. Please go to Settings Devices Network. 51/84 Operator users manual e) Once "Network" button is pressed, please choose the „Basic mode option. Set the „O.T number using the „+ and „-, buttons as „1 if there is only one Order Terminal connected to Click5000. (Change this number only if you are installing multiple easyphoto systems working as O.T. together with the same Click5000.) f) Even if you didnt change anything on this screen, please press the „Apply button.

There is a „Check connectivity button in this screen. Please DO NOT CHECK CONNECTIVITY YET! Please use it after restarting the system if you need to check. g) Restart the system. h) After restarting the system, please set the rest of settings of the system like the printing sizes, product prices and so on. 52/84 Operator users manual i) Once the system has completely been configured, its recommended to export the settings.

When working as an O.T., the settings are not exported to an external device: Click5000 will keep the easyphoto settings. See the „Import/ Export settings chapter of this manual. This way of work is useful when installing additional O.

Ts: all the previous steps are required for every O.T., except the h) step, that can be avoided just importing the settings from Click5000. Basic and Advanced mode. A deeper view. Basic mode: the Order Terminal (O.T.) number can be changed. This is useful, when using a basic lan installation, to identify each easyphoto connected to a Flexilab system. In this way, the basic connection parameters are changed automatically.

In this mode, Click5000 is supposed to be working with these parameters: IP: 192.168.0.100 IP mask: 255.255.255.0 Gateway: 192.168.0.1 And the easyphoto with these ones (when O.

T. number is „1): IP: 192.168.0.201 IP mask: 255.255.255.0 Gateway: 192.168.0.

1 Machine Name & Bluetooth ID: MT1-1 Initial order number: 1000 If O.T. number is changed, as instance, to „2, these parameters will be changed automatically to these new ones, and so on: IP: 192.168.0.202 IP mask: 255.255.255.0 Gateway: 192.168.

0.1 Machine Name & Bluetooth ID: MT1-2 Initial order number: 2000 NOTE Pressing "apply" button will reboot the system. Do not attempt to test connectivity before applying the changes Advanced mode: manual configuration of all the net parameters such as machine name, IP, Mask, Gateway IP, etc. 53/84 Operator users manual By pressing check connectivity button, a connection test is performed to ensure that the parameters are valid. The Machine Name parameter (visible in the Advanced Mode section) is also used to set the Bluetooth Name (ID). Even using the Basic mode, if the Bluetooth ID needs to be changed, its possible to select Advanced Mode and change this parameter. This is useful when there is more than one easyphoto (even working as standalone system) in the same place, in order to avoid duplicated Bluetooth ID. NOTE Pressing "apply" button will reboot the system. Do not attempt to test connectivity before applying the changes 54/84 Operator users manual 4.2.

1.2 Select Kiosk Languages 1. Use the arrows to display all the languages. 2. Press the languages to select them.
4.2.1.3 Select Country 1. Use the arrows to display all the countries.

2. Press the country to select it (only one can be selected at the same time). NOTE When changing the country, the application is automatically restarted with the new country parameters already set. Selecting a country means that the following parameters are changed: Default easyphoto language. Currency (symbol and symbol position). Measurement units (cm or inches). VAT information message (needs to be entered in the text box). 55/84 Operator users manual 4.2.1.

4 Date / Time Date and time configuration. In order to advance or take the date back, „hour setting must be changed. Only 1 day shifting can be applied.

4.2.2 User's administration Once the "Users administration" button is pressed, the following screen is showed: On this screen: Press the "Change name" button to modify the name of the operator and the supervisor. Press the "Change password" button to modify the supervisor or operator passwords. Press the "Clear button" to restore the modified names of operators and supervisor. 56/84 Operator users manual 4.2.

3 Devices Once the "Devices" button is pressed, the following screen is showed: Press the "PhotoPrinter" button to modify the MITSUBISHI photo printer default printing quality settings. Press the "DVD/ CD Burner" button to increase or decrease the recording speed. Press the "Printer ticket" button to change the receipt ticket messages, like shop name, address, phone number, etc...

Press the "Touch panel calibration" button to calibrate the screen. Press the "Network" button to setup network parameters when the system is working as an O.T. Also to setup Bluetooth communication. NOTE In order to setup the Bluetooth configuration (Bluetooth name for the easyphoto) see chapter „Network Settings.

57/84 Operator users manual 4.2.3.1 Devices. Photo printer Once the "Photoprinter" button is pressed, the following screen is showed. Depending on the printer model used, some of these parameters wont be shown: Change "Sharpness" value to enhance the sharpness of the printed pictures.



[You're reading an excerpt. Click here to read official MITSUBISHI](http://yourpdfguides.com/dref/4210477)

[EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)

<http://yourpdfguides.com/dref/4210477>

"Noise reduction" value can help to reduce grain or noise in flat color areas. Default value is "off". "Quality". Printing speed can be changed.

While "Fine" value means faster printing speed, "Super Fine" means slower printing speed but better quality. Default value is "Fine". "Auto-adjustments". This is an automatic brightness and contrast functionality, based in the content of each picture. Its very useful for amateur pictures, and the result can be very impressive on dark or poor contrast pictures. "ICC Profiles". In the CPD70 and K60 models only the colour management function can be activated or deactivated through the ICC profiles. In the case of the CP9550DWS, the ICC profile menu is accessed. This menu is for advanced users or technical staff. It allows to manage the ICC profiles for every printing size and speed.

58/84 Operator users manual Activate virtual printer. This allows you to work with the equipment without the printer connected. It simulates the connection of a printer with a 15x32 size consumable. Print finish options. Only for the CPD70 and K60.

This is configured if the print finish is glossy or satin by default, or if the end customer is asked to choose one of the two options. 4.2.3.2 Devices.

DVD/CD burner Once the "DVD/CD Burner" button is pressed, the following screen is showed: Press "-/+" button to increase or decrease the burning speed.

59/84 Operator users manual 4.2.3.3 Devices. Ticket printer Once the "Ticket Printer" button is pressed, the following screen is showed: In this one, its possible to edit the contents shown in the ticket. The barcodes shown are formatted in EAN13 standard. A screen keyboard is available to fill this data: Shop name Address (2 lines) Phone number 4.2.3.

3.1. Product barcode settings This is the barcode that identifies the product among the different available products in the easyphoto machine. Print product barcode: When its enabled, a barcode will be printed for each product. Print product reference: When its enabled, a different number will be printed per each product reference, instead of using a barcode. 60/84 Operator users manual Length: It allows setting the length of each part that composes the barcode. o Reference: Number of digits used to show the product reference. o Amount: Number of digits used to show the product price. Position: It specifies which field (Reference or Amount) is placed first in the barcode. The product reference is filled in the screen where prices are set.

(See chapter 4.2.4.1(3) "Prices settings") 4.2.

3.3.2. Order barcode settings This is a unique barcode being printed for the whole order, including the total price and global reference to the easyphoto service for the shop accounting. Print order barcode: When its enabled, a barcode will be printed for every order generated in the machine.

Length: it allows setting the length of each part that composes the barcode. o Reference: Number of digits used to show the order reference. o Amount: Number of digits used to show the order price. Reference: This is the code that identifies an easyphoto order. Position: It specifies which field (Reference or Amount) is placed first in the barcode. 61/84 Operator users manual 4.2.4 Services In "Services" it is possible to enable or disable services and set their prices and options when available. By pressing the button „Sizes the different print sizes can be defined for the selected service. When the system is set up as an Order Terminal, the list will be longer than if it is set up as an autonomous terminal.

NOTE It is highly recommended to enter this screen with the printer CONNECTED and the consumable already installed. Otherwise, certain configurations may be lost later. To check the available options per each different service, just press "Settings" button when the desired service is selected (rounded with the green square). 62/84 Operator users manual 4.2.4.1 Prints. By pressing the „Sizes button the available printing formats can be set. 1. Use the arrows to display all the sizes.

2. Press the desired sizes to select them. NOTE You can select a maximum of 4 sizes (when the system is not working as O.T.) When working as an O.T., its necessary to previously check that the selected print sizes are available at Flexilab size, otherwise the orders will never be printed out. If there is no printer attached to the system, the default print media size is 6x9 inches (15x23cm). 3. Press the "Prices settings" button to display all the prices and/or modify them.

The following screen is showed: 4. 5. 6. 7. 8. 9. Use the arrows to move across all available services. Press the price you want to modify. Once the price is selected, write the new one. Insert the product reference (it will be used in the ticket printing).

See chapter 4.2.3.1) Activate/deactivate price ranges by pressing the green circles. Enter the amount of copies of the range when activating a new one. 63/84 Operator users manual After pressing the button "back", the next screen will appear in order to apply the changes or not. NOTE Its highly recommended to enter this screen with the printer POWERED ON and the media already installed. Otherwise some configurations can be lost later. 4.2.

4.2 Index Print. By configuring this service, it is possible to set the print size, depending on the media size detected. In the example, 6x9 inch media size is installed in the printer, and up to 6 different print sizes can be printed with this media size, by cutting the paper automatically in the printer itself. 64/84 Operator users manual 4.

2.4.3 Photo ID. When configuring this service, it is possible to set a default picture source. This helps to increase the workflow speed and avoids asking the operator where the system will find the pictures every time.

The professional photographer is used to take ID pictures with the same camera and digital media. So, its not necessary to select picture source on every order and loose time to make the service. The available options are USB, MMC (digital media card) and PTP. The option of printing this type of service on satin or glossy paper is also shown. This option is only shown for certain printer models: CPD70 and K60. The PhotoID rotation angle allows setting an automatic rotation angle for every picture that the photographer takes. This helps to save time, too. Its also possible to enable or disable in this screen the auto biometric detection every time that a picture is selected in the thumbnails array of PhotoID. Default value is „enabled (checked). In the Advanced PhotoID settings is possible to adjust some picture properties corrections in order to be applied automatically every time an ID picture is being printed.

Brightness, contrast and color balance can be set. This function can be enabled or disabled, too. A sample picture can be loaded (either from the USB or memory card source) in order to adjust the parameters.



[You're reading an excerpt. Click here to read official MITSUBISHI](http://yourpdfguides.com/dref/4210477)

[EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)

<http://yourpdfguides.com/dref/4210477>

65/84 Operator users manual 4.2.4.4 Calendars. The purpose of these settings is to maintain the library of available calendar designs per every year. Every item of the list shown in the screen belongs to a different language, showing the first and the last of the available years. By configuring this service, depicted on the image below, it is possible to change the following settings: 1.

Delete all calendars. This option will delete all the installed calendars, regardless of the selected language. 2. Delete until the previous year. This option will delete all the calendars of the previous years, leaving the current year and the following years, regardless of the selected language.

. 3. Import designs. This option allows importing designs of calendars from the distributed Calendars Designs CD. 4.

Default language selection. The ticked language will be set as default language. In the case that the system language or the language selected by the end user does not match with any of the installed calendar languages, the calendars on the language ticked as default will be shown. 5. Storage Space Available. It shows the information about the free disk space in the system. 66/84 Operator users manual NOTE In order to import new designs, as shown on the following screen, it is needed to select the calendars languages that will be installed on the system from the distribution CD. Please do not install more than 4 different calendar collections in the system. Consider the available storage space before installing new calendar collections. Old calendar collections can be deleted in case of more space is needed.

4.2.4.5 Collage. By configuring this service, depicted on the image below, it is possible to change the following settings: 1. Import Backgrounds: . This option allows to import new different background.. 2. Restore backgrounds:.

This option allows to restore the originally included backgrounds.. 3. Select border color and thickness: This option allows to set different styles of the border in the collage pictures. NOTE In order to import new backgrounds an usb pendrive has to be plugged in, and the system wont ask for confirmation.

67/84 Operator users manual 4.2.4.6 Frames & Greetings. By configuring this service, depicted on the image below, it is possible to change the following settings: 1.

2. 3. 4. Delete All. This option allows deleting every frame&greeting design available in the system. Delete by theme. This option allows deleting the frames&greetings selecting by theme. Import designs. This option allows importing designs of frames&greetings. Change font.

There are five different text fonts selected by default. The final user will be able to choose among these five text fonts. Its possible to change them by selecting the one to replace and then click Change font. It will appear the picture shown below with a list of available the fonts and there the desired font has to be chosen. NOTE In order to import new designs it is needed to press „Import designs and then follow the same workflow as when importing calendars 68/84 Operator users manual 4.2.4.7 Mosaic Poster. Its possible to select which mosaic poster formats will be available at Mosaic Poster service. NOTE The available formats may differ from picture above, according to the available print sizes in the system.

4.2.4.8 ONLINE Kioskgifts. In the settings section, the list of all the available products is shown.

All the different products (easyalbum, greetings, calendars...) are together in the same list. The sole purpose of this screen is to permit each product to be enabled or disabled.

69/84 Operator users manual 4.2.5 Statistics When this option is enabled in Statistics menu you can see all the orders done in the easyphoto.. Its also possible to export statistics in xml format in order to keep them saved and study them. . Today: You can see all the orders done in the current day. Previous day: You can see all the orders done in earlier days. Month: You can see the accumulated statistics in a month, up to 2 years. Years: You can see the accumulated statistics in a year, up to 3 years.

Print a ticket with the selected statistics using the ticket printer. Reset statistics, NOTE STATISTICS ARE DISABLED by default. Its necessary to "Enable" them if Statistics registration is needed. When exporting data to an external storage device, please do the following: 1- Insert the storage device. Wait for a few seconds to allow the system recognize the device. If the device is coming with an indicator light, please wait this light to stop flashing. 2- Press "Export statistics" and follow the instructions. When exporting on an external device, several xml files will be shown on it with the statistics, along with the activity records. The xml files are „stats-day-yyyymmdd.xml, „stats-months-yyyy.

xml and „stats-year-yyyy.xml, where yyyymmdd is the period. Two copies or periods are saved from the first and second xml types and three copies from the third type. The individual data of each order are shown in the activity files: „statistics.log and „statistics.

log.1. The second is the one that records the oldest data, in the same way as a backup. The operating mode is as follows: When the „statistics.log files occupies about 2.

5MB on the disk, it is renamed „statistics.log.1 (if this file already exists, it is overwritten) and a new „statistics.log is created. 70/84 Operator users manual

4.2.6 Import / export settings Use this option for importing settings from another system or export settings to another one. When exporting data to an external USB storage device, please do the following: 1- Insert the storage device. Wait for a few seconds to allow the system recognize the device. If the device is coming with an indicator light, please wait this light to stop flashing.

2- Press "Export settings" and follow the instructions. NOTE When importing settings from a different easyphoto system, LOCAL ADDITIONAL LICENSES (like PhotoID) AND STATISTICS WILL BE OVERWRITTEN AND LOST. When working as O.T., when pressing the „Export button, the settings are stored in the Click5000 system. They can be imported later in any additional O.T. The importation files may not be compatible among different software versions Network parameters will be only exported when the easyphoto is working in any mode (Kiosk, Operator, O.T.) and an USB device is used to save the data. Network parameters will be only imported when the system is not working as O.T. and an USB pendrive is used to import the data. 71/84 Operator users manual 4.2.

7 Screenshots Its possible to take screenshots of the application and save them into a USB memory device or digital media card. A keyboard attached to the system is needed. Once the "Screenshots" button is pressed, the following screen is showed: For enabling this option: NOTE For saving the screenshots correctly the USB devices and memory cards should be inserted before this function is enabled, and wait for some seconds to allow the operating system to recognize the storage device 1.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>

Press the "Enable" button. 2.

Choose the destination device. Press the "Destination device: USB" button if you want to save the screenshots in the USB. Press "Destination device: MC" button if you want to save the screenshots in the memory card. Now its possible to take screenshots from any screen. Press „F12 in the keyboard every time you need to take a screenshot. Before taking out the storage device: NOTE To extract successfully the storage device where the screenshots are saved, it is highly recommended to access again to the menu "Settings" and disable this function. This action causes the system ejecting the USB storage device properly. 72/84 Operator users manual 5 MT1-ID The MT1-ID is a limited edition of the standard easyphoto with reduced functionalities. The main use of the system is for PhotoID purposes. 5.

1 Available services The MT1-ID offers the following services. · Prints service · CD/DVD burn service · Photo ID service (license is included) As an option: · Decopack: Calendar, Mosaic, Greetings, Collage The Composition service available in the standard easyphoto product is not available in the MT1-ID. 5.2 Working modes The MT1-ID can only work in operator mode. Both Kiosk mode and Order Terminal mode are not supported. 5.3 Printer model Supported printer model is the CPD70DW-U. 73/84 Operator users manual 6 Recovery USB and easyphoto backups Its strongly recommended to make a safe copy of the system after a first setup and also periodically. In the event of a system malfunction, it could be very helpful in recovering normal operation. For that purpose, the equipment includes a DVD, the „Recovery USB creator which is used to generate a recovery tool in a USB drive.

A USB drive with a capacity of 4GB is required, together with a PC with a DVD reader and inputs compatible with USB devices. In some cases, the MT1 equipment can be used if it has an internal or external DVD reader. After executing the process described below, the USB drive will be converted into the system recovery tool and maintenance tool for installing software updates. NOTE All the information in the USB drive will be deleted during the creation of the recovery tool. 6.

1 Creation of the recovery tool in a USB drive To use the USB device as a recovery tool proceed as follows: 1. Switch on the computer (PC) and insert the DVD immediately, so that the system is booted exceptionally from the DVD itself. Do not connect the USB drive yet. 2. Once the boot process has ended, the equipment calibration screen will be displayed.

If the PC is not an MT1 and has a keyboard and mouse, the ESC key can be used to exit the process. If it is an MT1 and the touch screen must be used, press with your finger on each of the green zones that appear in succession until the process has been completed. NOTE If the computer (PC) cannot be booted correctly through the DVD, check that the equipment allows you to boot it from the DVD. Another possibility is that the PC is not compatible with the DVD operating system. Use another PC that can be booted through the DVD. 74/84 Operator users manual 3. The language selection screen will then appear, like the one shown in the illustration. 4. After selecting the language the following screen will appear. Press the button in the centre to create the recovery tool in the USB drive.

5. The next step is a confirmation question. Accept in order to proceed to the next screen where you will be asked to insert the USB device in any available connector. 75/84 Operator users manual 6. Then the USB drive writing process will start. This may last for several minutes. 7. When the process has ended press the button in the bottom right-hand corner of the screen to return the equipment to the initial screen. 8. To switch off the equipment press the off button on the right side of the initial menu.

IMPORTANT: DO NOT REMOVE THE DVD UNTIL THE EQUIPMENT HAS BEEN SWITCHED OFF. If you do this by mistake, ignore the messages that appear on screen and switch the equipment off completely. At any event the process will have been completed correctly. 76/84 Operator users manual 6.2

Using the recovery tool The USB tool created in accordance with the above section can be used to carry out maintenance tasks.

Insert the USB drive, preferably at the rear part of the MT1 equipment, and it will start up. After a few seconds the system will be booted from the USB and the touch screen calibration tool will be displayed. Press the different points that appear at the corners of the screen with your finger to complete this process correctly. Then the main menu of the recovery tool will appear. There is a choice of various options: Software update.

Create partial backup. Create total backup. Restore partial backup. Restore total backup. Shutdown (button located at the bottom on the right) NOTE **IMPORTANT:** After configuring the software for the first time, be sure to create a total backup. The default backup copy supplied with the Recovery USB may be an older release than the content of the MT1 equipment supplied by the factory. It is advisable to make partial backups after making updates to the equipment or at certain time intervals. Two USB drives can be used simultaneously in the equipment, one as a booting and recovery tool and the other as a storage device or as the source of the update data. 77/84 Operator users manual 6.2.

1 Software update This option allows updating the software of easyphoto to a new software version, or installing special update packages. NOTE It is very important to create a backup before updating the process to avoid losing parameters of the configuration, if any backup was not performed before. When this option is chosen, the user is requested to insert an USB memory device, and the system detects if there is an available software update in the memory unit, showing the name of the file and requesting confirmation for the update. Once the update is finished correctly, the system informs about the success of the operation. 6.2.2 Create Partial backup This option allows creating a Partial Backup of the software in the memory device. The partial backup saves everything of the system except the operating system files. Its faster than creating a Total Backup, and the resulting file takes less storage space than the one created after a Total Backup, also. Once the backup is finished correctly, the system informs about the success of the operation.

NOTE To make partial backup copies, it is advisable to use a USB drive that is different from the one used as the recovery device, due to the memory space required for the saved file. It is best to use a USB drive with a free space of 4GB. 6.2.3 Create Total Backup This option allows creating a Total Backup of the software in the memory device.

Its needed a high capacity USB storage device, with a minimum of 4GB free memory. NOTE If using the same USB as the recovery tool, the default backup copy supplied with it will be overwritten.



[You're reading an excerpt. Click here to read official MITSUBISHI EASY02-K60 user guide](http://yourpdfguides.com/dref/4210477)
<http://yourpdfguides.com/dref/4210477>