



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA DTA100. You'll find the answers to all your questions on the MOTOROLA DTA100 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MOTOROLA DTA100
User guide MOTOROLA DTA100
Operating instructions MOTOROLA DTA100
Instructions for use MOTOROLA DTA100
Instruction manual MOTOROLA DTA100



DTA100

Digital Transport Adapter



Quick Start Guide



[You're reading an excerpt. Click here to read official MOTOROLA DTA100 user guide](http://yourpdfguides.com/dref/2347506)

<http://yourpdfguides.com/dref/2347506>

Manual abstract:

Connect the DTA100 to your cable service. Connect the coaxial cable from your wall outlet to the connector on the back of the DTA100 labeled Cable In. Connect the DTA100 to your A/V equipment. Refer to the illustrations in this guide to connect the DTA100 to your TV and other A/V components. Turn on the DTA100. @@ Plug the other end into a non-switched wall outlet. The DTA100 will turn on automatically. (Optional) Connecting the Remote Extender.

@@@ When you place the DTA100 out of view, you must use the Remote Extender for the DTA100 to receive commands from the remote control. Insert the connector of the Remote Extender into the IR IN port and position the opposite end of the Remote Extender in view of the remote control (e.g. attached to the top of the TV). 5. Tune your TV to Channel 3 or 4 Turn on your TV and ensure that it is tuned to either channel 3 or 4. On the back of the DTA100, ensure that the Ch 3/4 switch is set to the same channel as your TV.

Enjoy your new services! 6. 2. Important: If your TV screen is blank or you have no sound, you may have mixed the cable connections. After plugging a cable into the Cable In or To TV connector, be sure to plug the other end of the cable into the corresponding connector on your TV or other A/V component.

Important handling and installation instructions · Install the terminal away from heat sources such as radiators, heat registers, and stoves. The air surrounding the terminal should not exceed 40°C (104 °F). · Do not place the terminal in an enclosed area where the cooling vents are blocked or impede the flow of air through the ventilation openings. · Position the unit with at least 3 inches of space on all sides. · Place the terminal on a flat surface not prone to vibration or impact. @@@@ This information is to help you quickly solve a problem. @@ If it is lit green, the DTA100 is powered on. @@ It is recommended to use an unswitched outlet, if possible. @@@@ Verify that the remote control is in Cable mode. Verify that there are no obstructions between the remote control and the DTA100. Aim the remote control directly at the DTA100 front panel or the Remote Extender, if connected, not the TV or VCR.

The angle between the remote control and the DTA100 may be too large. Stand in front of the DTA100 and not too far to either side. Press and release operation keys one at a time, firmly and deliberately. Check the batteries in the remote control. Install new batteries if needed. Verify that the TV is powered on and set to the appropriate channel (3 or 4) for the DTA100. Verify that the DTA100 is powered on and tuned to an authorized cable channel. Verify that the coaxial cable between the DTA100 and the TV is firmly connected. Verify that the coaxial cable feed is firmly connected to the DTA100 and the wall jack. Verify that the mute button on the remote control has not been pressed.

Press MUTE on the remote control to restore sound. If the DTA100 audio output is connected to the TV, verify that the Mute button on the TV has not been pressed. Verify that closed captions are enabled on the TV. @@@ Patent and Trademark Office. @@ Motorola, Inc.

2008 556788-001-a 11/08 This device is ENERGY STAR® qualified when connected to a digital video service. The Service Provider is responsible for completing the ENERGY STAR Partnership Agreement prior to deploying any Set-top device with an ENERGY STAR label, or claiming to provide ENERGY STAR qualified Set-top devices in advertising or promotional materials. .



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/2347506)

[DTA100 user guide](http://yourpdfguides.com/dref/2347506)

<http://yourpdfguides.com/dref/2347506>