





# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA EQ5. You'll find the answers to all your questions on the MOTOROLA EQ5 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual MOTOROLA EQ5**  
**User guide MOTOROLA EQ5**  
**Operating instructions MOTOROLA EQ5**  
**Instructions for use MOTOROLA EQ5**  
**Instruction manual MOTOROLA EQ5**

	<p><b>welcome</b></p> <p>The MOTOROKR™ EQ5 Ultra-Portable Wireless Speaker is sleek, stylish and pocket-sized. It's the perfect companion to your MP3 player or music phone.</p> <ul style="list-style-type: none"> <li>• <b>Pocket portability</b>—The sleek, slim design fits comfortably in your pocket, so your music and speakerphone calls can go anywhere you go.</li> <li>• <b>Expand your sound</b>—The EQ5 delivers high-definition stereo sound powered by SRS™ WOW HD™ enhanced audio technology.</li> <li>• <b>Don't miss the call</b>—When paired with your phone, the MOTOROKR™ EQ5 doubles as a speakerphone with echo-cancellation and noise-reduction to keep you sounding clear. Switch between music and calls with the touch of a button.</li> <li>• <b>Wireless mobility</b>—Tangled wires are a thing of the past. Bluetooth stereo connectivity cuts the speaker cable, and the rechargeable battery unplugs you from the wall. Integrated music and call controls mean there's no need to reach for your phone, and your music automatically pauses with each call.</li> </ul> <p style="text-align: center;">2</p>
<p><b>Note:</b> Before using your speaker for the first time, be sure to review the important safety and legal pamphlet and follow instructions. Periodically review this information so you remember how to safely use your speaker.</p> <p style="text-align: center;">3</p>	<p style="text-align: center;"><b>before you begin</b></p> <p>Take a moment before you get started to familiarize yourself with the components of your speaker.</p>  <p style="text-align: center;">4</p>



[You're reading an excerpt. Click here to read official MOTOROLA EQ5 user guide](http://yourpdfguides.com/dref/838602)  
<http://yourpdfguides.com/dref/838602>

**Manual abstract:**

It's the perfect companion to your MP3 player or music phone. · Pocket portability--The sleek, slim design fits comfortably in your pocket, so your music and speakerphone calls can go anywhere you go. Expand your sound--The EQ5 delivers high-definition stereo sound powered by SRSTM WOW HDTM enhanced audio technology. Don't miss the call--When paired with your phone, the MOTOROKR™ EQ5 doubles as a speakerphone with echo-cancellation and noise-reduction to keep you sounding clear. Switch between music and calls with the touch of a button. Wireless mobility--Tangled wires are a thing of the past. Bluetooth stereo connectivity cuts the speaker cable, and the rechargeable battery unplugs you from the wall. Integrated music and call controls mean there's no need to reach for your phone, and your music automatically pauses with each call. MOTOROKR™ EQ5 · Quick Start Guide 2 Note: Before using your speaker for the first time, be sure to review the important safety and legal pamphlet and follow instructions. Periodically review this information so you remember how to safely use your speaker.

before you begin Take a moment before you get started to familiarize yourself with the components of your speaker. before you begin Volume Buttons Call Button Main Indicator Light Charging Port and Light (behind flap) Microphone (on side) Audio In Port (on side behind flap) Reverse Button Forward Button Play/Pause Button Power Switch (on bottom) 3 4 charge your speaker You'll need to charge your speaker's battery for a minimum of 1 hour using the included charger. charge your speaker turn it on & off turn it on & off To turn your speaker on and off, slide the Power switch to the ON position. The main indicator light flashes 3 times. Note: You can use the speaker while the battery charges.

1 Plug the charger into the charging port on your speaker, as shown. The Charging indicator light turns red when battery is charging. It may take up to 1 minute for the indicator light to turn on. When the speaker's battery is fully charged, the indicator light turns green. 2 Disconnect the charger. Note: This product uses a lithium ion, rechargeable, non-replaceable battery. Under normal use, expected life of the rechargeable battery is approximately 500 charges. @@@@ Turn on your speaker. @@ Place phone or music player in Bluetooth search mode. The phone or music player searches for your speaker. Notes: · After successfully pairing your speaker and Bluetooth device, you don't need to repeat these steps. For each use, ensure that your speaker is turned ON and that your device's Bluetooth feature is ON. Some music devices will automatically attempt to play music when the EQ5 re-connects to it. · 5 6 7 Select Motorola EQ5 from search results on your phone or music player. Select OK or Yes to pair your speaker with your phone or music player.

If prompted, enter 0000 for passkey. 7 8 control your tunes Playback controls on your speaker can be used when listening to wireless music streaming from a Bluetooth-enabled music player that also provides remote control capabilities (AVRCP). control your tunes crank it up crank it up To adjust music volume, use the Volume buttons on your speaker. Press--play/pause music Press and hold--stop music Press--decrease volume (step) Press and hold--decrease volume (continuous) Press--increase volume (step) Press and hold--increase volume (continuous) Press--skip to previous track Press--skip to next track Press and hold--rewind track\* Press and hold--fast-forward track\* \* If your music player supports this feature When remote control capabilities are not supported by your music player, the EQ5 simply acts as a speaker, and music should be controlled from your music player. 9 You'll hear a tone when maximum or minimum volume is reached on your speaker. Note: The volume setting on your music player may impact volume on your speaker. 10 handsfree calls To make and receive calls using the speaker, a Bluetooth handsfree (HFP) connection must be established with your phone (see "connect wirelessly" on page 7 for details). handsfree calls receive a call receive a call When there's an incoming call, the main indicator light flashes quickly in blue on your speaker, and you hear a ring tone over your speaker. If music is playing when a call is received, the music pauses or mutes, depending on your music player and connection setup. You'll use these controls and indicators on your speaker when making and receiving handsfree calls.

Press--answer call Volume Buttons Call Button Main Reject Microphone Reject Call Mute Indicator Call Light Button Button Button Press and hold (either button)--reject call 11 12 while on a call When a call is active, the main indicator light slowly pulses in blue on your speaker. while on a call while on a call When there's a second incoming call, the main indicator light flashes quickly in blue on your speaker and you hear an alert. Press--adjust call volume (step) Press and hold--adjust call volume (continuous) Press--1) answer second call (first call is placed on hold), 2) end second call (first call resumes), or 3) resume first call on hold (when second caller hangs up) Press--mute call (main indicator light pulses in purple while muted) Press--end call Press and hold (either button)-- reject second incoming call\* \* If your phone supports this feature 13 14 make a call Using the speaker to make a call, you can redial the last dialed number or make a voice dial call (if your phone supports this feature). When making a voice dial call, the microphone on the speaker is enabled, and you hear a prompt from your phone. make a call cable connection cable connection To listen to your music using a wired connection, connect your music player to the Audio port on your speaker using the included audio cable.

Press--make a voice dial call (you hear a prompt from your phone) Press and hold--redial last number Notes: · · The Audio port functions as an input port from a music device only (not as a headphone jack). Playback controls provided on your speaker cannot be used when listening to music input from wired connection. In wired connection, if no audio is heard turn up volume on music device. · 15 16 check your battery To check your speaker's battery charge level, press and hold both Volume buttons. The main indicator light displays charge status until the Volume buttons are released.

check your battery speaker status speaker status The main indicator light on your speaker displays current status of Bluetooth wireless connection(s) to your phone and/or music player. Main Indicator Light Wireless Status pairing mode standby (handsfree connection only) standby (streaming music connection only) standby (both handsfree and streaming music connection) incoming/outgoing call connected on a call connected call muted started/paused music player music streaming (with handsfree connection active) Main Indicator Light Red Yellow Green Battery Charge Status Less than 30% charge Between 30% and 70% charge More than 70% charge steady blue long blue flash long yellow flash long green flash quick blue flash long blue pulse long purple pulse three green flashes long green pulse When your speaker is in a low battery charge state, the main indicator light flashes quickly in red, and a tone is repeated every minute.



[You're reading an excerpt. Click here to read official MOTOROLA EQ5 user guide](http://yourpdfguides.com/dref/838602)

<http://yourpdfguides.com/dref/838602>

17 18 speaker status tips & tricks tips & tricks multi-point (two device) connection To connect to phone and music device at the same time: Main Indicator Light long yellow pulse long purple pulse two yellow flashes three yellow flashes slow red flash Wireless Status music streaming (without handsfree connection active) music from wired connection active SRS WOW HD on/off stopped music player idle (not connected to a device) 1 2 3 4 5 6 7 8 Pair and connect to your phone first (see page 7). Turn off your phone and your speaker. Turn your speaker back on. The Bluetooth indicator flashes to indicate the speaker is in discoverable mode. Turn on your music device. Make sure the Bluetooth feature is turned on in the device. The music device searches for your speaker. Complete steps 5 through 7 on page 7 to pair and connect your music device and speaker successfully.

Turn off your speaker. Turn your phone back on and make sure the Bluetooth feature is turned on in both the phone and music device. Turn your speaker system back on. It should now connect to both devices. 19 20 tips & tricks pairing tips - To initiate pairing (discoverable) mode manually when your speaker is already powered on, press and hold both Call and Play/Pause buttons at the same time. To clear paired devices list in your speaker, press and hold both Reverse and Forward buttons at the same time until speaker resets. tips & tricks disabling SRS WOW HD SRS WOW HD is an audio enhancement technology that provides better width and improved bass and definition control. This feature is enabled on your speaker at purchase. If your music player also has SRS or any other sound enhancement technology, best audio results may be achieved if the audio enhancement feature is enabled on only either the music source or the speaker (but not both).

Always obey the laws and regulations on the use of these products.  
SRS and WOW HD are trademarks of SRS Labs, Inc. © 2008 Motorola, Inc. All rights reserved. Bluetooth QD ID: B013626  
Manual Number: 6809519A01-A MOTOROLA TM EQ5 Guía de inicio rápido 2ca el altavoz.

Si se le solicita, ingrese 0000 como contraseña. Luz Botón Botón de Botón indicadora rechazar silencio Rechazar principal una llamada del micrófono una llamada 11 recibir una llamada Cuando hay una llamada entrante, la luz indicadora principal destella rápidamente en azul en el altavoz, y se escucha un tono de timbre en el altavoz. Si se está escuchando música cuando se recibe una llamada, la música se pone en pausa o se silencia, dependiendo del reproductor de música y de la configuración de conexión. recibir una llamada durante una llamada Cuando una llamada está activa, la luz indicadora principal pulsa lentamente en azul en el altavoz. durante una llamada Oprima: ajustar volumen de llamada (en pasos) Mantenga oprimido: ajustar volumen de llamada (continuamente) Oprima: contestar la llamada Mantenga oprimido (cualquier botón): rechazar una llamada Oprima: silenciar llamada (la luz indicadora principal pulsa en púrpura mientras está silenciada) Oprima: finalizar la llamada 12 13 durante una llamada Cuando hay una segunda llamada entrante, la luz indicadora principal destella rápidamente en azul en el altavoz, y se escucha una alerta.

realizar una llamada Al usar el altavoz para realizar una llamada, se puede remarcar el último número marcado o realizar una llamada de marcado por voz (si el teléfono admite esta función). Cuando se realiza una llamada de marcado por voz, el micrófono del altavoz está activado y se escucha una instrucción del teléfono. realizar una llamada Oprima 1) responder segunda llamada (la primera está se deja en espera), 2) finalizar la segunda llamada (la primera llamada se reanuda) o 3) reanudar la primera llamada en espera (cuando la segunda cuelga). Oprima: realizar una llamada de marcado por voz (se escucha una instrucción del teléfono) Mantenga oprimido: remarcar último número Mantenga oprimido (cualquier botón): rechazar una segunda llamada entrante\* \*\*

Si el teléfono admite esta función. 14 15 conexión de cable Para escuchar música mediante una conexión alámbrica, conecte el reproductor de música al puerto de audio del altavoz mediante el cable de audio incluido. conexión de cable consultar la batería Para revisar el nivel de carga de la batería del altavoz, mantenga oprimidos ambos botones de volumen. La luz indicadora principal muestra el estado de la carga hasta que se sueltan los botones de volumen. consultar la batería Luz indicadora principal Rojo Amarillo Verde Estado de carga de la batería Menos del 30% de la carga Entre 30% y 70% de la carga Más del 70% de la carga Notas: · El puerto de audio funciona como un puerto de entrada sólo desde un dispositivo de música (no como un conector del audífono). Los controles de reproducción del altavoz no se pueden usar cuando se escucha entrada de música desde una conexión alámbrica. En una conexión alámbrica, si no se escucha audio, active el volumen del dispositivo de música.

Cuando el altavoz está en un estado de carga de batería baja, la luz indicadora principal destella rápidamente en rojo y se repite un tono cada minuto. · · 16 17 estado del altavoz La luz indicadora principal del altavoz muestra el estado actual de las conexiones inalámbricas Bluetooth con el teléfono o reproductor de música. estado del altavoz estado del altavoz Luz indicadora principal pulso verde prolongado pulso amarillo prolongado pulso púrpura prolongado dos destellos amarillos tres destellos amarillos destello rojo lento Estado inalámbrico música continua (con conexión manos libre activa) música continua (sin conexión manos libre activa) música de conexión alámbrica activa SRS WOW HD activar/desactivar reproductor de música detenido en reposo (no conectado a un dispositivo) Luz indicadora principal azul constante destello prolongado azul destello amarillo prolongado destello verde prolongado destello azul rápido pulso azul prolongado pulso púrpura prolongado tres destellos verdes Estado inalámbrico modo de asociación en espera (sólo conexión manos libres) en espera (sólo conexión a música continua) en espera (conexiones manos libres y de música continua) llamada entrante o saliente conectado en una llamada llamada conectada silenciada reproductor de música iniciado o pausado 18 19 consejos y trucos consejos y trucos consejos y trucos 7 8 Vuelva a encender el teléfono y asegúrese de que la función Bluetooth esté activada en el teléfono y en el dispositivo de música.



[You're reading an excerpt. Click here to read official MOTOROLA EQ5 user guide](http://yourpdfguides.com/dref/838602)  
<http://yourpdfguides.com/dref/838602>

Vuelva a encender el sistema del altavoz. Ahora debe conectarse a ambos dispositivos. conexión de puntos múltiples (dos dispositivos) Para conectarse a un teléfono y un dispositivo de música al mismo tiempo: 1 2 3 4 Asocie y conecte el teléfono primero (consulte la página 7). Apague el teléfono y el altavoz. Vuelva a encender el altavoz. El indicador Bluetooth destella para indicar que el altavoz está en modo detectable. Encienda el dispositivo de música. Asegúrese de que la función Bluetooth esté activada en el dispositivo. El dispositivo de música busca el altavoz. consejos para la asociación · Para iniciar el modo de asociación (detectable) manualmente cuando el altavoz ya está encendido, mantenga oprimidos los botones Llamada y Reproducir/Pausa al mismo tiempo. Para borrar la lista de dispositivos asociados del altavoz, mantenga oprimidos los botones Retroceder y Avanzar al mismo tiempo hasta que el altavoz se reinicie. · 5 6 20 Realice los pasos 5 a 7 en la página 7 para asociar y conectar el dispositivo de música y el altavoz correctamente. Apague el altavoz. 21 consejos y trucos desactivar SRS WOW HD SRS WOW HD es una tecnología de mejoramiento de audio que ofrece mejor amplitud, bajos y control de definición. Esta función se habilita en el altavoz al momento de la compra. Si el reproductor de música también tiene SRS o cualquier otra tecnología de mejoramiento de audio, se pueden lograr mejores resultados de audio si la función de mejoramiento de audio está habilitada en la fuente de música o en el altavoz (pero no en ambos). Para desactivar la función de mejoramiento de audio SRS WOW HD en el altavoz, mantenga oprimidos los botones Reproducir/Pausa y Rebobinar al mismo tiempo, hasta que escuche un tono y la luz indicadora principal destelle en amarillo dos veces. Para volver a activar la función SRS, realice la misma acción. vocabulario técnico vocabulario técnico Aquí presentamos algunos términos útiles sobre Bluetooth: Perfil Aplicación (o caso de uso) mediante la cual diferentes dispositivos Bluetooth pueden comunicarse entre sí. Ambos dispositivos deben admitir el mismo perfil para entre sí para la aplicación. Perfil para transmitir audio estéreo en canal doble desde un reproductor de música estéreo hasta el altavoz. A2DP (Perfil de distribución de audio avanzado) AVRCP (Perfil de control remoto de audio y video) HFP (Perfil de manos libres) Perfil para controlar la preproducción de audio y video continuo en dispositivos remotos. Se usa generalmente con dispositivos A2DP para las funciones de selección de pistas anteriores o posteriores y de reproducir/pausa. @@@@24 Motorola, Inc. @@Obedezca siempre las leyes y las regulaciones sobre el uso de estos productos. MOTOROLA y el Logotipo de la M Estilizada están registrados en la Oficina de Patentes y Marcas Registradas de los Estados Unidos. Las marcas comerciales Bluetooth pertenecen a sus respectivos dueños y son utilizadas por Motorola, Inc.

bajo licencia. SRS y WOW HD son marcas comerciales de SRS Labs, Inc. Todas los demás nombres de productos y servicios pertenecen a sus respectivos dueños. © 2008 Motorola, Inc. Todos los derechos reservados. ID de Bluetooth QD: B013626 Número de manual: 6809519A01-A 25 .



[You're reading an excerpt. Click here to read official MOTOROLA EQ5 user guide](http://yourpdfguides.com/dref/838602)  
<http://yourpdfguides.com/dref/838602>