




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA MOTO FONE F3. You'll find the answers to all your questions on the MOTOROLA MOTO FONE F3 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MOTOROLA MOTO FONE F3
User guide MOTOROLA MOTO FONE F3
Operating instructions MOTOROLA MOTO FONE F3
Instructions for use MOTOROLA MOTO FONE F3
Instruction manual MOTOROLA MOTO FONE F3



[You're reading an excerpt. Click here to read official MOTOROLA MOTO FONE F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

Manual abstract:

Voice prompt instructions in a language you choose. Intuitive, icon-based menu interface. © Consumer Advocacy Office 1307 East Algonquin Road Schaumburg, IL 60196 www.hellomoto.com Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office.

All other product or service names are the property of their respective owners. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. © Motorola, Inc., 2007.

Caution: Changes or modifications made in the radio phone, not expressly approved by Motorola, will void the user's authority to operate the equipment.

Software Copyright Notice The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual Number: 6809507A54-O 3 contents get started.

.
.
.
. 6 install SIM card & battery

.
. 6 charge battery .
.
.

.
. 6 turn phone on & off . .
.
.

. 7 make a call . .
.
.

.
7 answer a call
.
.

.
7 end a call
.
.

.
. 7 basics . .
.
.

.
.
.
. 8 your phone

.
.
.
. 8 main keys.

.

.....
.....
..... 9 main menu.....

.....
.....
..... 9 action icons...

.....
.....
..... 10 status indicators..

.....
.....
..... 10 lock & unlock keypad.....

.....
.....
..... 11 voicemail.....

.....
.....
... 11 recent calls.....

.....
.....
..... 11 speakerphone.....

.....
.....
..... 12 emergency calls.....

.....
.....
.. 12 customize.....

.....
.....
..... 13 change ringtone.....

.....
.....
... 13 change ringer volume.....

.....
.....
.. 13 change earpiece volume...

..... 13 date, time, & alarms..
.....
.....

... 14 advanced settings.....
.....
.....

..... 15 phonebook .

.....
.....
.....
.....

. 16 call phonebook entry

.....
.....

..... 16 4 add entry

.....
.....
.....

..... 16 delete entry . .

.....
.....
.....

..... 17 speed dial.

.....
.....
.....
.....

.. 17 text messages.

.....
.....
.....

.. 18 send message

.....
.....
.....

. 18 read message

.....
.....
.....

19 reply to message

.....
.....

..... 19 voice prompts ...

.....
.....
.....

..... 20 what are voice prompts? ...

.....
.....
.....

.. 20 use voice prompts ...

.....
.....
.....

.. 20 service & repairs ...

.....
.....

.....
.....
.....
..... 21 SAR Data

.....
.....

.....
.... 22 Safety Information .

.....
.....

.....
24 Industry Canada Notice

.....
.....

.. 29 FCC Notice

.....
.....
.....

.... 29 Warranty

.....
.....
.....

..... 30 Hearing Aids . .

.....
.....
.....

..... 35 WHO Information .

.....
.....
.....

..... 36 Registration

.....
.....
.....

..... 36 Export Law . . .

.....
.....
.....

..... 36 Recycling Information .

.....
.....
.....

.. 37 Perchlorate Label

.....
.....
.....

..... 37 Privacy and Data Security .

.....
.....
.....

.... 38 Driving Safety .

.....
.....
.....

.... 39 5 get started install SIM card & battery get started 1 Remove cover.

2 Insert SIM. 3 Insert battery. 4 Replace cover. charge battery New batteries are not fully charged. Plug the battery charger into your phone and an electrical outlet. Your phone might take several seconds to start charging the battery. The battery indicator in your phone's external display flashes during charging. When charging is complete, the battery indicator stops flashing. 6 get started turn phone on & off Press and hold P for a few seconds, or until the display turns on or off. make a call Enter a phone number and press N.

answer a call When your phone rings and/or vibrates, press N. end a call Press P. 7 basics your phone basics Signal Strength weak strong Battery Strength Action Key Navigation Pad Make & answer calls. Phonebook Headset & Phone Charge Connector Lock & unlock keypad. Turn on & off (press & hold), hang up, exit. 8 basics main keys Action Key Open main menu. Select items in menus & on screen. Phonebook Key Open phonebook or store new phonebook entry when you see V. Navigation Pad Press arrows to move left, right, up, & down. main menu 1 2 Press 1 to open the main menu.

Press c or a to scroll to the option you want: C D B Write Messages Read Messages View Recent Calls List E F G Change Ringtone Set Alarm Adjust Date & Time 3 Press I to select the option. 9 basics action icons When your phone displays these icons, you can: i Q V U Enter numbers. Enter letters. Add phonebook entry. Delete an item.

T R S Select an option. Write a message. Use speakerphone. status indicators W J g O I N Call in progress. Out of network. Keypad locked. Ringtone set to vibrate. Ringtone set to silent. Error. X K L M Call failed. Alarm set. New voicemail message. New text message. P Action successful. 10 basics lock & unlock keypad You can lock your phone's keys to prevent accidental key presses.

To lock/unlock your keypad, press and hold * for two seconds. voicemail Your phone shows L when you have a new voicemail message. If your voicemail number is stored as phonebook entry 1, press and hold 1 to quickly access your voicemail messages.



[You're reading an excerpt. Click here to read official MOTOROLA MOTO F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

recent calls To view recent calls: Find it: I > c > B > I Press h to scroll through the list of calls. 11 basics speakerphone During a call you will see S, which means you can use the speakerphone. To turn the speakerphone on, press I twice. To turn the speakerphone off, press I once. emergency calls To call an emergency number: Press keypad keys to enter the emergency number, then press N to call it. Your service provider programs one or more emergency phone numbers (such as 112 or 911) that you can call under any circumstances, even when your phone is locked. Note: Emergency numbers vary by country.

Your phone's preprogrammed emergency number(s) may not work in all locations. Sometimes an emergency call cannot be placed due to network, environmental, or interference issues. 12 customize change ringtone customize Find it: I > c > E > I 1 2 Scroll to the ringtone you want. Press I to select it. change ringer volume From the home screen (phone is not in an active call), press h.

To set your phone to vibrate, press d until the phone vibrates. change earpiece volume During an active call, press h. 13 customize date, time, & alarms To adjust date and time: Find it: I > c > G > I 1 2 Enter the date and time. Press I. To set an alarm: Find it: I > c > F > I 1 2 Enter the alarm time.

Press I. To turn off an alarm: Find it: I > c > F > I When you see U, press b to select it. 14 customize advanced settings To access advanced phone settings, press ***, enter the number code (see below), then press *I. Phone Setting change language select time format set voicemail number voice prompts ON/OFF keypad tones ON/OFF auto keypad lock ON/OFF set SIM PIN SIM PIN ON/OFF reset to factory settings restricted calling (phonebook only) ON/OFF Number Code 520 470 644 510/511 250/251 260/261 300 310/311 000 160/161 To display detailed phone information, press: **9999*1 15 phonebook call phonebook entry phonebook I 2 3 Press Z to open the phonebook. Press h to scroll to the entry you want to call. Press N to call the entry. add entry I 2 3 4 Enter the number. Press Z to open the phonebook. When you see Q, enter the name of the entry. Press a key more than once to see more letters.

For example, to see the letter N, press 6 twice. Press I to store the entry. Whenever you see V, press Z to add the number to the phonebook. TIP 16 phonebook delete entry I 2 3 4 Press Z to open the phonebook. Press h to scroll to the entry you want to delete. Press c to scroll to U. Press b to delete the entry. speed dial Use speed dial numbers to quickly call someone in your phonebook. Your phonebook automatically assigns a speed dial number to each entry you add to your phonebook. For phonebook entries 1 through 9, press and hold the corresponding key (1 - 9) for two seconds.

For all other phonebook entries: I 2 3 Type the entry number (for example, 15 for entry 15). Press #. Press N to call the number. 17 text messages send message text messages Find it: I > C > I 1 2 3 Enter the message and press I. Enter the number of the recipient, or press Z and select a name from your phonebook Press I.

When entering text, press a key more than once to see more letters. For example, to see the letter N, press 6 twice. To delete a character, press a. To delete the entire message, press and hold O. TIP 18 text messages read message Your phone shows M when you have a new text message.

To open the message: Find it: I > c > D > I To read and scroll through the message, press c. To view a other messages, press h. Note: Text messages are automatically deleted (oldest to newest) when the SIM card is full. reply to message While reading a message: I 2 3 Press I. Enter your response. Press I. 19 ositions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 0.

66 W/kg, and when worn on the body, as described in this user guide, is 1.18 W/kg. (Body-worn measurements differ among SAR Data 22 phone models, depending upon available accessories and regulatory requirements).² While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure. Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines. Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <http://www.phonefacts.net> or the Canadian Wireless Telecommunications Association (CWTA) Web site: <http://www.cwta.ca> 1.

In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements. 2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

23 Safety and General Information This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your mobile device. * Safety Information Exposure to Radio Frequency (RF) Energy Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your Motorola mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy. Operational Precautions For optimal mobile device performance and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions. External Antenna Care If your mobile device has an external antenna, use only a Motorola-supplied or approved replacement antenna. Use of unauthorized antennas, modifications, or attachments could damage the mobile device and/or may result in your device not complying with local regulatory requirements in your country. DO NOT hold the external antenna when the mobile device is IN USE. Holding the external antenna affects call quality and may cause the mobile device to operate at a higher power level than needed. * 24 The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2007. Product Operation When placing or receiving a phone call, hold your mobile device just like you would a landline phone.



[You're reading an excerpt. Click here to read official MOTOROLA MOTO F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

If you wear the mobile device on your body, always place the mobile device in a Motorola-supplied or approved clip, holder, holster, case, or body harness. If you do not use a body-worn accessory supplied or approved by Motorola--or if you hang your mobile device from a lanyard around your neck--keep the mobile device and its antenna at least 2.

5 centimeters (1 inch) from your body when transmitting. When using any data feature of the mobile device, with or without an accessory cable, position the mobile device and its antenna at least 2.5 centimeters (1 inch) from your body. Using accessories not supplied or approved by Motorola may cause your mobile device to exceed RF energy exposure guidelines. For a list of Motorola-supplied or approved accessories, visit our Web site at: www.motorola.com.

RF Energy Interference/Compatibility Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices. Follow **Instructions to Avoid Interference Problems** Turn off your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight. **Implantable Medical Devices** If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this mobile device. **25 Persons with implantable medical devices should observe the following precautions:** · ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON. · DO NOT carry the mobile device in the breast pocket.

· Use the ear opposite the implantable medical device to minimize the potential for interference. · Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place. Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your health care provider. **Driving Precautions** Check the laws and regulations on the use of mobile devices in the area where you drive.

Always obey them. When using your mobile device while driving, please: · Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue use if you can't concentrate on driving. · Use handsfree operation, if available. · Pull off the road and park before making or answering a call if driving conditions so require. · Do not place a mobile device in the airbag deployment area. Responsible driving practices can be found in the "Smart Practices While Driving" section in this user's guide and/or at the Motorola Web site: www.motorola.com/callsmart.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. **26 Operational Warnings** Obey all posted signs when using mobile devices in public areas. **Potentially Explosive Atmospheres** Areas with potentially explosive atmospheres are often but not always posted and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders. When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries. In such areas, sparks can occur and cause an explosion or fire. **Symbol Key** Your battery, charger, or mobile device may contain symbols, defined as follows: **Symbol 032374o** Definition Important safety information follows. Do not dispose of your battery or mobile device in a fire.

@@@Contact your local regulatory authorities for more information. Do not throw your battery or mobile device in the trash. Your mobile device contains an internal lithium ion battery. @@@@If glass breaks, do not touch or attempt to remove. @@@@See 47 CFR Sec.

15.21. This device complies with part 15 of the FCC Rules. @@See 47 CFR Sec. 15.

19(3). @@@@Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help. **Motorola Limited Warranty for the United States and Canada** **Warranty What Does this Warranty Cover?** Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty: **30 Products and Accessories** Products Covered Products and Accessories as defined above, unless otherwise provided for below. **Decorative Accessories and Cases.** Decorative covers, bezels, PhoneWrap™ covers and cases. **Monaural Headsets.** Ear buds and boom headsets that transmit mono sound through a wired connection.

Consumer and Professional Two-Way Radio Accessories. Length of Coverage One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below. Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product. Ninety (90) days from the date of purchase by the first consumer purchaser of the product. Products and Accessories that The balance of the original warranty or are Repaired or Replaced. for ninety (90) days from the date returned to the consumer, whichever is longer. Exclusions Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage. Batteries.

Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.



[You're reading an excerpt. Click here to read official MOTOROLA MOTO F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial 31 purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage. Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage. Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage. Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage. Software Products Covered Length of Coverage Software. Applies only to physical defects in Ninety (90) days from the date the media that embodies the copy of the of purchase. software (e.g. CD-ROM, or floppy disk). Exclusions Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected. 32 Software NOT Embodied in Physical Media.

Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty. Who Is Covered? This warranty extends only to the first consumer purchaser, and is not transferable. What Will Motorola Do? Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service. How to Obtain Warranty Service or Other Information Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729 Canada All Products 1-800-461-4575 TTY 1-888-390-6456 For Accessories and Software, please call the telephone number designated above for the product with which they are used. USA 33 You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center.

To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number. What Other Limitations Are There? ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW. Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of 34 such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted. Hearing Aid Compatibility with Mobile Phones Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs. M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled.



[You're reading an excerpt. Click here to read official MOTOROLA MOTO F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

M4 is the better/higher of the two ratings. T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.) Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find Hearing Aids 35 results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones. Information from the World Health Organization Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using handsfree devices to keep mobile phones away from your head and body. Source: WHO Fact Sheet 193 Further information: <http://www.who.int/peh-emf> WHO Information Product Registration Online Product Registration: direct.motorola.com/hellomoto/Motosupport/source/registration.asp Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage. Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status. Thank you for choosing a Motorola product. Registration Export Law Assurances This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. Export Law 36 For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade. Caring for the Environment by Recycling This symbol on a Motorola product means the product should not be disposed of with household waste. Recycling Information Disposal of your Mobile Device and Accessories Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste.

These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/recycling Disposal of your Mobile Device Packaging and User's Guide Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details. California Perchlorate Label Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. @ @ @ @ @ Lock your device's keypad where this feature is available. @ @ · Erase before recycling--Delete personal information or data from your mobile device prior to disposing of it or turning it in for recycling. For step-by-step instructions on how to delete all personal information from your device, see the section entitled "master clear" or "delete data" in this user's guide.

Note: For information on backing up your mobile device data before erasing it, go to www.motorola.com and then navigate to the "downloads" section of the consumer Web page for "Motorola Backup" or "Motorola Phone Tools." · Understanding AGPS--In order to comply with emergency caller location requirements of the FCC, certain Motorola mobile devices incorporate Assisted Global Positioning System (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user's location--for example, to provide driving directions.

Users who prefer not to permit such tracking and monitoring should avoid using such applications. Privacy and Data Security 38 If you have further questions regarding how use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider. Smart Practices While Driving Drive Safe, Call Smart SM Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them.

The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information. Your mobile device lets you communicate by voice and data--almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips: · Get to know your Motorola mobile device and its features such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road. · When available, use a handsfree device. If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original handsfree accessories available today.

· Position your mobile device within easy reach. Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you. · Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and even heavy traffic can be hazardous. · Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility--driving safely. Driving Safety 39 · Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic. If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue. · Do not engage in stressful or emotional conversations that may be distracting.

Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road. · Use your mobile device to call for help.



[You're reading an excerpt. Click here to read official MOTOROLA MOTO FONE F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>

Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies. · Use your mobile device to help others in emergencies. If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*

** Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.* * 40 Wherever wireless phone service is available. www.motorola.com 6809507A54-O .*



[You're reading an excerpt. Click here to read official MOTOROLA MOTO F3 user guide](http://yourpdfguides.com/dref/563895)
<http://yourpdfguides.com/dref/563895>