



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA T305. You'll find the answers to all your questions on the MOTOROLA T305 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MOTOROLA T305
User guide MOTOROLA T305
Operating instructions MOTOROLA T305
Instructions for use MOTOROLA T305
Instruction manual MOTOROLA T305

 <p>motorola Portable Bluetooth® Hands-Free Speaker</p> <p>MOTOSTART T305 Get connected in 4 quick steps.</p>	<p>BEFORE YOU BEGIN</p> <p><i>Before using this product, read the Important Safety and Legal Information pamphlet and follow its instructions. Take a moment before you get started to familiarize yourself with your new T305 Portable Bluetooth Hands-Free Speaker.</i></p> 
<p>1 CHARGE YOUR HANDS-FREE SPEAKER</p> <p>Charge your hands-free speaker's battery for 2 hours:</p>  <p><i>Note: Do not place hands-free speaker with clip installed on visor when charging.</i></p> <p>1 Plug the Motorola charger into the charging port on the end of the hands-free speaker.</p> <p>The indicator light turns steadily red when the battery is charging and the hands-free speaker is turned off. It may take up to 1 minute for the indicator light to turn on. When the hands-free speaker's battery is fully charged (about 2 hours), the indicator light turns steadily blue.</p> <p>2 Disconnect the charger.</p> <p><i>Note: Hands-free speaker is functional while charging; however, when charging the hands-free speaker while turned on, the indicator light does not provide charging status.</i></p>	<p>2 START BLUETOOTH FEATURE</p> <p>Your Phone</p> <p>Your phone's Bluetooth feature is off by default. To use your hands-free speaker, you must turn on the Bluetooth feature in your phone.</p> <p>For most Motorola phones (at the main menu):</p> <ol style="list-style-type: none"> Press [Menu] > Settings > Connection > Bluetooth Link > Setup. Scroll to Power. Select Change. Scroll to On. Press Select to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn the feature off. <p><i>Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.</i></p>



[You're reading an excerpt. Click here to read official MOTOROLA T305 user guide](http://yourpdfguides.com/dref/301132)
<http://yourpdfguides.com/dref/301132>

Manual abstract:

Take a moment before you get started to familiarize yourself with your new T305 Portable Bluetooth Hands-Free Speaker. Multi-Color Indicator Light and Call Button Volume Up (+) Button (on side) Speaker Volume Down (-) Button Microphone Power Button T305 Get connected in 4 quick steps. 1 CHARGE YOUR HANDS-FREE SPEAKER 2 START BLUETOOTH FEATURE Your Phone Charge your hands-free speaker's battery for 2 hours: Charging Port Note: Do not place hands-free speaker with clip installed on visor when charging. Your phone's Bluetooth feature is off by default. To use your hands-free speaker, you must turn on the Bluetooth feature in your phone. @@@@It may take up to 1 minute for the indicator light to turn on. @@3 Select Change. 4 Scroll to On. 5 Press Select to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn the feature off.

d Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide. 2 Disconnect the charger. Note: Hands-free speaker is functional while charging; however, when charging the hands-free speaker while turned on, the indicator light does not provide charging status. 3 PAIR Your Hands-Free Speaker Motorola, Inc.

Consumer Advocacy Office 1307 East Algonquin Road Schaumburg, IL 60196 www.hellomoto.com 1-877-MOTOBLU 1-888-390-6456 (TTY/TDD United States for hearing impaired) Guide Number: 6809503A47-A Before you can use your hands-free speaker, you must pair (link) it with your phone. Step A - ENSURE HANDS-FREE SPEAKER IS IN PAIRING MODE To initiate easy pairing, power on hands-free speaker by pressing and holding the Power button until the indicator light becomes steadily lit in purple. Release the button and, after a few moments, the indicator light will be steadily lit in blue to indicate hands-free speaker is in pairing mode.

Indicator Light (steadily blue for pairing mode) If the hands-free speaker does not enter pairing mode, see TROUBLESHOOTING for help. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product or service names are the property of their respective owners. © Motorola, Inc. @@@@My phone does not find my hands-free speaker. @@@@Support.

@@Then, release the button. Note: Hands-free speaker may take up to 3 to 4 seconds to turn on. To turn your hands-free speaker off, press and hold the Power button until the indicator light turns purple and then turns off. IMPORTANT: Be sure to first follow the Quick Start Guide on the reverse side of this guide to complete initial setup of your T305. To conserve battery power, your hands-free speaker will turn off when not connected to your phone for more than 30 minutes. Power Button Indicator Light INSTALLING HANDS-FREE SPEAKER IN YOUR CAR Follow these steps to install your hands-free speaker in your car: INSTALLING HANDS-FREE SPEAKER IN YOUR CAR Continued 2 Slide the visor clip onto your sun visor. 1 Slide the visor clip onto the mounting bracket on the bottom of the hands-free speaker. To do this, place the loop end first onto the hands-free speaker and slide forward as shown below. When installed, the Power button must be facing toward you as shown. The visor clip is reversible to allow placement of your hands-free speaker on either the front or the back of your car's sun visor.

ADJUSTING HANDS-FREE SPEAKER VOLUME You can adjust hands-free speaker volume using the Volume buttons. To adjust volume, tap or press and hold button. European Union Directives Conformance Statement Hereby, Motorola declares that this product is in compliance with: · The essential requirements and other relevant provisions of Directive 1999/5/EC. · All other relevant EU Directives. Volume Up (+) Button Volume Down (-) Button 0168 Product Approval Number The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site. Note: Hands-free speaker volume cannot be adjusted during an incoming call.

MAKING CALLS Function Make a voice dial call Action Tap the Call button and speak the name after the tone Tap the Call button (if a call is on hold, tap twice to end all calls) Tap the Call button Tap either Volume button Press and hold the Call button until you hear a beep MAKING CALLS CONTINUED Function Answer a second incoming call Toggle between two active calls Mute or unmute a call Action Press and hold the Call button (places first call on hold) Press and hold the Call button Tap both Volume buttons End a call Receive a call Reject a call Redial last call Note: Some features are phone/network dependent. @@@@Audio Tone Single high tone when pressing Volume button Five rapid high tones repeated every 60 sec. No audio indications; deteriorating quality Ring tone Single high tone Single low tone Dual high/low tone (phone dependent) Single high tone Low to high tone Two ascending tones Two descending tones Status Volume at minimum or maximum Low battery Out of range Incoming call Pairing confirmation Voice activation Voice tag not recognized End call Phone network not available Mute enabled Mute disabled Steady red Steady blue Charging Charging complete With No Charger Plugged In Indicator Light Off Steady purple Steady blue Quick red flash Blue with quick purple flashes Slow blue pulse Blue flash Quick blue flash Slow purple pulse Status Power off Powering up Pairing mode Battery low Pairing successful Connected (on a call) Standby (not on call) Incoming call Muted .



[You're reading an excerpt. Click here to read official MOTOROLA](http://yourpdfguides.com/dref/301132)

[T305 user guide](http://yourpdfguides.com/dref/301132)

<http://yourpdfguides.com/dref/301132>