



*Manual abstract:*

@@(The Nikon F2 and F models are not equipped with eyepieces. @@ remove the eyepiece and attach the DR-6 to the camera by sliding it down from the top of the camera's viewfinder. (Certain cameras are not equipped with eyepieces. @@@@When reproduction ratio of the Right-Angle Viewing Attachment is set to 1:2, finder view may appear unclear. in this case , adjust the diopter on the attached camera. @@@@ do not use the wrench to attach the adapter ring to the camera. @@It may fall from the camera's viewfinder. .



[You're reading an excerpt. Click here to read official NIKON DR-5 user guide](#)

<http://yourpdfguides.com/dref/3691946>