



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NILFISK GWD 320. You'll find the answers to all your questions on the NILFISK GWD 320 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NILFISK GWD 320
User guide NILFISK GWD 320
Operating instructions NILFISK GWD 320
Instructions for use NILFISK GWD 320
Instruction manual NILFISK GWD 320

**GD 320 GWD 320 GWD 335
GWD 350 GWD 375**



INSTRUCTION FOR USE
BETRIEBSANLEITUNG
INSTRUCTIONS D'UTILISATION
INSTRUCCIONES DE MANEJO
INSTRUÇÕES DE OPERAÇÃO
ISTRUZIONI SULL'USO
GEBRUIKSAANWIJZING
BRUKSÄNVIJNING
DRIFTSINSTRUKS
DRIFTSVEJLEDNING
KÄYTTÖOHJE



CE
823 0062 000
P01

Printed in Hungary

Nilfisk
setting standards



[You're reading an excerpt. Click here to read official NILFISK GWD 320 user guide](http://yourpdfguides.com/dref/2885017)
<http://yourpdfguides.com/dref/2885017>

Manual abstract:

De hulpstukken op de afbeeldingen kunnen van model tot model variëren. To reduce the risk of fire, electric shock, or injury, please read and follow all safety instructions and caution markings before use. This vacuum cleaner is designed to be safe when used for cleaning functions as specified. Should damage occur to electrical or mechanical parts, the cleaner and / or accessory should be repaired by a competent service station or the manufacturer before use in order to avoid further damage to the machine or physical injury to the user. Do not leave the machine when it is plugged in. Unplug from the socket when not in use and before maintenance · Do not use with damaged cord or plug. to unplug grasp the plug , not the cord. Do not handle plug or cleaner with wet hands. Turn off all controls before unplugging. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. do not run cleaner over cord. Keep cord away from heated surfaces. @@Do not put any objects into openings or use with opening blocked. @@@@ Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be pre sent. @@@@ Children must be supervised not to play with the appliance.

Use extra care when cleaning on stairs. Do not use unless filters are fitted. @@@@This appliance is provided with double insulation. In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a mean for grounding be added to the appliance.

Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel.

Replacement parts for a doubleinsulated appliance must be identical to the parts they replace. A double insulated appliance is marked with the words "DOUBLE INSULATION" or "DOUBLE INSULATED. " The symbol (square within a square) may also be used on the product. iMPORTANT! The machine is equipped with a specially designed cord which if damaged, must be replaced by a cord of the same type. This is available at authorised service centres and dealers and must be installed by trained personnel. nB! Remove the plug from the socket before performing maintenance. @@@@The accessories shown in the pictures may vary from model to model. @@@@Dry cleaner shall always have the sack filter mounted in the machine. Wet cleaner (not the GD 320) shall always have the the Sack Filter and the Float System mounted in the machine during both WET AND DRY operations.

Please also notice that the fill factor at the container may vary when using a sack filter during wet pick-up operations. Always empty and clean the container and the float system after picking-up liquids. Never pick up liquid without the float system and sackfilter installed in the machine. Then pull out the hose. 2c) Empty by tilting the container backwards and pour the liquids into a floor drain or similar. Wipe the float valve and float basket with a damp cloth before the motor top is reinstalled to the container. The machine is equipped with a float system that shuts off the airflow through the machine when the maximum liquid level is reached. Never pick up liquid without the float body in place. To control: Loosen the two latches at each side of the motor top . @@Then tighten both latches so that the motor top is properly secured.

Always use a chemical defoamer when picking up water containing foaming detergents. @@@@The natural pressure will then drain the liquids from the container. @@The suction hose can be attached during emptying from the container. Grasp with one hand at the handle at the lower part of the container. @@@@ attach suitable nozzle to the tube.

@@Connect the plug into a proper electrical outlet. @@@@The handle can be adjusted to the suitable working heigth. Start by loosing the two locking screws at each side of the handle. @@@@See item number 2 for emptying after wet pick-up. Remove the plug from the socket before emptying after dry pickup.

check the filters and dustbag regularly. @@ lift up the motor top from container. @@Wait until it is dry before you reuse it. Shake filter so that all dust is removed from the filter. @@@@After emptying: Put back the motor top to the container. @@ secure with the latches. @@The suction efficiency of the vacuum cleaner depends on the size and quality of the filter and dust bag. Therefore - use only Original filter and dust bags. Remove the plug from the socket before performing maintenance. Always empty and clean the container and the float system after picking-up liquids.

Turn the motor top to upside down position. 4b)Then loosen the float basket by turning the basket to the left. Remove the complete float system from motor top. 4d) Wipe the float valve and float basket with a damp cloth before the motor top is reinstalled to the container. then reinstall the float valve to the float basket. Make sure that the sealed surface of the float valve is installed upwards in direction towards the motor top. @@Then secure the float basket by turning it to the right. @@@@The machine will be shut off when the switch is placed in position 0. @@@@Remove the plug from the socket when machine is not in use. wind up the cord starting from the machine.

The power cord can be wound up around the handle/hooks located on the motor top. Some variants have special storage places for accessories. THIS VACUUM CLEANER is designed, developed and rigorously tested to function efficiently and safely when properly maintained and used in accordance with the following instructions. These instructions have been prepared with safety and efficiency paramount. THE MACHINE OPERATOR must be trained by a suitably qualified instructor and must understand these instructions for use, and be made aware of any relevant regulations and legislation in force at the time of use.

CAUTION - This machine is not suitable for use in explosive or inflammable atmospheres or where such atmospheres are likely to be produced by the presence of volatile liquid or inflammable gas or vapour. CAUTION - In no circumstances should the power supply cord be wrapped around fingers or any part of the operators person. CAUTION - The electrical supply plug must not be subjected to undue stress by pulling on the power supply cord. Your MACHINE must only be connected to an electrical supply of the same voltage and frequency as indicated on the rating plate.

@@@@Machine are fitted with a 13 amp.

Only fuses that are ASTA approved to BS 1362 should be fitted. Never use the plug without the fuse cover fitted. @@If the available socket outlet is not suitable for the plug supplied, the plug must be cut off and an appropriate plug fitted. The plug thus cut off MUST BE DESTROYED for safety reasons before being disposed of. Machines built for other voltages and frequencies are not normally supplied with a fitted plug. If it is necessary to fit a plug, the wires in this power supply cord are coloured in accordance with the following code: If using a three-pin plug, do not make any connection to the the terminal in the plug which is marked with the letter 'E' or by the safety earth symbol or coloured green or green & yellow.



[You're reading an excerpt. Click here to read official NILFISK GWD](#)

[320 user guide](#)

<http://yourpdfguides.com/dref/2885017>