



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NILFISK SO4500. You'll find the answers to all your questions on the NILFISK SO4500 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NILFISK SO4500
User guide NILFISK SO4500
Operating instructions NILFISK SO4500
Instructions for use NILFISK SO4500
Instruction manual NILFISK SO4500

SO 4500

User Manual



CE

Nilfisk
setting standards



[You're reading an excerpt. Click here to read official NILFISK SO4500 user guide](http://yourpdfguides.com/dref/4308977)
<http://yourpdfguides.com/dref/4308977>

Manual abstract:

.....
.....
.....
.....

....3 Included Attachments.

.....
.....

.....
.....
.....
.....

.....
.....

....4 Congratulations.

.....

.....
.....
.....
.....

.....
.....
.....
.....

....5 Getting the best results.....

.....
.....
.....

.....
.....
.....
.....

.....5 Assembly...

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..6 Warnings.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....6 Operating Procedure...

.....
.....
.....
.....
.....
.....
.....
.....

...6 & 7 During Use.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....8 Do's & Don'ts....

.....
.....
.....
.....
.....
.....
.....
.....

...8 Daily.

.....
.....
.....
.....
.....
.....
.....
.....

...9 Weekly....

.....
.....
.....
.....
.....
.....

.....
.....

.....
.....
.....
.....9 Guarantee.

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....10 Technical Data...

.....
.....

.....
.....
.....
.....

.....
.....

.....11 Symptom, possible cause & action.....

.....
.....
.....
.....

.....12 Installation Operation Maintenance Service Technical Troubleshooting Modified January 2010 3 English Components 1. Cold Water Tank 2. Steam Control 3. Steam Hose Socket 4. Caster with Brake 5. Caster No Brake 6. Serial Number Diagram A Diagram B 7. On/Off Switch 8. Heater On LED 9. Steam Ready LED 10. Cold Water Refill LED 11. Temperature Display LED 4 English Attachments These Parts were carefully packed at Nilfisk.
Please check all accessories on receipt. @4 Metre Steam Only Hose 3. Floor Brush 5. Large Brush Elbow 7. Large Nozzle 9. Detail Brush Nozzle 11. Detail Brass Brush x 5 2. Extension Tube x 2 4. Triangular Brush 6. Window Squeegee 8.

Curved Nozzle 10. Detail Nylon Brush x 5 12. 55mm Round Brush Diagram C 1. 5. 9. 6. 2. 10. 3. 7.
11. 4. 8. @@@@Please read this instruction manual carefully before you start using or carrying out any maintenance on the machine. If you use this machine correctly as stated in this instruction manual this machine will fulfil all your steam cleaning needs.
This machine is intended for use in a commercial cleaning environment. If you do not follow the instructions contained in this manual, situations may arise which may be dangerous or harmful to the machine or the person operating the machine. Read this manual carefully so that you know when such situations can arise. @@@@This machine has been designed with your safety in mind, however it is important that you observe the following points for safe operation during the operating procedure This is an electrical product Do not use in wet weather or allow the machine to get wet. Do not discharge steam towards people, danger of scolding.

Or towards equipment containing electrical components Never allow children to play with this appliance. Do not use the machine for other purposes that it was built for. Please remember that the steam cleaner operates at temperatures in excess of 170°C. Never use it on objects, which cannot resist the temperature (delicate materials, fabrics, plastics, wood etc). Where any doubt exists check carefully on a part of the material where minor marks will not matter. @@1. @@!! @@2. @@!! Grease "O" rings on steam pin before connecting. !! @@3. Plug the power cable into a 240 Volt supply.

!! Inspect the electric cable before every use. @@!! @@The machine is not in use ii. Cleaning the machine iii. Any maintenance work is being carried out 8. Switch the On/Off switch (Number 7 Diagram B) to the ON position. The Heater On light LED (Number 8 Diagram B) will illuminate. 9. Allow approximately 5 minutes for the boiler to heat the water 10. @@11. The handle controls are now active.

@@@Hold the switch as long as you need to dispense the detergent. Releasing the switch will stop the detergent supply. 12. @@@Cold Water Tank Empty(Number 1 Diagram A) 1. @@@@2.

The pumps will not work when the cold-water tank is empty. 3. Once the cold water refill LED is illuminated the boiler heater will remain on for 30 minutes. If the cold-water tank is not refilled within 30 minutes and the machine is left powered on the boiler heater will switch off. Safety Precautions .

.....

.....
.....
.....
.....
.....
.....

. This machine is to be used by trained operatives only DO DONT . Use the machine near people, children or animals . Point steam at electrical apparatus . Use the machine to clean the machine down . Do not use on Velvet, satin or leather . Leave the machine unattended Check the cable and plug are safe and intact before plugging the machine in. @@To be carried out every day or every 8 hours of operation. 1. Grease "O" rings on the steam pin in the steam hose.

2. Wipe down the body of the machine with a clean damp cloth 3. @@@@To be carried out every week or every 50 hours of operation. As for daily maintenance plus the following: 1. Inspect the power cable for any signs of damage. If damaged do not repair, contact the supplier of this product. Do not use until repaired. 2. Inspect the hose assembly for any signs of damage. If damaged do not repair, contact the supplier of this product.

Do not use until repaired. 3. @@@@Nilfisk guarantees that if within 12 months from the date of purchase this appliance, or any parts thereof, is proved to be defective by reason of faulty workmanship or materials, we will at our option repair or replace the same free of charge for labour and materials, provided that: . The appliance has been installed and used in accordance with our operating and servicing instructions. . If the appliance has been serviced, maintained, repaired, modified taken apart or tampered with by any person not authorised by us, then we will not be liable under this guarantee for any fault arising from their defective workmanship. . We shall not be liable under this guarantee for any fault in the appliance arising from the use of spare parts not supplied and recommended by us. @@@@The steam handle will work again. Call for service Wait for the "Ready to steam " light to illuminate Hold the steam switch on for approximately one minute, ever if just water is coming out. @@@@Change and re grease "O" Rings. @@Call for service On / Off switch not on Fuse blown Unknown Steam Control turned down fully clockwise Steamer not ready Clean water tank is low (beeping sound& "refill" light is lit) Unknown Steamer not ready Boiler at pressure and not heating(temperature less than 110°C) Unknown "O" Rings split No steam No steam, Just water Steam Leaking from front socket "O" rings worn Unknown 13 English 14 English 15 .



[You're reading an excerpt. Click here to read official NILFISK](http://yourpdfguides.com/dref/4308977)

[SO4500 user guide](http://yourpdfguides.com/dref/4308977)

<http://yourpdfguides.com/dref/4308977>