



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NOKIA 100. You'll find the answers to all your questions on the NOKIA 100 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NOKIA 100
User guide NOKIA 100
Operating instructions NOKIA 100
Instructions for use NOKIA 100
Instruction manual NOKIA 100

Nokia 100 User Guide

Issue 1.0EN



[You're reading an excerpt. Click here to read official NOKIA 100 user guide](http://yourpdfguides.com/dref/4211675)

<http://yourpdfguides.com/dref/4211675>

Manual abstract:

0EN Keys and parts 1 ct Sele 2 k Bac 8 3 7 6 5 5 6 7 8 4 1 2 3 4 Earpiece Screen End/Power key Keypad Microphone Scroll key Call key Selection keys 12 9 10 11 9 10 11 12 Charger connector Flashlight Loudspeaker Headset connector Insert the SIM card and battery 1 Slide the back cover down. 4 Line up the battery contacts. 2 Slide the SIM card under the metal part. 5 Push the battery in. 3 Make sure the plastic tab holds the SIM card in place. 6 Slide the back cover up. Charge the battery Switch on 2 seconds 1 Connect the charger to a wall outlet. 1 Press and hold the power key . 09:00 OK Back 2 Connect the charger to the phone. 2 To set the hour, press up or down.

You can also press the number keys. 15:00 OK Back 3 The phone indicates a full charge. You can use the phone while charging. 3 To set the minutes, press right, and then press up or down. Press OK.

Lock or unlock keypad Time is set Menu Go to 4 The time is changed. To avoid accidental pressing of keys, use the keypad lock. Date: 08.04.2011 OK Exit 5 To set the date, press up or down.

Press OK. 1 Press Menu, and then quickly press *. Keypad locked 6 The phone is ready to use. Menu Go to 2 The keypad locks. To unlock the keypad, repeat step 1. Explore your phone Menu Go to Select Back 1 To see the available functions, press Menu. 4 To select an item, press Select. Select Exit Select Back 2 To go to a function, press the scroll key up, down, left, or right. 5 To return to the previous view, press Back. Select Exit Select Exit 3 To select the function, press Select.

6 To return to the home screen, press . Make or answer a call 9876543210 calling Silence 3 Make a call to a number that you have. 012345 Clear A friend's phone rings. To answer, . press Options 1 Enter the phone number. Calling 0123456789 4 You can enjoy chatting with your . friend. To end the call, press End call 2 Press . Change the volume Use the loudspeaker Is the volume too loud during a call or when listening to the radio? Volume Others in the room can join in with a call. 0123456789 00:00:05 Options Loudsp.

1 Press left for quieter, right for louder. 1 During a call, press Loudsp.. 2 Better. 2 Place the phone on a table.

Use the headset Switch off You can make a hands-free call with a headset. To save battery power, switch the phone off. Switch off 2 seconds 1 0123456789 calling 1 Press and hold the power key . Connect a headset. Calling 0123456789 End call 2 Make a call.

2 The phone switches off. Save a name and number Contact name: Mi OK Clear 3 Add a friend's number to your phone. Write the name. Contact name: Mike Menu Go to Select Exit OK Clear 1 Press Menu. @@@@ Select Settings. Tone settings Display settings Profiles Select Back 16 Write the name, and press OK. The phonebook name is changed. Mum Dad 12345678 2 Select Tone settings. Ringing tone Ringing volume Select Nokia tune 87654321 Mike 0123456789 Details Back Level 4 Back 17 To see the phonebook quickly, press , and then press down. 3 Select Ringing tone.

Flashlight Airy Beach Bold Brook Coconut Desk phone OK Back 4 To listen to the sound of a ringtone, go to the ringtone. Airy Beach Bold Brook Coconut Desk phone OK Use the flashlight if you need more light. See iii) in General Information. Back x2 1 Menu Go to 5 Press OK. Done To use the flashlight, press up twice. x1 6 The ringtone is selected. 2 Menu Go to To switch the flashlight off, press up once. Send and receive messages Hello Anna, how are you today?

Menu Go to Select Exit Options Clear 1 Press Menu. Select Messages. Create message Inbox Sent items Select Back 4 Press Options, and select Send.

See i) in General Information. Phone number: OK 0123456789 Clear 2 Select Create message. Hello Anna, 5 Enter a phone number. Press OK. Options Clear 3 To write your message, press the keys.

6 The message is sent. Write text Press a key repeatedly until the letter is shown. Change the writing language: select Menu > Settings > Phone settings > Language, the language, and OK. See iv) in General Information. Insert a space: press 0.

Change a word: press * repeatedly until the word is shown. Insert a number: press and hold the number key. Insert a special character: press and hold *.

Change the text input method: press # repeatedly. Use predictive text: select Options > Dictionary and the language. Press a key for each letter. When the word is shown, press 0. Start writing the next word. Stop using predictive text: select Options > Dictionary > Dictionary off. 1 message received Show Exit 7 To read a message, press Show.

Hello Anna, how are you today? Options Back 8 To view the rest of the message, press down. Set an alarm 08:00 OK Back 3 Use your phone as an alarm clock to wake you up. To set the hour, press up or down. Menu Go to Select Exit 08:30 OK Back 1 Press Menu. Select Clock. Alarm time Alarm tone 4 To set the minutes, press right and then up or down. Off Repeat alarm Select Speaking clock Alarm once 08:30 OK Back Back 2 Select Alarm time. 5 Press OK. Set a reminder Alarm on Meeting 6 The alarm is ready. Postp.

Quit Set a reminder to meet your friends. Alarm! 08:30 Menu Go to Select Exit Stop Snooze 7 An alarm sounds at the set time. Press Stop. 1 Press Menu. Select Extras.

Spreadsheet Countd. tim. Calendar Select Back Off 2 Select Calendar. Feb 2011 Week 5 MTWTF S S 31 7 14 21 28 1 8 15 22 1 2 9 16 23 2 3 10 17 24 3 4 11 18 25 4 5 12 19 26 5 6 13 20 27 6 Alarm on Alarm off Options Back OK Back 3 Go to the date, and press Options. Add reminder Go to date 6 To set an alarm, select Alarm on.

20:30 OK Back OK Back 4 Select Add reminder. 7 To set the hour and minutes, press up or down. Reminder added Reminder about: Meeting OK Clear 5 Write a name for the reminder. 8 Press OK. The alarm is ready. Listen to the radio Search all available channels? OK Back 3 Use your phone to listen to the radio. See ii) in General Information. To automatically find radio channels, press OK. 87.5 87.

50 MHz; 108 Options Back 1 Connect a headset. The headset cable works as the radio antenna. 4 To select the next channel, press down. Switch off Manual tuning Save channel Auto tuning Set frequency Delete channel Select Back Menu Go to Select Exit 2 Press Menu. Select Radio. The radio is on. 5 To save the channel, press Options, and select Save channel. Channel name: Station 1 OK Clear Switch off Save channel Auto tuning Set frequency Delete channel Rename Select Back Radio off 6 Write a name for the channel, and press OK.



[You're reading an excerpt. Click here to read official NOKIA 100 user guide](http://yourpdfguides.com/dref/4211675)

<http://yourpdfguides.com/dref/4211675>

1. (empty) 2.

(empty) 3. (empty) 4. (empty) 5. (empty) 6. (empty) Select 9 To close the radio, press Options, and select Switch off.

Back Stop Alarm! 08:30 Snooze 7 Select an empty channel. To save more channels, repeat steps 57. Save channel Auto tuning Set frequency Delete channel Rename Loudspeaker Select Back Tip: Wake up to the radio. Press Options, and select Clock radio. 8 To use the loudspeaker, press Options, and select Loudspeaker.

Calculator Equals 50 Clear 3 Use your phone to make a calculation. To enter numbers, press the keys. x Menu Go to Select Exit 50 Clear Equals 1 Press Menu. Select Extras. 4 To change a function, use the scroll key. Calculator Converter Spreadsheet Select Back x Equals 50 120 Clear x Equals = 50 120 6000 Clear 2 Select Calculator. 5 Enter the second number, and press Equals. General information Read these simple guidelines. Not following them may be dangerous or illegal. For further information, read the complete user guide.

SWITCH OFF IN RESTRICTED AREAS Switch the device off when mobile phone use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas. **ROAD SAFETY COMES FIRST** Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety. **INTERFERENCE** All wireless devices may be susceptible to interference, which could affect performance. **QUALIFIED SERVICE** Only qualified personnel may install or repair this product. **KEEP YOUR DEVICE DRY** Your device is not waterresistant. Keep it dry. **PROTECT YOUR HEARING** Listen to a headset at a moderate level, and do not hold the device near your ear when the loudspeaker is in use.

Battery removing Switch the device off and disconnect the charger before removing the battery. Product and safety information Feature specific instructions **Important: Do not use a mini-UICC SIM card, also known as a micro-SIM card, a microSIM card with an adapter, or a SIM card that has a mini-UICC cutout (see figure) in this device. A micro SIM card is smaller than the standard SIM card. This device does not support the use of micro-SIM cards and use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card. Your device may have internal and external antennas. Avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with antennas affects the communication quality and may cause a higher power level during operation and may reduce the battery life. i) You can send text messages that are longer than the character limit for a single message. Longer messages are sent as two or more messages. Your service provider may charge accordingly.**

@@@The headset acts as an antenna. iii) Do not shine the flashlight in anyone's eyes. @@For availability, contact your service provider. Send messages only to devices that support the selected language. @@To use the device, you need a subscription with a service provider. @@Some product features require support from the network, and you may need to subscribe to them. Take care of your device Handleproved batteries or incompatible chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. @@Never use a damaged battery or charger. Only use the charger indoors. @@Ensure the device is switched on.

2. Check for adequate signal strength. You may also need to do the following: · Insert a SIM card. @@ · Ensure your device is not in an offline or flight profile. 3. To clear the display, press the end key as many times as needed. 4. Enter the official emergency number for your present location. Emergency call numbers vary by location. 5.

Press the call key. 6. Give the necessary information as accurately as possible. @@@@Connections in all conditions cannot be guaranteed. @@Small children Your device and its accessories are not toys.

They may contain small parts. Keep them out of the reach of small children. @@@@Do not use the headset where it can endanger your safety. Some wireless devices may interfere with some hearing aids. @@@@To send data files or messages requires a quality connection to the network.

Data files or messages may be delayed until such a connection is available. Follow the separation distance instructions until the transmission is completed.

Vehicles Radio signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection, electronic antilock braking, electronic speed control, and air bag systems. For more information, check with the manufacturer of your vehicle or its equipment. Only qualified personnel should install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories. Remember that air bags inflate with great force. Do not place your device or accessories in the air bag deployment area.

Potentially explosive environments Switch off your device in any area with a potentially explosive atmosphere, for example near gas pumps at service stations. Sparks in such areas could cause an explosion or fire resulting in bodily injury or death. Observe restrictions in fuel service stations, storage, and distribution areas; chemical plants; or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include areas where you would be advised to turn off your vehicle engine, below deck on boats, chemical transfer or storage facilities and where the air contains chemicals or particles such as grain, dust, or metal powders. You should check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) to determine if this device can be safely used in their vicinity. Certification information (SAR) This mobile device meets guidelines for exposure to radio waves. Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organisation ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The exposure guidelines for mobile devices employ a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit stated in the ICNIRP guidelines is 2.0 watts/ kilogram (W/kg) averaged over 10 grams of tissue. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands.



[You're reading an excerpt. Click here to read official NOKIA 100 user guide](http://yourpdfguides.com/dref/4211675)

<http://yourpdfguides.com/dref/4211675>

The actual SAR level of an operating device can be below the maximum value because the device is designed to use only the power required to reach the network.

That amount changes depending on a number of factors such as how close you are to a network base station. The highest SAR value under the ICNIRP guidelines for use of the device at the ear is 1.28 W/kg. Use of device accessories may result in different SAR values. SAR values may vary depending on national reporting and testing requirements and the network band.

*Additional SAR information may be provided under product information at www.nokia.com. **DECLARATION OF CONFORMITY 0434** Hereby, NOKIA CORPORATION declares that this RH-130 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at www.nokia.com/phones/declaration_of_conformity/. © 2011 Nokia. All rights reserved. Nokia and Nokia Connecting People are trademarks or registered trademarks of Nokia Corporation.*

Nokia tune is a sound mark of Nokia Corporation. @@@@Nokia operates a policy of continuous development. @@@@The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice. The availability of products, features, applications and services may vary by region. For more information, contact your Nokia dealer or your service provider. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited. .



[You're reading an excerpt. Click here to read official NOKIA 100 user guide](http://yourpdfguides.com/dref/4211675)

<http://yourpdfguides.com/dref/4211675>