



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NOKIA 220. You'll find the answers to all your questions on the NOKIA 220 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual NOKIA 220**  
**User guide NOKIA 220**  
**Operating instructions NOKIA 220**  
**Instructions for use NOKIA 220**  
**Instruction manual NOKIA 220**

**User Guide**  
Nokia 220  
RM-970

**NOKIA**

Issue 1.0 (2011)

RM-970



[You're reading an excerpt. Click here to read official NOKIA 220 user guide](http://yourpdfguides.com/dref/5575440)

<http://yourpdfguides.com/dref/5575440>

### Manual abstract:

@@Obey all instructions in restricted areas. ROAD SAFETY COMES FIRST Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety. @@QUALIFIED SERVICE Only qualified personnel may install or repair this product. BATTERIES, CHARGERS, AND OTHER ACCESSORIES Use only batteries, chargers, and other accessories approved by Nokia for use with this device. Do not connect incompatible products. KEEP YOUR DEVICE DRY Your device is not water-resistant. Keep it dry. PROTECT YOUR HEARING To prevent possible hearing damage, do not listen at high volume levels for long periods.

Exercise caution when holding your device near your ear while the loudspeaker is in use. © 2014 Nokia. All rights reserved. 3 Get started Get to grips with the basics, and have your phone up and running in no time. Keys and parts Explore the keys and parts of your new phone.

1 Charger connector 2 Flashlight 3 Headset connector (3.5 mm) 4 Screen 5 Scroll key 6 End/Power key 7 Microphone 8 Keypad 9 Call key 10 Selection keys 11 Earpiece 12 Camera lens. Before using the camera, remove the protective tape from the lens. 13 Antenna area Avoid touching the antenna area while the antenna is in use. Contact with antennas affects the communication quality and may reduce battery life due to higher power level during operation.

Do not connect products that create an output signal, as this may damage the device. Do not connect any voltage source to the audio connector. If you connect an external device or headset, other than those approved for use with this device, to the audio connector, pay special attention to volume levels. Some of the accessories mentioned in this user guide may be sold separately. Insert SIM, battery, and memory card Learn how to insert the battery and SIM and memory cards. Important: This device is designed to be used with a standard SIM card (see figure) only. Use of incompatible SIM cards may damage the card or the device, and may corrupt data stored on the card. Please consult your mobile operator for the use of a SIM card that has a mini-UICC cutout. Use only compatible memory cards approved for use with this device. Incompatible cards may damage the card and the device and corrupt data stored on the card.

© 2014 Nokia. All rights reserved. 4 Note: Switch the device off and disconnect the charger and any other device before removing any covers. Avoid touching electronic components while changing any covers. Always store and use the device with any covers attached. 1. Place your thumb on the Nokia logo, and pull the top corners one at a time to separate the back cover from the phone. 2. Place your fingers at the top middle of the back cover, and with your thumb on the Nokia logo, remove the cover. 3.

If the battery is in the phone, lift it out. 4. Slide the SIM into the holder with the contact area face down. 5. Line up the battery contacts, and put the battery in. 6. Insert the memory card into the memory card slot. Push the memory card in until it locks into place. © 2014 Nokia. All rights reserved.

5 Important: Do not remove the memory card when an app is using it. Doing so may damage the memory card and the device and corrupt data stored on the card. 7. Replace the back cover. Remove the memory card Pull the memory card out. Switch on your phone Press and hold the power key. Charge the battery Your battery has been partially charged at the factory, but you may need to recharge it before you can use your phone. 1. Plug the charger into a wall outlet.

2.

Connect the charger to the phone. When done, unplug the charger from the phone, then from the wall outlet. If the battery is completely discharged, it may take several minutes before the charging indicator is displayed or before any calls can be made. Tip: You can use USB charging when a wall outlet is not available. Data can be transferred while charging the device. The efficiency of USB charging power varies significantly, and it may take a long time for charging to start and the device to start functioning. Make sure your computer is switched on. Lock or unlock the keys To avoid accidentally pressing the keys, use keypad lock. 1. Quickly press .

© 2014 Nokia. All rights reserved. 6 2. Select Lock. Lock Unlock the keypad , and select Unlock.

Press Change the volume Trouble hearing your phone ringing in noisy environments, or calls too loud? You can change the volume to your liking. Scroll up or down to change the volume during a call or when listening to the radio. © 2014 Nokia. All rights reserved. 7 Basics Learn how to get the most out of your new phone.

Explore your phone Explore your phone with a simple key press. See the apps and features of your phone Press Menu. Menu Go to an app or feature Press the scroll key up, down, left, or right. Open an app or select a feature Press Choose. Choose Go back to the previous view Press Back. Back © 2014 Nokia. All rights reserved. 8 Go back to the home screen . Press Switch the flashlight on On the home screen, quickly press the scroll key up twice. Menu Camera To switch the flashlight off, press up once.

Do not shine the light in anyone's eyes. Write text Writing with the keypad is easy and fun. Press a key repeatedly until the letter is shown. Type in a space Press 0. Type in a special character or punctuation mark Press \*. Switch between character cases Press # repeatedly. Type in a number Press and hold a number key. Use predictive text To speed up your writing, your phone can guess what you are starting to write. Predictive text is based on a built-in dictionary. This feature is not available for all languages.

1. Select Options > Dictionary and the language. 2. Start writing a word. When the word you want is shown, press 0.

Change a word Press \* repeatedly until the word you want is shown. © 2014 Nokia. All rights reserved. 9 Add a new word to the dictionary If the word you want isn't in the dictionary, write the word, press \* repeatedly to skip all unwanted words, select Spell, and write the word. Switch between predictive and traditional text Press # repeatedly.

Switch predictive text off Select Options > Dictionary > Dictionary off. Set the ringtone Set a ringtone for your phone. 1. Select Menu > Settings > Tone settings. 2. Select Ringtone. 3. Pick a ringtone, and select OK. © 2014 Nokia. All rights reserved.

10 People & messaging Contact your friends and family using your phone. Stay tuned with the latest updates to your social networking services even when on the go. Make a call Learn how to make a call with your new phone. 1. Type in the phone number. To type in the + character, used for international calls, press \* twice. 2. Press . 3. To end the call, press Answer a call .

Press . Save a name and phone number Save and organise your friends' phone numbers. Or why not spice up your contacts list by assigning photos or other info to your contacts? 1. Select Menu > Contacts > Add. 2.

Write the name, type in the number, and select Save.



[You're reading an excerpt. Click here to read official NOKIA 220 user guide](http://yourpdfguides.com/dref/5575440)

<http://yourpdfguides.com/dref/5575440>

Send and receive messages Keep in touch with your friends and family through text messages. 1. Select Menu > Messaging. 2. Select Create message. 3. Type in a phone number, or select a recipient from your contacts list. 4. Write your message. Tip: To insert special characters, such as a smiley or symbol, select Options > Insert options. 5. Select Send. You can send text messages that are longer than the character limit for a single message. Longer messages are sent as two or more messages.

Your service provider may charge accordingly. Characters with accents, other marks, or some language options, take more space, and limit the number of characters that can be sent in a single message. Read a message On the home screen, select Read. To read the rest of the message, select Open. Get social Want to connect and share stuff with the people in your life? With social apps, you can stay up to date with what's happening with your friends. © 2014 Nokia. All rights reserved. 11 To keep in touch with your friends and family, sign in to your instant messaging, sharing, and social networking services. Select Menu and the service you want to use. The available services may vary.

© 2014 Nokia. All rights reserved. 12 Internet Learn how to browse the web. Browse the web Catch up on the news, and visit your favourite websites on the go. 1.

Select Menu > Internet. 2. Select the address bar. 3. Write a web address, and select OK.

Tip: To search the internet, write a search word in the address bar. You can also use the available links. Using services or downloading content may cause the transfer of large amounts of data, which may result in data costs. © 2014 Nokia. All rights reserved. 13 Camera With your phone camera, you can easily take photos or record videos. Take a photo Capture the best moments with your phone camera. 1. To switch the camera on, select Camera. 2.

To zoom in or out, press the scroll key up or down. 3. To take a photo, press the scroll key. View the photos you've taken > Photos > Captured. @ @ 1. To switch the camera on, select Camera. > Video camera. 2. To switch the video camera on, select 3. To start recording, select .

4. To stop recording, select . @ @ . @ @ 1. Select Photos and a photo or Videos and a video.

2. Select Options and Share photo or Share video. 3. Select Slam via Bluetooth. 4.

@ @ @ @ @ @ @ @ @ @ @ @ To play music, you need to store the music files on a memory card. 1. Select Menu > Music > Music player. 2. Select Options > All songs. 3. @ @ @ @ The headset acts as an antenna. 1. Connect a headset, and select Menu > Music > Radio. 2.

To go to the previous or next channel, scroll left or right. 3. @ @ 1. Select Menu > Music > Radio. 2. Select Options > Set frequency. 3. Type in the station frequency. 4. To save a station, select Options > Save station.

@ @ @ @ @ Learn how to connect to accessories and networks, transfer files, create backups, lock your phone, and keep the software up to date. Copy content between your phone and computer Copy photos, videos, music, and other content created to regulations governing radio devices. Do not drop, knock, or shake the device. Rough handling can break it. Only use a soft, clean, dry cloth to clean the surface of the device.

Do not paint the device. Paint can prevent proper operation. @ @ Keep the device away from magnets or magnetic fields. @ @ @ @ All materials of the device can be recovered as materials and energy. @ @ @ @ @ For more info on the environmental attributes of your device, see [www.nokia.com/ecoprofile](http://www.nokia.com/ecoprofile). Battery and charger info Use your device only with an original BL-5C rechargeable battery. Charge your device with AC-18 charger.

Charger plug type may vary. Nokia may make additional battery or charger models available for this device. Battery and charger safety Always switch the device off and unplug the charger before removing the battery. To unplug a charger or an accessory, hold and pull the plug, not the cord. When your charger is not in use, unplug it. If left unused, a fully charged battery will lose its charge over time.

Always keep the battery between 15°C and 25°C (59°F and 77°F) for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Accidental short-circuiting can happen when a metallic object touches the metal strips on the battery. This may damage the battery or the other object. Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible. Do not dispose as household waste. Do not dismantle, cut, crush, bend, puncture, or otherwise damage the battery in any way.

If a battery leaks, do not let liquid touch skin or eyes. If this happens, immediately flush the affected areas with water, or seek medical help. Do not modify, attempt to insert foreign objects into the battery, or immerse or expose it to water or other liquids. Batteries may explode if damaged. Use the battery and charger for their intended purposes only.

Improper use, or use of unapproved or incompatible batteries or chargers may present a risk of fire, explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery or charger is damaged, take it to a service centre before continuing to use it. Never use a damaged battery or charger. Do not charge your device during a lightning storm. Only use the charger indoors.

Additional safety information Small children Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children. Medical devices Operation of radio transmitting equipment, including wireless phones, may interfere with inadequately shielded medical devices' function. Consult a physician or the medical device's manufacturer to determine if it is adequately shielded from external radio energy. Implanted medical devices To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and the medical device. Persons who have such devices should: • • Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device. Not carry the wireless device in a breast pocket.

© 2014 Nokia. All rights reserved. 19 • • • Hold the wireless device to the ear opposite the medical device. Switch the wireless device off if there is any reason to suspect that interference is taking place. Follow the manufacturer directions for the implanted medical device. If you have any questions about using your wireless device with an implanted medical device, consult your health care provider. Hearing Warning: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety. Some wireless devices may interfere with some hearing aids. Nickel The surface of this device is nickel-free.

Protect your device from harmful content Your device may be exposed to viruses and other harmful content.



[You're reading an excerpt. Click here to read official NOKIA 220 user guide](http://yourpdfguides.com/dref/5575440)

<http://yourpdfguides.com/dref/5575440>

Take the following precautions: •••••Be cautious when opening messages. They may contain malicious software or otherwise be harmful to your device or computer. Be cautious when accepting connectivity requests, browsing the internet, or downloading content. Do not accept Bluetooth connections from sources you do not trust.

Only install and use services and software from sources that you trust and that offer adequate security and protection. Install antivirus and other security software on your device and any connected computer. Only use one antivirus app at a time. Using more may affect performance and operation of the device and/or computer. If you access preinstalled bookmarks and links to third party internet sites, take the appropriate precautions.

Nokia does not endorse or assume liability for such sites. Vehicles Radio signals may affect improperly installed or inadequately shielded electronic systems in vehicles. For more info, check with the manufacturer of your vehicle or its equipment. Only qualified personnel should install the device in a vehicle. Faulty installation may be dangerous and invalidate your warranty. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. @@@Sparks may cause an explosion or fire resulting in injury or death. @@@These usually are areas where you are advised to switch your engine off, below deck on boats, chemical transfer or storage facilities, and where the air contains chemicals or particles. Check with the manufacturers of vehicles using liquefied petroleum gas (such as propane or butane) if this device can be safely used in their vicinity. Certification information (SAR) This mobile device meets guidelines for exposure to radio waves.

For information on SAR, see the printed user guide, or go to [www.nokia.com/sar](http://www.nokia.com/sar). © 2014 Nokia. All rights reserved. 20 Copyrights and other notices  
DECLARATION OF CONFORMITY Hereby, NOKIA CORPORATION declares that this RM-970 product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity can be found at [www.nokia.com/global/declaration/declaration-of-conformity](http://www.nokia.com/global/declaration/declaration-of-conformity). The availability of products, features, apps and services may vary by region.

Nokia may, in its sole discretion, change, correct or discontinue any of its services in whole or in part. For more info, contact your Nokia dealer or your service provider. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries.

Diversion contrary to law is prohibited. The contents of this document are provided "as is".

Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice. To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

Reproduction, transfer or distribution of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of continuous development.

Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice. Nokia does not make any representations, provide a warranty, or take any responsibility for the functionality, content, or enduser support of third-party apps provided with your device.

By using an app, you acknowledge that the app is provided as is. Downloading of maps, games, music and videos and uploading of images and videos may involve transferring large amounts of data. Your service provider may charge for the data transmission. The availability of particular products, services and features may vary by region. Please check with your local Nokia dealer for further details and availability of language options. TM & © 2014 Nokia. All rights reserved. Third party products/names may be TMs of their respective owners.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Nokia is under license. This product is licensed under the MPEG-4 Visual Patent Portfolio License (i) for personal and noncommercial use in connection with information which has been encoded in compliance with the MPEG-4 Visual Standard by a consumer engaged in a personal and noncommercial activity and (ii) for use in connection with MPEG-4 video provided by a licensed video provider. No license is granted or shall be implied for any other use. Additional information, including that related to promotional, internal, and commercial uses, may be obtained from MPEG LA, LLC. See [www.mpegla.com](http://www.mpegla.com). © 2014 Nokia. All rights reserved.

21 .



[You're reading an excerpt. Click here to read official NOKIA 220 user guide](http://yourpdfguides.com/dref/5575440)

<http://yourpdfguides.com/dref/5575440>