




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NOKIA BH-105. You'll find the answers to all your questions on the NOKIA BH-105 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NOKIA BH-105
User guide NOKIA BH-105
Operating instructions NOKIA BH-105
Instructions for use NOKIA BH-105
Instruction manual NOKIA BH-105

Nokia Bluetooth Headset BH-105



[You're reading an excerpt. Click here to read official NOKIA BH-105 user guide](#)

<http://yourpdfguides.com/dref/5224696>

Manual abstract:

A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/. Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice. To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused. The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. @@The availability of particular products may vary by region. Please check with your Nokia dealer for details.

@@All rights reserved. Nokia, Nokia Connecting People and the Nokia Original Accessories logo are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners. Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

@@@Read this user guide carefully before using the headset. @@This product may contain small parts. Keep them out of the reach of small children. The surface of this device is nickel-free. metres (33 feet) of each other.

Connections may be subject to interference from obstructions, such as walls, or other electronic devices. The headset is compliant with Bluetooth Specification 2.1 + EDR supporting the Headset Profile 1.1 and Hands-Free Profile 1.5. Check with the manufacturers of other devices to determine their compatibility with this device. Bluetooth wireless technology Bluetooth wireless technology allows you to connect compatible devices without cables. The headset and the other device do not need to be in line of sight, but they should be within 10 ENGLISH Get started The headset contains the following parts shown on the title page: power key (1), earloop (2), answer/end key (3), earpiece (4), indicator light (5), charger connector (6), and microphone (7). Before using the headset, you must charge the battery and pair the headset with a compatible device. with this particular model.

@@@Connect the charger to a wall outlet. 2. Connect the charger cable to the charger connector. The red Parts of the device are magnetic. @@Do not place credit cards or other charging. @@because information stored on them may 3. When the battery is fully charged, be erased. the green indicator light is displayed. @@@@To check the battery charge when the headset is not connected to a charger, press the power key. If the indicator light is green, the charge level is sufficient.

If the light is yellow, you may need to recharge the battery soon. If the light is red, recharge the battery. When the battery charge is low, the headset beeps every 5 minutes and the red indicator light flashes. and the red indicator light is briefly displayed. If the headset is not connected to a device within about 30 minutes, it switches off automatically.

Pair and connect the headset 1. Ensure that your mobile device is switched on and the headset is off. 2. Press and hold the power key (for about 5 seconds) until the green indicator light starts to flash quickly. 3.

Within about 3 minutes, activate Bluetooth connectivity on your Switch on or off device, and set it to search for Bluetooth devices. To switch on, press and hold the power key for about 2 seconds. The headset 4. Select the headset from the list of beeps, and the green indicator light is found devices. displayed. The headset tries to 5. If necessary, enter the passcode connect to the last connected device. 0000 to pair and connect the To switch off, press and hold the headset to your device. @@The headset beeps, ENGLISH connection separately after pairing. @@@Proceed as described in the user guide of your device.

To answer or end a call, press the Calls answer/end key. @@@@Push or pull the earloop to set its length.

@@@@@The battery can be charged and discharged hundreds of times, but it will eventually wear out. Recharge your battery only with Nokia approved chargers designated for this device. Use of an unapproved charger may present a risk of fire, explosion, leakage, or other hazard. If a battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger, then disconnect and reconnect it to begin charging the battery. @@@@Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. @@Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Never use any charger that is damaged. @@The amount of time a device is used for calls will affect its standby time. Likewise, the amount of time that the ENGLISH device is turned on and in the standby mode will affect its talk time. Care and maintenance Your device is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation. @@@@This requirement applies in the European Union.

Do not dispose of these products as unsorted municipal waste. @@Always return your used electronic products, batteries, and packaging materials to a dedicated collection point. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. More detailed information is available from the product retailer, local waste authorities, national producer responsibility organisations, or your local Nokia representative. Check how to recycle your Nokia products at www.nokia.com/werecycle, or if browsing on a mobile device, www.nokia.mobi/werecycle.



[You're reading an excerpt. Click here to read official NOKIA BH-105 user guide](#)

<http://yourpdfguides.com/dref/5224696>