



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NOKIA BH-220. You'll find the answers to all your questions on the NOKIA BH-220 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NOKIA BH-220
User guide NOKIA BH-220
Operating instructions NOKIA BH-220
Instructions for use NOKIA BH-220
Instruction manual NOKIA BH-220

Nokia Luna with Wireless Charging (BH-220) User Guide

Issue 1.0



[You're reading an excerpt. Click here to read official NOKIA BH-220 user guide](#)

<http://yourpdfguides.com/dref/4726128>

When your charger is not in use, unplug it from the electrical plug and the device. Do not leave a fully charged battery connected to a charger, as overcharging may shorten the battery's lifetime. @@@@Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Do not dispose of batteries in a fire as they may explode. Dispose of batteries according to local regulations. Recycle when possible. Do not dispose as household garbage. Use the charger for its intended purpose only. @@@@Never use a damaged charger. Only use the charger indoors.

Take care of your device Handle your device, charger and accessories with care. The following suggestions help you protect your warranty coverage. •••••
••Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits. If your device gets wet, allow the device to dry.

Do not use or store the device in dusty or dirty areas. Moving parts and electronic components can be damaged. Do not store the device in high temperatures. High temperatures can shorten the life of the device, damage the battery, and warp or melt plastics. Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage electronic circuits. Do not attempt to open the device. Unauthorized modifications may damage the device and violate regulations governing radio devices. Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and mechanics.

10 • Only use a soft, clean, dry cloth to clean the surface of the device. R.



[You're reading an excerpt. Click here to read official NOKIA BH-220 user guide](http://yourpdfguides.com/dref/4726128)

<http://yourpdfguides.com/dref/4726128>