




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NOKIA BLUETOOTH STEREO HEADSET BH-214. You'll find the answers to all your questions on the NOKIA BLUETOOTH STEREO HEADSET BH-214 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NOKIA BLUETOOTH STEREO HEADSET BH-214
User guide NOKIA BLUETOOTH STEREO HEADSET BH-214
Operating instructions NOKIA BLUETOOTH STEREO HEADSET BH-214
Instructions for use NOKIA BLUETOOTH STEREO HEADSET BH-214
Instruction manual NOKIA BLUETOOTH STEREO HEADSET BH-214

Nokia Bluetooth Stereo Headset BH-214



9214016/1



[You're reading an excerpt. Click here to read official NOKIA BLUETOOTH STEREO HEADSET BH-214 user guide](http://yourpdfguides.com/dref/2737775)
<http://yourpdfguides.com/dref/2737775>

Manual abstract:

A copy of the Declaration of Conformity can be found at http://www.nokia.com/phones/declaration_of_conformity/. Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice. To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused. The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice. The availability of particular products may vary by region.

Please check with your Nokia dealer for details. Export controls This device may contain commodities, technology or software subject to export © 2009 Nokia. All rights reserved. Nokia, Nokia Connecting People and the Nokia Original Accessories logo are trademarks or registered trademarks of Nokia Corporation. Nokia tune is a sound mark of Nokia Corporation.

Other product and company names mentioned herein may be trademarks or tradenames of their respective owners. Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited. @@@@You can also listen to music from a compatible music player. Read this user guide carefully before using the headset. @@This product may contain small parts.

Keep them out of the reach of small children. The surface of this device is nickel-free. without cables. @@Connections may be subject to interference from obstructions, such as walls, or other electronic devices. The headset is compliant with the Bluetooth Specification 2.1 + EDR supporting the following profiles: Headset Profile 1.2, Hands-Free Profile (HFP) 1.5, Advanced Audio Distribution Profile (A2DP) 1.2, and Audio Video Remote Control Profile 1.0.

Check with the manufacturers of other devices to determine their compatibility with this device. Bluetooth wireless technology Bluetooth wireless technology allows you to connect compatible devices ENGLISH Get started The headset contains the following parts shown on the title page: 3.5 mm audio connector (1) for headphones, microphone (2), power key (3), indicator light (4), answer/end key (5), rewind key (6), play/pause key (7), forward key (8), clip (9), charger connector (10), volume up key (11), and volume down key (12). Before using the headset, you must charge the battery and pair the headset with a compatible device. Parts of the device are magnetic. Metallic materials may be attracted to the device. Do not place credit cards or other magnetic storage media near the device, because information stored on them may be erased. Charge the battery Before charging the battery, carefully read "Battery and charger information". Warning: Use only chargers approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

When you disconnect the power cord of any accessory, grasp and pull the plug, not the cord. 1. Connect the charger to a wall outlet. 2. Connect the charger cable to the charger connector (14).

The red indicator light is displayed during charging. Charging the battery fully may take up to 2 hours. ENGLISH 3. When the battery is fully charged, the green indicator light is displayed. Disconnect the charger from the headset, then from the wall outlet.

The fully charged battery has power for up to 8 hours of talk time, up to 300 hours of standby time, or up to 7 hours of music playing time. To check the battery charge when the headset is not connected to a charger, press the answer/end key when the headset is switched on and no call is in progress. If the indicator light is green, the charge level is sufficient. If the light is yellow, you may need to recharge the battery soon. If the light is red, recharge the battery. When the battery charge is low, the headset beeps every 5 minutes and the red indicator light flashes. Switch on or off To switch on, press and hold the power key for about 2 seconds. The headset beeps, and the green indicator light is displayed. The headset tries to connect to the last connected mobile device. To switch off, press and hold the power key for about 5 seconds.

The headset beeps, and the red indicator light is briefly displayed. If the headset is not connected to a device within about 30 minutes, it switches off automatically. Pair and connect the headset Before using the headset, you must pair and connect it with a compatible device. If your mobile device supports the A2DP Bluetooth profile and has a music player feature, you can use the ENGLISH device to also play music through the headset. If your mobile device does not support the A2DP profile, you can separately pair the headset with the mobile device and a music player that supports this profile. @@1. @@2.

@@3. @@4. Select the headset from the list of found devices.

5. @@@@ Use the clip to attach the headset to your clothing. @@@@ To adjust the volume quickly, press and hold either key. @@@@ Proceed as described in the user guide of the mobile device. To answer or end a call, press the answer/end key.

To reject a call, press this key twice. @@@@ The available music functions depend on your music player. If you receive or make a call while listening to music, the music is paused until you end the call. Warning: Listen to music at a moderate level. Continuous exposure to high volume may damage your hearing.

To play a song, select it in the music player, and press the play/pause key. To pause or resume playing, press the play/pause key. To stop playing, press and hold the play/pause key. To select the next song during playback, press the forward key. To select the previous song, press the ENGLISH rewind key twice. To scroll through the hold the power key and the answer/ current song quickly, press and hold end key (for about 5 seconds) until the either key. red and green indicator lights start to alternate. Turn lights on or off To reset the headset if it stops By default, the indicator lights are functioning, even though it is charged, shown in all situations. To turn the connect the headset to a charger lights off in some situations (for while you press and hold the power example, during a call or when the key. headset is connected to a mobile device) or back on, press and hold the Troubleshooting power key and the answer/end key for If you cannot connect the headset to about 5 seconds when the headset is your compatible device, check that connected to a device.

the headset is charged, switched on, and paired with the device.



**[You're reading an excerpt. Click here to read official NOKIA
BLUETOOTH STEREO HEADSET BH-214 user guide
http://yourpdfguides.com/dref/2737775](http://yourpdfguides.com/dref/2737775)**

Clear settings or reset To clear the volume and pairing settings from the headset, press and Battery and charger information This device has an internal, nonremovable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device. This device is intended for use when supplied with power from the ENGLISH following chargers: AC-3, AC-4, AC-5, AC-8, DC-4, and DC-9. The exact charger model number may vary depending on the type of plug. The plug variant is identified by one of the following: E, EB, X, AR, U, A, C, or UB. The battery can be charged and discharged hundreds of times, but it will eventually wear out. @@@@ Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Always try to keep the battery between 15°C and 25°C (59°F and 77°F). Extreme temperatures reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily. Battery performance is particularly limited in temperatures well below freezing. Do not dispose of batteries in a fire as they may explode.

Batteries may also explode if damaged. Never use any charger that is damaged. Important: Battery operating times are estimates only and depend on network conditions, features used, battery age and condition, temperatures to which battery is exposed, and many other factors. ENGLISH Care and mainte.



[You're reading an excerpt. Click here to read official NOKIA BLUETOOTH STEREO HEADSET BH-214 user guide](http://yourpdfguides.com/dref/2737775)
<http://yourpdfguides.com/dref/2737775>