



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for OKI C331DN. You'll find the answers to all your questions on the OKI C331DN in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual OKI C331DN**  
**User guide OKI C331DN**  
**Operating instructions OKI C331DN**  
**Instructions for use OKI C331DN**  
**Instruction manual OKI C331DN**

<b>C331 dn/ C531 dn</b>		<b>OKI</b>
<b>Safety, Warranty and Regulatory Information</b>	..... 2	
<b>Informations de sécurité, de garantie, et de réglementation</b>	.....14	
<b>Información sobre seguridad, garantía, y regulaciones</b>	..... 27	
<b>Informações sobre segurança para modelos de 120 V</b>	.....38	
<hr/>		
<b>Country/ Region • Pays/ Région • País/ região • País/ região</b>		
<hr/>		
<b>United States and Canada, Etats-Unis et Canada, Estados Unidos y Canadá</b>		
<hr/>		
<i>English</i>		
Safety Information	..... 2	
Warranty Information	..... 4	
Service and Support	..... 4	
Regulatory Information	..... 5	
Material Safety Data Sheet (MSDS)	..... 6	
<i>Français</i>		
Informations sur la sécurité	..... 14	
Information sur la garantie	..... 15	
Service et soutien	..... 17	
Informations réglementaires	..... 18	
Fiche technique santé-sécurité (MSDS)	..... 19	
<i>Español</i>		
Información de Seguridad	..... 27	
Información sobre la garantía	..... 29	
Servicio y Apoyo	..... 30	
Información reglamentaria	..... 33	
Hojas de Información sobre Seguridad de los Materiales (MSDS)	..... 35	
<hr/>		
<b>Mexico, México</b>		
<hr/>		
<i>Español</i>		
Información de Seguridad	..... 27	
Información sobre la garantía	..... 29	
Servicio y Apoyo	..... 30	
Información reglamentaria	..... 33	
Hojas de Información sobre Seguridad de los Materiales (MSDS)	..... 35	
<i>English</i>		
Safety Information	..... 2	
Regulatory Information	..... 5	
Material Safety Data Sheet (MSDS)	..... 6	
<hr/>		
<b>América Latina (otro), Latin America (other)</b>		
<hr/>		
<i>Español</i>		
Información de Seguridad	..... 27	
Información sobre la garantía	..... 29	
Servicio y Apoyo	..... 30	
Información reglamentaria	..... 33	
Hojas de Información sobre Seguridad de los Materiales (MSDS)	..... 35	
<i>English</i>		
Safety Information	..... 2	
Regulatory Information	..... 5	
Material Safety Data Sheet (MSDS)	..... 6	
<hr/>		
<b>Brasil, Brazil</b>		
<hr/>		
<i>Português</i>		
Informações de segurança	..... 38	
Informações sobre a garantia	..... 40	
Informações normativas	..... 41	
Ficha de Informação de Segurança do Produto	..... 42	
<i>English</i>		
Safety Information	..... 2	
Regulatory Information	..... 5	
Material Safety Data Sheet (MSDS)	..... 6	



[You're reading an excerpt. Click here to read official OKI C331DN user guide](http://yourpdfguides.com/dref/5165047)  
<http://yourpdfguides.com/dref/5165047>

**Manual abstract:**

Use only a damp cloth; do not use liquid or aerosol cleaners. Place your product on a firm, solid surface. If you put it on something unsteady, it may fall and be damaged. Protect your product from overheating. Make sure no obstructions block the openings of the product. Do not put the product on or near a heat source (such as a radiator or heat register). Keep the product out of direct sunlight. Always use this product in a well ventilated area. Allow enough room around the product for adequate ventilation and easy access to the paper trays. If you put the product in any kind of enclosure, make sure the enclosure is well ventilated.

Do not use your product near water. Do not spill liquid of any kind into it. Be certain that your power source matches the rating listed on the back of the product. If you are not sure, check with your dealer or with your local power company. Do not connect this product to an uninterruptible power supply (UPS).

This plug only fits into a grounded outlet. If the plug does not fit, the outlet may be an older, non-grounded type. Contact an electrician to have the outlet replaced. Do not use an adapter to defeat the grounding. Install the product near an easily accessed power outlet.

Avoid damaging the power cord. Do not put anything on it or place it where it will be walked on. If the cord becomes damaged or frayed, replace it immediately. If you are using an extension cord or power strip with the product, make sure that the total of the amperes required by all the equipment on the extension is less than the extension's rating. The total ratings of all equipment plugged into the outlet should not exceed 15 amperes. Important! A telephone cable using 26 AWG wire or larger must be used with this equipment. Do not poke anything into the ventilation slots of the product. You could get an electrical shock or cause hazardous electrical arcing, which could cause a fire. Aside from the routine maintenance described in the documentation, do not try to service the product yourself. Removing the cover may expose you to shocks or other hazards.

Do not make any adjustments other than those outlined in the documentation. You may cause damage that will require extensive repair work. The provided documentation explains how to get your product serviced by qualified Oki Data technicians. If anything happens that indicates that your product is not working properly or has been damaged, unplug it immediately and follow the procedures in the provided documentation for having your product serviced. Here are some of the things to look for: The power cord or plug is frayed or damaged. Liquid has been spilled into the product, or the product has been exposed to water. The product has been dropped, or the cabinet is damaged. The product does not function normally when you are following the operating instructions. 2 - English Safety Information, i 220/240-Volt Models This product has been carefully designed to give years of safe, reliable performance.

As with all electrical equipment, however, there are a few basic precautions that should be taken to avoid injury or damage: Ensure this and all other documentation is both read carefully and retained for future reference. Ensure all warning and instruction labels on the product are read, understood and followed in order to prevent any risk of injury. This product may be heavy. Please check the weight of the product and take all necessary precautions to prevent the risk of personal injury. The product must be placed on a flat solid surface strong enough to support its weight to prevent any risk of injury. Ensure that there is adequate ventilation all around the product to prevent overheating and any risk of fire. Keep the product away from direct heat sources such as radiators and out of direct sunlight to prevent any risk of overheating. The power supply required for this product is 220-240 VAC, 50/60 Hz. (For any DC powered product, the figures are 9.) Refer to your product's rating label on the machine for full power rating details.

Ensure that you have a suitable power supply before connecting the product. If in doubt contact your dealer or check with your local power provider. Ensure both the product and mains power switches are in the OFF position before connecting the AC power cable. Do not connect or disconnect the power plug with a wet hand as this may cause electric shock. Always hold the power plug to connect/disconnect the power cable to/from the mains socket. Unplugging by pulling on the cable can cause fraying and may lead to fire or electric shock. This product has an earthed plug as a safety feature and will only connect to an earthed socket. Do not attempt to defeat the earthing or there is a risk of fire or shock. If using an extension cable or power strip ensure that the total current rating (amperes) of all connected equipment is less than the maximum rating of the extension cable, power strip or wall outlet. If the product is already supplied with a fitted power strip then no additional power strip or extension cable should be used to connect to the mains wall outlet.

Otherwise, fire or shock may occur. Ensure the power cable is routed so as not to be damaged or cause a trip hazard. If the cable becomes frayed or damaged replace it immediately to prevent any risk of shock. Do not twist, constrict or knot the power cable as this can cause overheating which may lead to fire or electric shock. Ensure the power socket to which the product is connected is easily accessible at all times and not obstructed. Use only the power cable supplied. Using a power cable not intended for this product may lead to fire or electric shock. To avoid risk of fire and electric shock, do not use the power cable supplied with this product for any other electrical equipment. If you do not connect the power cord or any other cables only as directed in the User's Guide, this may result in a fire. It is recommended that the machine is switched off prior to opening covers; otherwise there is a risk of electric shock.

When the product cover is open, do not touch the fuser unit or print head as you may receive burns. Allow it to cool before touching. If the product casing gets extremely hot or smoke, unusual smells or abnormal noises are emitted from the product, there is a risk of fire. Unplug the mains connector and contact your dealer. If the product has been knocked over or damaged, there is a risk of electric shock, fire and/or injury.

Unplug the mains connector and contact your dealer. If any liquid (for example water) is allowed to enter the product, there is a risk of fire. Unplug the mains connector and contact your dealer. Do not place containers containing liquid on the product as electric shock, fire and/or injuries may occur.



[You're reading an excerpt. Click here to read official OKI C331DN user guide](http://yourpdfguides.com/dref/5165047)  
<http://yourpdfguides.com/dref/5165047>

If any foreign objects (for example clips) are allowed to enter the product, there is a risk of electric shock, fire and/or injury.

Unplug the mains connector before removing the object. Do not introduce foreign objects into the ventilation holes or operate this product with any covers open or doors removed as electric shock, fire and/or injuries may occur. Do not use an extremely flammable spray near the product as the product contains high temperature parts that may cause a fire. Switch the product off before cleaning to prevent any risk of injury. Ensure loose clothing and hair is kept clear of moving parts when the product is in operation to prevent possible risk of injury. @@ this may result in electric shock, fire and/or injury. Do not touch the battery if one is fitted to the product. @@@@ if a scanner, finisher etc. @@@@This Limited Warranty extends to the original purchaser only. @@@@Additional information on obtaining service under this Limited Warranty is available by contacting the Oki Data dealer from whom the product was purchased, by contacting Oki Data directly at 1-800-654-3282 (1-800-OKI-DATA) [U.

However, the procedure for obtaining service may vary outside the continental United States. Contact your Oki Data dealer for such warranty service information. This warranty gives you specific legal rights, and tinguishing Media: In case of small fire, use CO2. In case of large fire, shut off air by spraying with water or foam. Special Fire Fighting Procedures: Fight fire from upwind position. avoid inhalation of smoke or gases. Wear self-contained breathing apparatus. hazardous Combustion Products: Carbon monoxide, oxides of nitrogen. Emergency First Aid Procedures Toner swallowed (ingested)

Immediately seek medical attention. Never give anything by mouth to an unconscious person.

If possible, rinse out mouth and give one or two glasses of water or milk to drink. Toner gets in the eyes. Flush eyes with large quantities of cool water for 15 minutes, keeping the eyelids open with fingers. If necessary, seek medical attention. Toner gets on the skin.

Wash toner off the skin with plenty of cool water and soap. If necessary, seek medical attention. Note: Small amounts of toner on skin or clothing can easily be removed with soap and cold water. For large spills, use dust respirator during cleanup. protective Gloves and/or Eye Protection: Not normally required.

@@@ large Spills 1. @@ 2. Wear protective gear: respirator, rubber gloves, safety goggles. 3. Vacuum the spill, then wipe up remainder with a wet cloth. @- Large amounts must be passed to a licensed waste contractor. Precautions Precautions for Handling or Storage: Protect from the sun. store in a cool room, under 104°F (40°C). Keep out of reach of children. User's Responsibility \_\_\_\_\_ This bulletin cannot cover all possible situations which the user may experience when using this product.

Each aspect of your operation must be examined in regard to if, or where, additional precautions may be necessary. All health and safety information contained in this bulletin must be provided to your employees or customers. It is your responsibility to use this information to develop appropriate work practice guidelines and employee instructional programs for your operation. Emergency Information: call 1-800-654-3282; US and Canada only. fire and Explosion Hazard Data \_\_\_\_\_ Minimal fire hazard. Large quantities may cause risk of dust explosion. Extinguishing Media: In case of small fire, use CO2. In case of large fire, shut off air by spraying with water or foam. Special Fire Fighting Procedures: Fight fire from upwind position. avoid inhalation of smoke or gases.

Wear self-contained breathing apparatus. hazardous Combustion Products: Carbon monoxide, oxides of nitrogen. Emergency First Aid Procedures Toner swallowed (ingested) Immediately seek medical attention. Never give anything by mouth to an unconscious person. If possible, rinse out mouth and give one or two glasses of water or milk to drink.

Toner gets in the eyes. Flush eyes with large quantities of cool water for 15 minutes, keeping the eyelids open with fingers. If necessary, seek medical attention. Toner gets on the skin. Wash toner off the skin with plenty of cool water and soap.

If necessary, seek medical attention. Note: Small amounts of toner on skin or clothing can easily be removed with soap and cold water. For large spills, use dust respirator during cleanup. protective Gloves and/or Eye Protection: Not normally required. @@@ large Spills 1. @@ 2. Wear protective gear: respirator, rubber gloves, safety goggles. 3. Vacuum the spill, then wipe up remainder with a wet cloth. @- Large amounts must be passed to a licensed waste contractor.

Precautions Precautions for Handling or Storage: Protect from the sun. store in a cool room, under 104°F (40°C). Keep out of reach of children. User's Responsibility \_\_\_\_\_ This bulletin cannot cover all possible situations which the user may experience when using this product. Each aspect of your operation must be examined in regard to if, or where, additional precautions may be necessary. All health and safety information contained in this bulletin must be provided to your employees or customers. It is your responsibility to use this information to develop appropriate work practice guidelines and employee instructional programs for your operation. Emergency Information: call 1-800-654-3282; US and Canada only. fire and Explosion Hazard Data \_\_\_\_\_ Minimal fire hazard. Large quantities may cause risk of dust explosion.

Extinguishing Media: In case of small fire, use CO2. In case of large fire, shut off air by spraying with water or foam. Special Fire Fighting Procedures: Fight fire from upwind position. avoid inhalation of smoke or gases. Wear self-contained breathing apparatus.

hazardous Combustion Products: Carbon monoxide, oxides of nitrogen. Emergency First Aid Procedures Toner swallowed (ingested) Immediately seek medical attention. Never give anything by mouth to an unconscious person. If possible, rinse out mouth and give one or two glasses of water or milk to drink. Toner gets in the eyes.

Flush eyes with large quantities of cool water for 15 minutes, keeping the eyelids open with fingers. If necessary, seek medical attention. Toner gets on the skin. Wash toner off the skin with plenty of cool water and soap. If necessary, seek medical attention. Note: Small amounts of toner on skin or clothing can easily be removed with soap and cold water. For large spills, use dust respirator during cleanup. protective Gloves and/or Eye Protection: Not normally required. @@@ large Spills 1. @@ 2.

Wear protective gear: respirator, rubber gloves, safety goggles. 3. Vacuum the spill, then wipe up remainder with a wet cloth. @- Large amounts must be passed to a licensed waste contractor. Precautions Precautions for Handling or Storage: Protect from the sun. store in a cool room, under 104°F (40°C).



[You're reading an excerpt. Click here to read official OKI C331DN user guide](http://yourpdfguides.com/dref/5165047)  
<http://yourpdfguides.com/dref/5165047>

Keep out of reach of children. User's Responsibility \_\_\_\_\_ This bulletin cannot cover all possible situations which the user may experience when using this product. Each aspect of your operation must be examined in regard to if, or where, additional precautions may be necessary. All health and safety information contained in this bulletin must be provided to your employees or customers.

It is your responsibility to use this information to develop appropriate work practice guidelines and employee instructional programs for your operation. Emergency Information: call 1-800-654-3282; US and Canada only. fire and Explosion Hazard Data \_\_\_\_\_ Minimal fire hazard. Large quantities may cause risk of dust explosion. Extinguishing Media: In case of small fire, use CO2.

In case of large fire, shut off air by spraying with water or foam. Special Fire Fighting Procedures: Fight fire from upwind position. avoid inhalation of smoke or gases. Wear self-contained breathing apparatus. hazardous Combustion Products: Carbon monoxide , oxides of nitrogen.

Emergency First Aid Procedures Toner swallowed (ingested) Immediately seek medical attention. Never give anything by mouth to an unconscious person. If possible, rinse out mouth and give one or two glasses of water or milk to drink. Toner gets in the eyes. Flush eyes with large quantities of cool water for 15 minutes, keeping the eyelids open with fingers. If necessary, seek medical attention. Toner gets on the skin. Wash toner off the skin with plenty of cool water and soap. If necessary, seek medical attention. Note: Small amounts of toner on skin or clothing can easily be removed with soap and cold water.

For large spills, use dust respirator during cleanup. protective Gloves and/or Eye Protection: Not normally required. @@@@ large Spills 1. @@ 2. Wear protective gear: respirator, rubber gloves, safety goggles. 3. Vacuum the spill, then wipe up remainder with a wet cloth. @@@ Large amounts must be passed to a licensed waste contractor. Precautions Precautions for Handling or Storage: Protect from the sun. store in a cool room , under 104°F (40°C).

Keep out of reach of children. User's Responsibility This bulletin cannot cover all possible situations which the user may experience when using this product. Each aspect of your operation must be examined in regard to if, or where, additional precautions may be necessary. All health and safety information contained in this bulletin must be provided to your employees or customers. It is your responsibility to use this information to develop appropriate work practice guidelines and employee instructional programs for your operation.



[You're reading an excerpt. Click here to read official OKI C331DN user guide](http://yourpdfguides.com/dref/5165047)

<http://yourpdfguides.com/dref/5165047>