



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for OKI C5400. You'll find the answers to all your questions on the OKI C5400 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual OKI C5400
User guide OKI C5400
Operating instructions OKI C5400
Instructions for use OKI C5400
Instruction manual OKI C5400



Setup Guide
Guide d'installation
Guía de instalación
Manual de Instalação

59359301

Okidata Network Solutions
for a Global Society



[You're reading an excerpt. Click here to read official OKI C5400 user guide](http://yourpdfguides.com/dref/4286519)

<http://yourpdfguides.com/dref/4286519>

Manual abstract:

Do not touch the image drum's shiny green surface. Replace the black drum/toner unit, then push the lock lever toward the back of the printer as far as it will go. caution! Remove the fuser shipping restraint (A) and orange band (B) by pushing the restraint to the left, then lifting it out. Pull out the paper tray. Load the paper (maximum 300 sheets 20-lb [75 g/m2] paper). Note: Do not fill above paper full indicator (A). Gently close the paper tray. Open the tray (A, B, C), then push down on the platform (D). Press + one or more times, until you see INFORMATION MENU on the first line of the display.



[You're reading an excerpt. Click here to read official OKI C5400 user guide](http://yourpdfguides.com/dref/4286519)

<http://yourpdfguides.com/dref/4286519>