



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for OMRON ZFV. You'll find the answers to all your questions on the OMRON ZFV in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual OMRON ZFV**  
**User guide OMRON ZFV**  
**Operating instructions OMRON ZFV**  
**Instructions for use OMRON ZFV**  
**Instruction manual OMRON ZFV**



[You're reading an excerpt. Click here to read official OMRON ZFV user guide](http://yourpdfguides.com/dref/2890618)  
<http://yourpdfguides.com/dref/2890618>



) Approx. 200 mA Focus: f13.47 Thirty-six white LEDs Class 2 Yes Vibration resistance (destruction) Shock resistance (destruction) Connection method Degree of protection \*1. \*2. Approx. 350 mA (15 V: approx. 150 mA, 48 V: approx. 200 mA, including current when external light is connected) available. @@@@Wegalaan 67-69, NL-2132 JD, Hoofddorp, The Netherlands.

Tel: +31 (0) 23 568 13 00 Fax: +31 (0) 23 568 13 88 [www.omron-industrial.com](http://www.omron-industrial.com) Austria Tel: +43 (0) 1 80 19 00 [www.omron.at](http://www.omron.at) Belgium Tel: +32 (0) 2 466 24 80 [www.omron.be](http://www.omron.be) Czech Republic Tel: +420 234 602 602 [www.omron.cz](http://www.omron.cz) Denmark Tel: +45 43 44 00 11 [www.omron.dk](http://www.omron.dk) Finland Tel: +358 (0) 207 464 200 [www.omron.fi](http://www.omron.fi) France Tel: +33 (0) 1 56 63 70 00 [www.omron.fr](http://www.omron.fr) Germany Tel: +49 (0) 2173 680 00 [www.omron.de](http://www.omron.de) Hungary Tel: +36 (0) 1 399 30 50 [www.omron.hu](http://www.omron.hu) Italy Tel: +39 02 326 81 [www.omron.it](http://www.omron.it) Middle East & Africa Tel: +31 (0) 23 568 11 00 [www.omron-industrial.com](http://www.omron-industrial.com) Netherlands Tel: +31 (0) 23 568 11 00 [www.omron.nl](http://www.omron.nl) Norway Tel: +47 (0) 22 65 75 00 [www.omron.no](http://www.omron.no) Poland Tel: +48 (0) 22 645 78 60 [www.omron.pl](http://www.omron.pl) Portugal Tel: +351 21 942 94 00 [www.omron.pt](http://www.omron.pt) Russia Tel: +7 495 745 26 64 [www.omron.ru](http://www.omron.ru) Spain Tel: +34 913 777 900 [www.omron.es](http://www.omron.es) Sweden Tel: +46 (0) 8 632 35 00 [www.omron.se](http://www.omron.se) Switzerland Tel: +41 (0) 41 748 13 13 [www.omron.ch](http://www.omron.ch) Turkey Tel: +90 (0) 216 474 00 40 [www.omron.com.tr](http://www.omron.com.tr) United Kingdom Tel: +44 (0) 870 752 08 61 [www.omron.co.uk](http://www.omron.co.uk) More Omron representatives [www.omron-industrial.com](http://www.omron-industrial.com)

Authorised Distributor: Control Systems · Programmable logic controllers · Human-machine interfaces · Remote I/O Motion & Drives · Motion controllers · Servo systems · Inverters Control Components · Temperature controllers · Power supplies · Timers · Counters · Programmable relays · Digital panel indicators · Electromechanical relays · Monitoring products · Solid-state relays · Limit switches · Pushbutton switches · Low voltage switch gear Sensing & Safety · Photoelectric sensors · Inductive sensors · Capacitive & pressure sensors · Cable connectors · Displacement & width-measuring sensors · Vision systems · Safety networks · Safety sensors · Safety units/relay units · Safety door/guard lock switches KPP\_ZFV\_Colour\_01\_EN\_INT Although we strive for perfection, Omron Europe BV and/or its subsidiary and affiliated companies do not warrant or make any representations regarding the correctness or completeness of the information described in this document. We reserve the right to make any changes at any time without prior notice. .



[You're reading an excerpt. Click here to read official OMRON ZFV user guide](#)

<http://yourpdfguides.com/dref/2890618>