



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ONKYO BD-SP309. You'll find the answers to all your questions on the ONKYO BD-SP309 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ONKYO BD-SP309  
User guide ONKYO BD-SP309  
Operating instructions ONKYO BD-SP309  
Instructions for use ONKYO BD-SP309  
Instruction manual ONKYO BD-SP309

**ONKYO.**

LECTEUR DE DISQUES  
BLU-RAY

***BD-SP309***

Mode d'emploi

Nous vous remercions pour votre achat de ce LECTEUR DE DISQUES BLU-RAY Onkyo. Veuillez lire attentivement ce manuel avant de procéder à tout raccordement ou avant de brancher l'appareil. Suivre les instructions de ce manuel vous permettra d'obtenir une performance optimale et de profiter pleinement de votre nouveau LECTEUR DE DISQUES BLU-RAY. Veuillez conserver ce manuel pour vous y référer ultérieurement.

## Contenu

Introduction ..... 2

Raccordement ..... 15

Lecture ..... 19

Réglages ..... 39

Dépannage ..... 50

Annexe ..... 54



[You're reading an excerpt. Click here to read official ONKYO BD-SP309 user guide](http://yourpdfguides.com/dref/5224871)

<http://yourpdfguides.com/dref/5224871>

**Manual abstract:**

- Adresse IP, masque de réseau, passerelle, adresse DNS Do you obtain the IP address automatically? Enter 4-digit PIN code • Si le périphérique mémoire USB n'est pas correctement inséré ou si le fichier de mise à jour correct est introuvable sur le périphérique mémoire USB, un message d'erreur apparaît. @@Software update file is not detected in the USB memory device. @@@@OK There is more than one software file in the USB memory device. @@Insert USB memory device containing the software update file. The picture will temporarily go dark until the software update display appears. Wait several minutes and do not unplug the AC cord. Now checking the data in USB memory device. Now updating Checking \* Do not unplug AC cord. Software update file is detected in the USB memory device. .



[You're reading an excerpt. Click here to read official ONKYO BD-SP309 user guide](http://yourpdfguides.com/dref/5224871)  
<http://yourpdfguides.com/dref/5224871>