



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ONKYO TX-NR828. You'll find the answers to all your questions on the ONKYO TX-NR828 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ONKYO TX-NR828
User guide ONKYO TX-NR828
Operating instructions ONKYO TX-NR828
Instructions for use ONKYO TX-NR828
Instruction manual ONKYO TX-NR828

Quick Start Guide TX-NR828


Supplied Accessories

Make sure you have the following accessories:

- ① Indoor FM antenna
 - ② AM loop antenna
 - ③ Speaker cable labels
 - ④ Remote controller and two batteries (AA/R6)
 - ⑤ Power cord (Plug type varies from country to country.)
 - ⑥ Speaker setup microphone
- The AV receiver can automatically perform speaker and surround settings, so that you can easily enjoy a surround sound tailored to your listening environment. Connect the supplied microphone to the AV receiver and follow the on-screen instructions.
- When performing automatic speaker setup, connect your TV to the AV receiver and make the room as quiet as possible.




Using the Remote Controller



Note

Before connecting the power cord, connect all of your speakers and AV components.

1. Connecting Your Speakers




- ①② Front speakers
- ③ Center speaker
- ④⑤ Surround speakers
- ⑥ Subwoofer(s)
- ⑦⑧ Surround back speakers
- ⑨⑩ Front high speakers
- ⑪⑫ Front wide speakers

Speaker Configuration

- 5.1-channel: ①②③④⑤⑥
- 7.1-channel: ①②③④⑤⑥ + ⑦⑧
- 7.1-channel: ①②③④⑤⑥ + ⑨⑩
- 7.1-channel: ①②③④⑤⑥ + ⑪⑫

Please connect ①, ②, ③, ④, ⑤ and ⑥ for 5.1-channel surround.



SN 29401444
(C) Copyright 2013 Onkyo Corporation Japan. All rights reserved.



[You're reading an excerpt. Click here to read official ONKYO TX-NR828 user guide](#)
<http://yourpdfguides.com/dref/5225248>

Manual abstract:

) f Speaker setup microphone The AV receiver can automatically perform speaker and surround settings, so that you can easily enjoy a surround sound tailored to your listening environment. Connect the supplied microphone to the AV receiver and follow the on-screen instructions. When performing automatic speaker setup, connect your TV to the AV receiver and make the room as quiet as possible. @ @ 16 ft. @ @ @ @ @ @ For wireless LAN connection, see "4. Performing Wireless LAN Setup" (→Page 5). 3. Turning On & Initial Setup The components connected to each terminal (BD/DVD, GAME, etc.) can be selected with the input selector buttons of the same name on the front panel. Note that these default assignments can be changed.

For details, please refer to the instruction manual. HDMI OUT Initial Setup is automatically started upon first-time use, and you can make an initial setup by watching guidance displayed on the TV screen. If you make this setup later, select No and press ENTER on the remote controller on the next screen after selecting the language. • Connect the AV receiver to your TV with HDMI to make an Initial Setup on the TV screen. • If you set your home network to "Wireless", see "4.

Performing Wireless LAN Setup": □ Listening to TV audio (Optional) (Without Audio Return Channel) AUDIO OUT DIGITAL OPTICAL OUT L □ Video upconversion to HDMI Using the Setup User Interface If you connect the AV receiver to your TV with HDMI, you can make settings on the TV screen. On the TV, select the input to which the AV receiver is connected. Setup Menu (Home Menu) The Setup menu provides extended setup that includes settings for advanced users. Quick Setup The Quick Setup provides quick access to frequently used settings.

You can change settings and view the current information. (Supports Audio Return Channel) When using a TV that supports Audio Return Channel, both audio/video signals from the AV receiver and the audio output from the TV are carried bidirectionally on a single HDMI cable. (*) 1 2 BD/DVD Input Audio Video Information Listening Mode TV □ Setup operation HDMI IN R @ @ Press RETURN to return to the previous screen. Press HOME to close the setup screen. □ Input You can select the input source while viewing the related information. □ Audio You can change various audio settings such as tone controls, the subwoofer and center channel levels. □ Information You can view various information about the currently selected input source. □ Listening Mode You can select the listening modes that are grouped in categories. Press SETUP to close the menu. 1 AV receiver 2 3 4 "Setup" 5 If you've connected your TV to the AV receiver with an HDMI cable, composite video and component video sources can be upconverted and output by the HDMI output.

(*) In order for the AV receiver to upconvert component input to HDMI output, the source output must be set to 480i/576i. @ @ @ @ @ @ If not, make the setting manually. @ @ @ @ The name of the button may differ depending on the router maker. @ @ Use a supplied remote controller for the setting. Press RECEIVER before using the remote controller. @ @ Press RETURN to return to the previous screen. For further information, see "Remote Controller". (→Page 8) 1 1 2 3 4 5 Turn on the AV receiver. @ @ @ @ @ @ 1. Press Receiver followed by Home on the remote controller.

2. Select "Setup" on the screen, and press ENTER. 3. Select "Hardware Setup", and press ENTER. 4. Select "Network (*1)", and press ENTER. @ @ @ @ (*2) The reaction may be slow. @ @ @ @ @ @ @ @ Press "WPS button" on the wireless LAN router, select "OK" on the TV screen, and press ENTER. (*) If you select "PIN Code", PIN code setting is available.

Use this setting in case WPS button is in the hard location to press, etc. In PIN code setting, register the displayed eight-digit PIN code with the wireless LAN router. For registration, see the instruction manual provided with the wireless LAN router. Manual setting Select SSID of your wireless LAN router from the list of SSID displayed on the screen, and press ENTER. Either of the following options is automatically displayed in conjunction with the wireless router setting. 5. Select "OK" on the next screen, and press ENTER. (*) Pressing Shift switches between uppercase and lowercase. Put the AV receiver to pairing mode When you press BLUETOOTH on the front panel of the AV receiver, Bluetooth indicator flashes and the AV receiver is put to pairing mode. • When establishing pairing with other Bluetooth-enabled device, press and hold down BLUETOOTH on the AV receiver until the Bluetooth indicator flashes.

The AV receiver can save up to ten pairing information. WPA/WPA2 method 1. Select "Password", and press ENTER. 2. Enter the Password (*) by using a key board displayed on the screen, select "OK", and press ENTER. 3. Select "OK" on the next screen, and press ENTER. (*) Pressing Shift switches between uppercase and lowercase. 2 WEP method 1. Select "Default key ID", and press ENTER.

2. Select "1" on the next screen. (If you change WEP key on the router side, select that number.) 3. Select "Password" on the next screen, and press ENTER. 4. Enter the Password (*) by using a key board displayed on the screen, select "OK", and press ENTER. Connecting to Bluetooth-enabled device Connect the AV receiver to the Bluetooth-enabled device from a close distance (approx. 1 m) while the indicator on the AV receiver is flashing. @ @ @ @ Select "OK" on the screen, and press ENTER.

@ @ @ @ • Audio is not output from the AV receiver if audio volume on the Bluetooth-enabled device is set small. 4 5 Connection Connection is started, and Wi-Fi indicator flashes on the left of the AV receiver display. When connected successfully, Wi-Fi indicator lights. If the indicator does not light, the connection was not made successfully. Make settings above again. Try the manual setting if the automatic setting does not work. For further information, see "Playback" www.onkyo.com/ Tel: 800-229-1687, 201-785-2600 http://www.us.

onkyo.com/ Tel: +49-8142-4401-0 http://www.eu.onkyo.com/ Tel: +44-(0)8712-00-19-96 (Hong Kong) Tel: 852-2429-3118 http://www.hk.onkyo.com/ (Mainland) Tel: 86-21-52131366 http://www.cn.onkyo.com/ -7- .



[You're reading an excerpt. Click here to read official ONKYO TX-NR828 user guide](http://yourpdfguides.com/dref/5225248)
<http://yourpdfguides.com/dref/5225248>