



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC DMR-BCT730EG. You'll find the answers to all your questions on the PANASONIC DMR-BCT730EG in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PANASONIC DMR-BCT730EG
User guide PANASONIC DMR-BCT730EG
Operating instructions PANASONIC DMR-BCT730EG
Instructions for use PANASONIC DMR-BCT730EG
Instruction manual PANASONIC DMR-BCT730EG

Panasonic

Operating Instructions
Blu-ray Disc™ Recorder
Model No. **DMR-BCT835**
DMR-BCT735
DMR-BCT730

DIGA
Blu-ray



Thank you for purchasing this product.
Please read these instructions carefully before using this product, and save this manual for future use.
• This unit is equipped with two CI/CI Plus slots. They can receive encrypted digital broadcast services.

Software (Firmware) Update



Blu-ray Disc technology and broadcast services continue to add new features. As they evolve, firmware updates may be required to support the latest features. Panasonic strives to continually update firmware as new technology is released. It's very important you install the latest updates to maintain proper operation of your unit.
For details, refer to "Software (Firmware) Update" (#101) or <http://panasonic.jp/updates/global/> (This site is in English only)

EG

VQT4W71



[You're reading an excerpt. Click here to read official PANASONIC DMR-BCT730EG user guide](http://yourpdfguides.com/dref/5330536)
<http://yourpdfguides.com/dref/5330536>

Manual abstract:

@@@It's very important you install the latest updates to maintain proper operation of your unit. Book 2 Safety precautions WARNING Unit • To reduce the risk of fire, electric shock or product damage, - Do not expose this unit to rain, moisture, dripping or splashing. - Do not place objects filled with liquids, such as vases, on this unit. - Do not repair this unit by yourself. refer servicing to qualified service personnel. - Do not let metal objects fall inside this unit. - Do not place heavy items on this unit. AC mains lead • To reduce the risk of fire, electric shock or product damage, - Ensure that the power supply voltage corresponds to the voltage printed on this unit. - Insert the mains plug fully into the socket outlet. - Do not pull, bend, or place heavy items on the lead.

- Do not handle the plug with wet hands. - Hold onto the mains plug body when disconnecting the plug. @@@ cAUTION Unit • This unit utilizes a laser. @@@ This unit may receive radio interference caused by mobile telephones during use. If such interference occurs, please increase separation between this unit and the mobile telephone.

□ This unit is intended for use in moderate climates. placement • Place this unit on an even surface. □ To reduce the risk of fire, electric shock or product damage, - Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure this unit is well ventilated. - Do not obstruct this unit's ventilation openings with newspapers, tablecloths, curtains, and similar items.

- Do not expose this unit to direct sunlight, high temperatures, high humidity, and excessive vibration. Replace only with the type recommended by the manufacturer. □ Mishandling of batteries can cause electrolyte leakage and may cause a fire. - Do not mix old and new batteries or different types at the same time. - Do not heat or expose to flame. - Do not leave the battery(ies) in a car exposed to direct sunlight for a long period of time with doors and windows closed. - Do not take apart or short circuit. - Do not recharge alkaline or manganese batteries. - Do not use batteries if the covering has been peeled off. - Remove batteries if you do not intend to use the remote control for a long period of time.

store in a cool, dark place. □ When disposing the batteries, please contact your local authorities or dealer and ask for the correct method of disposal. These may be subject to change. □ Do not use AC mains lead with other equipment. Indemnity concerning recorded content Panasonic does not accept any responsibility for damages directly or indirectly due to any type of problems that result in loss of recording or edited content (data), and does not guarantee any content if recording or editing does not work properly. Likewise, the above also applies in a case where any type of repair is made to the unit (including any other non-HDD related component). Restriction on use of unauthorized copied content This unit adopts the following technology for copyright protection.

Cinavia Notice This product uses Cinavia technology to limit the use of unauthorized copies of some commercially-produced film and videos and their soundtracks. When a prohibited use of an unauthorized copy is detected, a message will be displayed and playback or copying will be interrupted. More information about Cinavia technology is provided at the Cinavia Online Consumer Information Center at <http://www.cinavia.com>.

To request additional information about Cinavia by mail, send a postcard with your mailing address to: Cinavia Consumer Information Center, P. 55 - Copying from media other than HDD with DIRECT NAVIGATOR . 69 - Operations during music play . Playing back video Playing titles on the HDD . 104 - Switching the aspect ratio of the screen .

About descriptions in these operating instructions • These operating instructions are applicable to models DMR-BCT835, DMR-BCT735 and DMR-BCT730. The illustrations in these Operating Instructions show images of DMR-BCT835 unless otherwise indicated. Getting started Watching broadcasts Recording

Playing back video Editing video Copying video Photo and Music Network With Other Equipment Convenient functions Troubleshooting Reference Troubleshooting Troubleshooting guide . 113 - When you experience problems with Easy Network Setting . Book 6 Getting started HDD and media information For more details, refer also to the specifications.

(117) Recordable/playable contents (–: Impossible) Media type Built-in hard disk drive (HDD) §1 Standard symbol [HDD] Recordable contents • Video • AVCHD/AVCHD 3D • JPEG • MPO (3D photo) • MP3 • Video §2 • Playable contents External hard disk drive (USB HDD) §1 (9) [USB_HDD] – BD-Video [BD-V] BD-RE §1 [BD-RE] BD-R [BD-R] DVD-Video §5 [DVD-V] DVD-RAM §1 [RAM] – • Video • JPEG • MPO (3D photo) – • Video • AVCHD §3 • MPO (3D photo) • MP3 Video • Xvid • Video • MKV • AVCHD §3 DVD-R DVD-R DL [DVD-R] • • • Xvid • MKV JPEG MPO (3D photo) MP3 6 VQT4W71 DMR-BCT835_735_730EG_eng. Book 7 Getting started (–: Impossible) Media type DVD-RW §1 Standard symbol [DVD-RW] Recordable contents • Video – • Video – • Video – – Playable contents • AVCHD §3 +R/+R DL +RW §1 Audio CD (CD-DA) [+R] [+RW] • AVCHD §3 • AVCHD §3 • Music [CD] CD (including CD-R/RW) SD Cards §1 [SD] – • JPEG • MPO (3D photo) • Xvid • MKV JPEG MPO (3D photo) MP3 AVCHD/AVCHD 3D §3 MP4 • JPEG MPO (3D photo) AVCHD/AVCHD 3D §3, 4 MP4 • MPEG2 Xvid • MKV JPEG MPO (3D photo) MP3 USB memory [USB] – Playable contents as DLNA client Refer to “Playable contents”. (74) §1 §2 §3 §4 §5 Rewritable media It cannot be recorded directly. (Only compatible with copying from the built-in HDD) Recorded with AVCHD format compatible devices (Panasonic video camera, etc.). It may not be able to play back, add, or edit depending on the device. It cannot be played back directly from the USB HDD or USB memory. □ The producer of the disc can control how discs are played. So you may not always be able to control play as described in these operating instructions. read the disc's instructions carefully.



[You're reading an excerpt. Click here to read official PANASONIC DMR-BCT730EG user guide](http://yourpdfguides.com/dref/5330536)
<http://yourpdfguides.com/dref/5330536>

