



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC KX-DT321. You'll find the answers to all your questions on the PANASONIC KX-DT321 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PANASONIC KX-DT321
User guide PANASONIC KX-DT321
Operating instructions PANASONIC KX-DT321
Instructions for use PANASONIC KX-DT321
Instruction manual PANASONIC KX-DT321








Panasonic®

Quick Reference Guide
Digital Proprietary Telephone

Model No. **KX-DT321**

Thank you for purchasing a Digital Proprietary Telephone (DPT). Please read this manual carefully before using this product and save this manual for future use. For more details, please refer to the manuals of the PBX.

Accessories (included)*1

<input type="checkbox"/> Handset: 1 	<input type="checkbox"/> Handset Cord: 1 	<input type="checkbox"/> Stand: 1 
<input type="checkbox"/> Screws for wall: 2 	<input type="checkbox"/> Telephone Line Cord: 1 	

*1 For extra orders for the accessories, call toll-free: 1-800-332-5368.

Document Version 2009-03



[You're reading an excerpt. Click here to read official PANASONIC KX-DT321 user guide](http://yourpdfguides.com/dref/2684438)
<http://yourpdfguides.com/dref/2684438>

Manual abstract:

*KX-DT321 Thank you for purchasing a Digital Proprietary Telephone (DPT). Please read this manual carefully before using this product and save this manual for future use. For more details, please refer to the manuals of the PBX. Accessories (included)*1 Handset: 1 Handset Cord: 1 Stand: 1 Screws for wall: 2 Telephone Line Cord: 1 *1 For extra orders for the accessories, call toll-free: 1-800-332-5368. Document Version 2009-03 Location of Controls Controls Location of A B C D E F G P O N H I J K L M 2 Document Version 2009-03 Location of Controls A LCD (Liquid Crystal Display) with Backlight B*

AUTO DIAL/STORE: Used for System/Personal Speed Dialing or storing program changes. C AUTO ANS (Auto Answer)/ MUTE: Used to receive an incoming call in hands-free mode or mute the microphone/handset during a conversation. D INTERCOM: Used to make or receive intercom calls. E MESSAGE: Used to leave a message waiting indication or call back the party who left the message waiting indication. F REDIAL: Used to redial the last dialed number. G TRANSFER: Used to transfer a call to another party.

@@J HOLD: Used to place a call on hold. K SP-PHONE (Speakerphone): Used for performing hands-free operations. @@M Microphone: Used for hands-free conversations. N Flexible Buttons: Used to seize an CO line or perform a feature that has been assigned to the key. O PROGRAM: Used to enter and exit the personal programming mode.

*P Message/Ringer Lamp: When you receive a call, the lamp flashes red. When someone has left you a message, the lamp stays on red. Document Version 2009-03 3 Settings Settings Speaker volume While in a hands-free conversation Handset/Headset While using the handset or headset volume*1 Ringer volume*

*While on-hook or receiving a call Press Up to increase or Down to decrease the volume. LCD Contrast While on-hook PROGRAM AUTO DIAL STORE AUTO DIAL STORE PROGRAM Ring Tone (CO) PROGRAM OR INTERCOM Press 2 times. *2 AUTO DIAL PROGRAM STORE LCD Backlight While on-hook Automatic*3 PROGRAM AUTO DIAL Always ON STORE Always OFF AUTO DIAL STORE *1 PROGRAM If you hear your own voice through the handset or headset, decrease the volume.*

**2 The ring tone pattern of patterns 09 to 30 is the same as pattern 01. @@@@ (2 digits) C. Tone * Enter CO line access number before outside phone number. desired phone no. * (max. 32 digits) To dial AUTO DIAL personal speed dial no. (2 digits) STORE System Speed Dialing To dial AUTO DIAL system speed dial no. (3 digits) STORE Doorphone Call doorphone no. (2 digits) C. Tone During a Conversation Call Hold To hold HOLD C.*

Tone (CO) To retrieve a call at the holding extension / INTERCOM To retrieve an outside call from another extension (CO) Call Transfer TRANSFER C. Tone extension no. (CO) To an extension To an outside party outside phone no. 6 Document Version 2009-03 Features List Useful Features Multiple Party Conversation To add other parties during a conversation (i.e., conference) assigned as a (Conference) Conference button desired phone no. C. Tone Talk to the new party. assigned as a (Conference) Conference C. @@@@@ Tone AM PM To cancel C.

@@extension no. OR outside phone no. C. @@@@Mailbox Password * If you have no password, you can skip the last step. 8 Document Version 2009-03 Features List Leaving a message VPS extension no.*

From your own extension Mailbox Password From someone else's extension mailbox no. Mailbox Password* Leave a message * If you have no password, you can skip the last step. Enter the desired mailbox number To send the message immediately (KX-TVA series) (KX-TVS series) Follow the guidance To set the delivery time During playback Repeat Voice Guidance Exit · Consult your dealer for more details regarding feature numbers. · It is possible to assign flexible buttons as feature buttons. · Control panel/button names and descriptions can be found in "Location of Controls" on page 2.*

Document Version 2009-03 9 Connection Connection Note: In the illustration below, the telephone line cords are routed for wall mounting. When using the stand, refer to "Attaching the Stand" and "Cabling" on page 11 for telephone line cabling. <Back view> The telephone line cord (included) Connect to a PBX. Connect to a digital proprietary telephone -- Digital XDP connection Clamp Headset Recommended: KX-TCA86, KX-TCA91, KX-TCA92 Do not use a KX-T7090 headset. · Consult your dealer for more details about Digital XDP. CAUTION: When connecting a headset When connecting cords · Ensure that the headset cord is wound around the hook to prevent damage to the connector. · Ensure the cords are inserted in the grooves, and are clamped to prevent damage to the connectors. @@@@Remove the stand if it is attached. For information on removing the stand, refer to page 11. 2.

@@@@730 g [1.61 lb]). @@@@ · Wipe the unit with a soft cloth. @@ · Use only the correct Panasonic handset. · Do not disassemble this unit. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians. · If damage to the unit exposes any internal parts, immediately disconnect the cable or cord. · Never attempt to insert wires, pins, etc. into the vents or other holes of this unit.

Take special care to follow the safety suggestions listed below. @@Damp basements should also be avoided. @@These noise sources can interfere with the performance of the unit. @@@@ (3) Place the unit on a flat surface. 14 Document Version 2009-03 Important Information WARNING: TO PREVENT POSSIBLE FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

THIS HANDSET EARPIECE IS MAGNETIZED AND MAY RETAIN SMALL FERROUS OBJECTS. THE USE OF EXCESSIVE SOUND VOLUME THROUGH EARPHONES, HEADPHONES, OR HEADSETS MAY CAUSE HEARING LOSS. DISCONNECT THE TELEPHONE LINE CORD FROM THIS PRODUCT IF THIS PRODUCT EMITS SMOKE, AN ABNORMAL SMELL OR MAKES UNUSUAL NOISE. THESE CONDITIONS CAN CAUSE FIRE OR ELECTRIC SHOCK. CONFIRM THAT SMOKE HAS STOPPED AND CONTACT AN AUTHORIZED SERVICE CENTER.

IMPORTANT NOTICE: · Under power failure conditions, the DPT may not operate. @@@@DO NOT send the product to the Executive or Regional Sales offices. @@@@1. Read and understand all instructions. 2. Follow all warnings and instructions marked on this unit. 3. Unplug this unit from the main unit before cleaning. Do not use liquid or aerded to the telephone company. @@300 Ste.

350-B Suwanee, GA 30024-3186 If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved. Hearing Aid Compatibility: This telephone provides magnetic coupling for hearing aids. Compliance with TIA-1083 standard: Compatible with Hearing Aid T-Coil Telephone handsets identified with this logo have reduced noise and interference when used with T-Coil equipped hearing aids and cochlear implants.



[You're reading an excerpt. Click here to read official PANASONIC KX-DT321 user guide](http://yourpdfguides.com/dref/2684438)
<http://yourpdfguides.com/dref/2684438>

T TIA-1083 18 Document Version 2009-03 One screw here WALL MOUNTING TEMPLATE 1. Drive the screws into the wall as indicated. 2. Hook the unit onto the screw heads. Note: Make sure to set the print size to correspond with the size of this page. If the dimensions of the paper output still deviate slightly from the measurements indicated here, use the measurements indicated here. One screw at either point Document Version 2009-03 19 for base unit 83 mm (3-1/4 in) 100 mm (3-15/16 in) Panasonic Consumer Electronics Company, Division of Panasonic Corporation of North America One Panasonic Way Secaucus, New Jersey 07094 <http://www.panasonic.com/csd>

Copyright: This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd. © Panasonic Communications Co., Ltd. 2009 PSQX4696ZA-UU (A) KK0309YH0 (M) .



[You're reading an excerpt. Click here to read official PANASONIC KX-DT321 user guide](http://yourpdfguides.com/dref/2684438)
<http://yourpdfguides.com/dref/2684438>