

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC KX-T7730. You'll find the answers to all your questions on the PANASONIC KX-T7730 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

> **User manual PANASONIC KX-T7730 User guide PANASONIC KX-T7730** Operating instructions PANASONIC KX-T7730 **Instructions for use PANASONIC KX-T7730 Instruction manual PANASONIC KX-T7730**

# **Panasonic**

Proprietary Telephones

# Quick Reference Guide

KX-T7720/KX-T7730 KX-T7731/KX-T7735 Model KX-T7736/KX-T7750

### Important Information

### When you ship the product:

Carefully pack and send it prepaid, adequately insured and preferably in the original carton. Attach a postage-paid letter, detailing the symptom to the outside of the carton. DO NOT send the product to the Executive or Regional Sales offices. They are NOT equipped to make repairs.

# Product service:

Panasonic Servicenters for this product are listed in the servicenter directory. Consult your authorized Panasonic dealer for detailed instructions.

WARNING:
TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

THIS HANDSET EARPIECE IS MAGNETIZED AND MAY RETAIN SMALL FERROUS

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in an emergency.

In this manual, the suffix of each model number is omitted.

# Included Accessories: for extra orders, call toll free 1-800-332-5368

For your future reference	
SERIAL NO(found on the bottom of the unit)	DATE OF PURCHASE
NAME OF DEALER	
DEALER'S ADDRESS	
DEALER'S TEL. NO.	21

Please read this manual before using and save for future reference.



You're reading an excerpt. Click here to read official PANASONIC KX-T7730 user guide

http://yourpdfguides.com/dref/2422637

### Manual abstract:

Attach a postage-paid letter, detailing the symptom to the outside of the carton. DO NOT send the product to the Executive or Regional Sales offices. They are NOT equipped to make repairs. Product service: Panasonic Servicenters for this product are listed in the servicenter directory. Consult your authorized Panasonic dealer for detailed instructions. WARNING: TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE. THIS HANDSET EARPIECE IS MAGNETIZED AND MAY RETAIN SMALL FERROUS OBJECTS. IMPORTANT NOTICE: Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available

for use in an emergency. Note: In this manual, the suffix of each model number is omitted. Included Accessories: for extra orders, call toll free 1-800-332-5368 Handset . . . . .

..... 1 Handset Cord ..... 1 Stand .
.... 1 Telephone Line Cord ..... 1 Stand .
.....
..... 1 Overlay .....

. 1 (Other than KX-T7720, KX-T7750) For your future reference DATE OF PURCHASE SERIAL NO. (found on the bottom of the unit) NAME OF DEALER DEALER'S ADDRESS DEALER'S TEL. NO. Please read this manual before using and save for future reference.

Features List Outside (CO) Line button Off-hook Desired Feature On-hook Programmable Feature button Talk Feature number \* "Location of Controls" is shown on page 8. Operation Making Calls To an extension To an external party phone no. Calling Redial To program extension no. KX-TA624 KX-TA1232

One-Touch Dialing (Check the type of your Main Unit.) phone no.

To dial assigned as a One-Touch Dialing button Calling an operator To set KX-TA624 3 KX-TA1232 personal speed dial no. (Check the type of your Main Unit.) Speed Dialing (Personal) desired no. @@extension no. @@@@@KX-TA624 For outside calls Set Cancel For intercom calls Set Call Waiting Receiver KX-TA1232 Set Cancel Cancel (Check the type of your Main Unit.) To talk to the new party While hearing the Call Waiting tone Holding a current status Terminating a current status During a Conversation Holding To retrieve a call at the holding extension Holding a call To retrieve an outside call from another extension Holding a call exclusively Holding To retrieve a call on exclusive hold Screened extension no. To an extension To an external party (System programming is required.) Transferring a call phone no. Unscreened to an extension extension no. Wait for an answer.

Announce. 4 Features List Desired Feature Operation Useful Features To page All extensions Group group no. KX-TA624 All external speakers All extensions & external speakers Announce. KX-TA1232 All external speakers Paging Specific external speaker external speaker no. All extensions & external speakers (Check the type of your Main Unit.) To answer an announced page From a telephone speaker From an external speaker KX-TA624 external speaker no. (Check the type of your Main Unit.) KX-TA1232 Three-party conference To set third party's no. KX-TA624 message no. KX-TA1232 message no. parameter (if required) parameter (if required) Setting Absent Message To cancel (Check the type of your Main Unit.) KX-TA624 KX-TA1232 (Check the type of your Main Unit.) 5 Features List Desired Feature Operation Useful Features KX-TA624 For Log-In For Log-Out Log-In/Log-Out KX-TA1232 For Log-In For Log-Out (Check the type of your Main Unit.) KX-TA624 All calls extension no. Busy/No answer extension no.

To an outside line line access phone no. code Follow Me your extension no. Cancel Follow Me your extension no. Cancel KX-TA1232 Forwarding a call All calls extension no. Busy extension no.

No answer extension no. Busy/No answer extension no. To an outside line line access phone no. code Follow Me your extension no. Cancel Follow Me your extension no. Cancel (Check the type of your Main Unit.) 6 Features List Desired Feature Operation Useful Features KX-TA624 # Set Cancel Do Not Disturb (DND) # KX-TA1232 Set Cancel (Check the type of your Main Unit.) KX-TA624 (Lock code is 4 digits.) 7 7 7 lock code lock code lock code lock code lock code with Locking your extension 7 # KX-TA1232 (Lock code is 3 digits.) 7 7 7 lock code lock code lock Check the type of your Main Unit.

) Clearing the setting 7 7 9 9 # 0 KX-TA624 KX-TA1232 (Check the type of your Main Unit.) \* Consult your dealer for more details on the operations above.\*
7 Location of Controls 2 RINGER 0 1 BACKLIGHT LCD (Liquid Crystal Display) 18 RINGER Volume Selector/ BACKLIGHT Illumination Selector 17 1 2 3 4 5 6 7 8 9 14 16 15 10 11 12 13 Headset Jack Microphone \* The KX-T7750 does not have a microphone. \* The backlit display is only available on the KX-T7730/7731/7735/7736. \* The headset is an option. Recommended headsets are KX-TCA91 and KX-TCA92. 1 2 3 4 PROGRAM: Used to enter and exit the programming mode. CONF (Conference): Used to establish a multiple party conversation. INTERCOM: Used to make or receive intercom calls. FWD/DND (Call Forwarding/Do Not Disturb): Used to perform Call Forwarding or Do Not Disturb.

FLASH/RECALL: Used for External Feature Access or to disconnect the current call and make another call without hanging up. 7 6 AUTO ANS (Auto Answer) (Other than KX-T7750): Used to receive an incoming call in the hands-free mode. @@@@AUTO DIAL/STORE: Used for speed dialing or storing program changes. @@TRANSFER: Used to transfer a call to another party. HOLD: Used to place a call on hold.


SP-PHONE (Other than KX-T7750): Used for the handsfree operation. MONITOR (KX-T7750 only): Used for handsfree dialing. You can monitor the other party's voice handsfree. @@VOLUME KEY (KX-T7720/7750): Used to adjust the volume. @@@@Pressing this button seizes an idle outside line automatically.

(Button assignment is required.) Also used as feature buttons. @@@@@@@@@@@@@@@@@@@@(e.g., S-Double, Call Waiting Tone1). @@@@@@@@@@@f requested, this number must be provided to the telephone company. @@@@See Installation Instructions for details. @@But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes to it's facilities, equipment, operations or procedures that could affect the operation of the equipment.

If this happens the telephone company will provide advance notice so you can make the necessary modifications to maintain uninterrupted service. If trouble is experienced with this equipment KX-T7731/36, for repair or warranty information, please contact Panasonic Services Company BTS Center 1225 Northbrook Parkway Suite 1-216 Suwanee GA 30024 If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

You're reading an excerpt. Click here to read official PANASONIC



Connection to party line service is subject to state tariffs. (Contact the state public utility commission, public service commission or corporation commission for information.) This equipment is hearing aid compatible. 11 Exhibit J - Customer Information Data Equipment The table below shows which jacks are associated with which modes of operation: Mode of Operation Permissive Programmable Fixed Loss Loop USOC Jack KX-TA624 RJ11 RJ41S and RJ45S RJ41S KX-TA1232 RJ11 and RJ14C RJ41S and RJ45S RJ41S Systems Facility Interface Codes (FIC), Service Order Codes (SOC), USOC Jack Codes and Ringer Equivalence Numbers (REN) are shown in the table below for each port whe the dealer or an experienced radio/TV technician for help. CAUTION: To assure continued compliance with FCC rules, do not make any unauthorized modifications. When programming emergency numbers and/or making test calls to emergency numbers: 1) Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up. 2) Perform such activities in the off peak hours, such as early morning hours or late evenings. If there is any problem, unplug the extension and connect a known working phone.

@@@@@@@Do not use benzine, thinner, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth. Do not disassemble this unit. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.

When a failure occurs which exposes any internal parts, disconnect the telephone line and mains supply immediately and return the unit to your maintainer. This telephone provides magnetic coupling for hearing aids. 14 Panasonic Consumer Electronics Company, Division of Matsushita Electric Corporation of America One Panasonic Way, Secaucus, New Jersey 07094 www.panasonic.com Panasonic Sales Company ("PSC"), Division of Matsushita Electric of Puerto Rico, Inc.

Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park, Carolina, Puerto Rico 00985 2002 Panasonic Communications Co., Ltd. All Rights Reserved.

Printed in the United Kingdom PSQW1921WA KU0902YS3054.



You're reading an excerpt. Click here to read official PANASONIC KX-T7730 user guide

http://yourpdfguides.com/dref/2422637