




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC KX-TGA470. You'll find the answers to all your questions on the PANASONIC KX-TGA470 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual PANASONIC KX-TGA470**  
**User guide PANASONIC KX-TGA470**  
**Operating instructions PANASONIC KX-TGA470**  
**Instructions for use PANASONIC KX-TGA470**  
**Instruction manual PANASONIC KX-TGA470**



[You're reading an excerpt. Click here to read official PANASONIC KX-TGA470 user guide](http://yourpdfguides.com/dref/4206876)  
<http://yourpdfguides.com/dref/4206876>

**Manual abstract:**

fm Page 1 Wednesday, November 16, 2011 10:51 AM Installation Manual Additional Digital Cordless Handset Model No. KX-TGA470 Thank you for purchasing a Panasonic product. This unit is an additional handset compatible with the following series of Panasonic Digital Cordless Phone: KX-TG4731/KX-TG4741/KX-TG4751/KX-TG4761/ KX-TG4771/KX-TG7731/KX-TG7741 (The corresponding models are subject to change without notice.) You must register this handset with your base unit before it can be used. This installation manual describes only the steps needed to register and begin using the handset. Please read the base unit's operating instructions for further details. Charge the batteries for about 7 hours before initial use. Please read this installation manual before using the unit and save it for future reference. @ or Puerto Rico. @\*4 PNKE1132Z1: Black Note: L Please read the base unit's operating instructions for additional/ replacement accessories.

Optional headsets: KX-TCA60, KX-TCA93, KX-TCA400, KX-TCA430 2 For assistance, please visit [http://www.panasonic.com/help\\_TGA470\(e\)](http://www.panasonic.com/help_TGA470(e)) fm Page 3 Wednesday, November 16, 2011 10:51 AM Setting up Connections/Wall mounting 25.4 mm (1 inch) Screws (Not supplied) To power outlet Hooks Note: L Use only the supplied Panasonic AC adaptor PNLV226.

L The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.) L Make sure that the wall and the fixing method are strong enough to support the weight of the unit. Battery installation/Battery charging Important: L Use the supplied rechargeable batteries. @L Wipe the battery ends (S, T) with a dry cloth.

L Avoid touching the battery ends (S, T) or the unit contacts. L Confirm correct polarities (S, T). L USE ONLY Ni-MH batteries AAA (R03) size. @@@@L Depending on the base unit, a registration tone sounds. L If all registered handsets start ringing, press {LOCATOR} again to stop, then repeat this step. 2 Handset: Place the handset on the base unit or charger, then wait until a long beep sounds and w is displayed. Note: L If an error tone sounds, or if \_ is displayed, register the handset according to the base unit's operating instructions. 4 For assistance, please visit [http://www.panasonic.com/help\\_TGA470\(e\)](http://www.panasonic.com/help_TGA470(e)).

fm Page 5 Wednesday, November 16, 2011 10:51 AM Display language 1 {MENU} (1) 2 {r}: Select the desired setting. s {SAVE} 3 {OFF} Belt clip N To attach N To remove For assistance, please visit [http://www.panasonic.com/help\\_5\\_TGA470\(e\)](http://www.panasonic.com/help_5_TGA470(e)) fm Page 6 Wednesday, November 16, 2011 10:51 AM For your safety To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product. WARNING Power connection L Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire. L Regularly remove any dust, etc. @@Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.

@@These conditions can cause fire or electric shock. @@@@@@@Ensure that the AC outlet is installed near the product and is easily accessible. Battery L We recommend using the supplied batteries or additional/replacement batteries noted on page 2 for replacement battery information. USE ONLY rechargeable Ni-MH batteries AAA (R03) size. L Do not mix old and new batteries.

L Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte is toxic and may be harmful if swallowed. L Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets, or keys to touch the batteries, otherwise a short circuit 6 For assistance, please visit <http://www>.

panasonic.com/help\_TGA470(e) fm Page 7 Wednesday, November 16, 2011 10:51 AM may cause the batteries and/or the conductive material to overheat and cause burns. L Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual. L Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger). Failure to follow these instructions may cause the batteries to swell or explode. @@@@@2. @3. Use only the power cord and batteries indicated in this manual.

Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions. @@Move away from the electrical appliances. @@Dispose of used batteries according to the instructions. @@@@@@@ Perform such activities in the off-peak hours, such as early morning or late evenings. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this phone. CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. @@@@@@@ Increase the separation between the equipment and receiver. @@@@FCC RF Exposure Warning: L This product complies with FCC radiation exposure limits set forth for an uncontrolled environment. L This handset may not be collocated or operated in conjunction with any other antenna or transmitter. L The handset may be carried and operated with only the specific provided beltclip.

Other non-tested belt-clips or similar body-worn accessories may not comply and must be avoided. Notice: L FCC ID can be found inside the battery compartment or on the bottom of the unit. Compliance with TIA-1083 standard: Compatible with Hearing Aid T-Coil Telephone handsets identified with this logo have reduced noise and interference when used with T-Coil equipped hearing aids and cochlear implants. T TIA-1083 For assistance, please visit <http://www.panasonic>.

com/help\_9\_TGA470(e) fm Page 10 Wednesday, November 16, 2011 10:51 AM Notice L This product is designed for use in the United States of America. @@@@@@@L L 10 For assistance, please visit [http://www.panasonic.com/help\\_TGA470\(e\)](http://www.panasonic.com/help_TGA470(e)) fm Page 11 Wednesday, November 16, 2011 10:51 AM If your product is not working properly. . . 1 Reconnect AC adaptor to the base unit. 2 Check if telephone line cord is connected.

3 Use rechargeable Ni-MH batteries. (Alkaline/Manganese/Ni-Cd batteries CANNOT be used.) IMPORTANT! 4 Read troubleshooting page in the base unit's Operating Instructions. Visit our Web site: <http://www.panasonic.com/help> L FAQ and troubleshooting hints are available. One Panasonic Way, Secaucus, New Jersey 07094 © Panasonic System Networks Co.



[You're reading an excerpt. Click here to read official PANASONIC KX-TGA470 user guide](http://yourpdfguides.com/dref/4206876)  
<http://yourpdfguides.com/dref/4206876>

, Ltd. 2011 For assistance, please visit <http://www.panasonic.com>.

*com/help 11 TGA470(sp).fm Page 1 Wednesday, November 16, 2011 11:32 AM Manual de instalación Auricular Inalámbrico Digites de operación de la unidad base. (4) TGA470(sp).fm Page 5 Wednesday, November 16, 2011 11:32 AM Idioma de la pantalla 1 {MENU} (11) 2 {r}: Seleccione la configuración deseada. s {GUARDA} 3 {OFF} Sujetador para cinturón N Para colocarlo N Para retirarlo (5) .*



[You're reading an excerpt. Click here to read official PANASONIC  
KX-TGA470 user guide  
<http://yourpdfguides.com/dref/4206876>](http://yourpdfguides.com/dref/4206876)