



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC KX-TGA660. You'll find the answers to all your questions on the PANASONIC KX-TGA660 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PANASONIC KX-TGA660
User guide PANASONIC KX-TGA660
Operating instructions PANASONIC KX-TGA660
Instructions for use PANASONIC KX-TGA660
Instruction manual PANASONIC KX-TGA660



[You're reading an excerpt. Click here to read official PANASONIC KX-TGA660 user guide](http://www.panasonic.com/help)
<http://yourpdfguides.com/dref/3973506>

Manual abstract:

fm Page 1 Friday, November 19, 2010 2:22 PM Installation Manual Additional Digital Cordless Handset Model No. KX-TGA660 Thank you for purchasing a Panasonic product. This unit is an additional handset compatible with the following series of Panasonic Digital Cordless Phone: KX-TG4131/KX-TG6591/KX-TG6631/KX-TG6641/ KX-TG7621/KX-TG7641 You must register this handset with your base unit before it can be used. This installation manual describes only the steps needed to register and begin using the handset. Please read the base unit's operating instructions for further details. Charge the batteries for about 7 hours before initial use. Please read this installation manual before using the unit and save it for future reference. For assistance, visit our Web site: <http://www.panasonic.com/help> for customers in the U.

*S.A. or Puerto Rico. Printed in Malaysia PNQX3161ZA TT1110MG0 TGA660(e).fm Page 2 Friday, November 19, 2010 2:22 PM Accessory information Supplied accessories Accessory item/Order number Charger*1 AC adaptor/PNLV226Z Rechargeable batteries/HHR-4DPA Handset cover Belt clip*4 *2, *3 Quantity 1 1 2 1 1 *1 PNLC1017ZB: Black, PNLC1017ZM: Metallic gray *2 PNYNTGA660BR: Black, PNYNTGA660MR: Metallic gray *3 The handset cover comes attached to the handset.*

**4 PNKE1098Z1: Black, PNKE1098Z2: Metallic gray Note: L Please read the base unit's operating instructions for additional/ replacement accessories. Optional headsets: KX-TCA60, KX-TCA93, KX-TCA94, KX-TCA400, KX-TCA430 2 For assistance, please visit <http://www.panasonic.com/help> TGA660(e).fm Page 3 Friday, November 19, 2010 2:22 PM Setting up Connections/Wall mounting 25.*

4 mm (1 inch) Screws (Not supplied) (120 V AC, 60 Hz) Hooks Note: L Use only the supplied Panasonic AC adaptor PNLV226. L The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.) L Make sure that the wall and the fixing method are strong enough to support the weight of the unit. Battery installation/Battery charging Important: L Use the supplied rechargeable batteries. @L Wipe the battery ends (S, T) with a dry cloth. L Avoid touching the battery ends (S, T) or the unit contacts. L Confirm correct polarities (S, T). L USE ONLY Ni-MH batteries AAA (R03) size. @@@@Note: L If an error tone sounds, or if _ is displayed, register the handset according to the base unit's operating instructions.

4 For assistance, please visit <http://www.panasonic.com/help> TGA660(e).fm Page 5 Friday, November 19, 2010 2:22 PM Display language 1 {MENU} (11) 2 {r}: Select the desired setting. s {SAVE} 3 {OFF} Belt clip N To attach N To remove For assistance, please visit <http://www.panasonic.com/help> 5 TGA660(e).fm Page 6 Friday, November 19, 2010 2:22 PM For your safety To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product. WARNING Power connection L Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.

L Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire. L Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise.

These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact the Panasonic Call Center at 1-800-211- PANA (1-800-211-7262). Installation L To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture. L Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

CAUTION Installation and location L The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible. Battery L We recommend using the supplied batteries or additional/replacement batteries noted on page 2 for replacement battery information. USE ONLY rechargeable Ni-MH batteries AAA (R03) size. L Do not mix old and new batteries. L Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte is toxic and may be harmful if swallowed. L Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets, or keys to touch the batteries, otherwise a short circuit 6 For assistance, please visit <http://www>.

[panasonic.com/help](http://www.panasonic.com/help) TGA660(e).fm Page 7 Friday, November 19, 2010 2:22 PM may cause the batteries and/or the conductive material to overheat and cause burns. @@@@Do not tamper with the base unit (or charger). @@@@ @ @. @ @3. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

@ @ Move away from the electrical appliances. @ @ Dispose of used batteries according to the instructions. @ @ @ @ @ @ @ @ @ @ @ @ @ @ @ This device complies with Part 15 of the FCC Rules. @ @ @ @ These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this 8 For assistance, please visit <http://www.panasonic.com/help> TGA660(e).fm Page 9 Friday, November 19, 2010 2:22 PM equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. FCC RF Exposure Warning: L This product complies with FCC radiation exposure limits set forth for an uncontrolled environment. L This handset may not be collocated or operated in conjunction with any other antenna or transmitter. L The handset may be carried and operated with only the specific provided beltclip. Other non-tested belt-clips or similar body-worn accessories may not comply and must be avoided. Notice: L FCC ID can be found inside the battery compartment or on the bottom of the unit. @ @ @ @ @ @ @ @ L Este producto está diseñado para usarse en los Estados Unidos de América.



[You're reading an excerpt. Click here to read official PANASONIC KX-TGA660 user guide](http://yourpdfguides.com/dref/3973506)

<http://yourpdfguides.com/dref/3973506>

La venta o el empleo de este producto en ciertos países puede constituir violación de la legislación local.

L L 10 For assistance, please visit <http://www.panasonic.com/help> TGA660(e).fm Page 11 Friday, November 19, 2010 2:22 PM If your product is not working properly. . . 1 Reconnect AC adaptor to the base unit. 2 Check if telephone line cord is connected. 3 Use rechargeable Ni-MH batteries.

(Alkaline/Manganese/Ni-Cd batteries CANNOT be used.

) IMPORTANT! 4 Read troubleshooting page in the base unit's Operating Instructions. Visit our Web site: <http://www.panasonic.com/help> L FAQ and troubleshooting hints are available. One Panasonic Way, Secaucus, New Jersey 07094 © Panasonic System Networks Co.

, Ltd. 2010 For assistance, please visit <http://www.panasonic.com/help> 11 TGA660(sp).fm Page 1 Friday, November 19, 2010 1:36 PM Manual de instalación Auricular Inalámbrico Digital Adicional Motrucciones de operación de la unidad base.

(4) TGA660(sp).fm Page 5 Friday, November 19, 2010 1:36 PM Idioma de la pantalla 1 {MENU} (11) 2 {r}: Seleccione la configuración deseada. s {GUARDA} 3 {OFF} Sujetador para cinturón N Para colocarlo N Para retirarlo (5).



[You're reading an excerpt. Click here to read official PANASONIC](http://yourpdfguides.com/dref/3973506)

[KX-TGA660 user guide](http://yourpdfguides.com/dref/3973506)

<http://yourpdfguides.com/dref/3973506>