




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC KX-TGDA20. You'll find the answers to all your questions on the PANASONIC KX-TGDA20 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PANASONIC KX-TGDA20  
User guide PANASONIC KX-TGDA20  
Operating instructions PANASONIC KX-TGDA20  
Instructions for use PANASONIC KX-TGDA20  
Instruction manual PANASONIC KX-TGDA20



[You're reading an excerpt. Click here to read official PANASONIC KX-TGDA20 user guide](http://yourpdfguides.com/dref/5646268)  
<http://yourpdfguides.com/dref/5646268>

**Manual abstract:**

) You must register this handset with your base unit before it can be used. This installation manual describes only the steps needed to register and begin using the handset. Please read the base unit's operating instructions for further details. Please read this installation manual before using the unit and save it for future reference. For assistance, visit our Web site: <http://www.panasonic.com/help> for customers in the U. Pdf 1 2013/11/14 15:24:43 Installation

Accessory information Supplied accessories Accessory item/Order number Charger/PNLC1056ZN Rechargeable batteries/HHR-4DPA Handset cover\*1/PNYNTGDA20NR Belt clip/PNKE1054Z4 \*1 The handset cover comes attached to the handset. Quantity 1 2 1 1 Note: R Please read the base unit's operating instructions for additional/replacement accessories. Setting up Connections/Wall mounting Connect the AC adaptor to the power outlet. Drive the screws 1 (not supplied) into the wall, if necessary. (It is normal for the adaptor to feel warm during use.) R Make sure that the wall and the fixing method are strong enough to support the weight of the unit. For replacement, we recommend using the Panasonic rechargeable batteries noted on page 2. R Confirm correct polarities ( , Charge for about 7 hours.

r Confirm Charging is displayed (2). Handset: Place the handset on the base unit or charger, then wait until a long beep is displayed. Sounds and Note: is displayed, register the handset according to R If an error tone sounds, or if the base unit's operating instructions. For assistance, please visit <http://www>. Pdf 3 2013/11/14 15:24:43 Installation Display language 1 MMENUN #110 2 MbN: Select the desired setting. A MSAVEN a MOFFN For your safety To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product. WARNING Power connection R Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire. r Regularly remove any dust , etc. From the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire. R Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact us at <http://www>.

panasonic.com/contactinfo Installation R To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture. R Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident. CAUTION Installation and location R The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible. Battery R We recommend using the supplied batteries or additional/replacement batteries noted on page 2 for replacement battery information. uSE ONLY rechargeable Ni-MH batteries AAA (R03) size. R Do not mix old and new batteries. Pdf 4 2013/11/14 15:24:44 Installation R Do not open or mutilate the batteries.

Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte is toxic and may be harmful if swallowed. R Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets, or keys to touch the batteries, otherwise a short circuit may cause the batteries and/or the conductive material to overheat and cause burns. R Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual.

R Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger). Failure to follow these instructions may cause the batteries to swell or explode. Attention: A nickel metal hydride battery that is recyclable powers the product you have purchased. @@@@ @ 2. @ @ 3. Use only the power cord and batteries indicated in this manual. Check with local codes for possible special disposal instructions. @@ Move away from the electrical appliances. @@ Dispose of used batteries according to the instructions. For assistance, please visit <http://www>. @@ R Do not use benzene, thinner, or any abrasive powder. @@@@ @ 316. @@@@ @@@@ @@@@ @@@@ This device complies with Part 15 of the FCC Rules. @@ Privacy of communications may not be ensured when using this phone.

@@@@@@@@@ However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. FCC RF Exposure Warning: R This product complies with FCC radiation exposure limits set forth for an uncontrolled environment. R This handset may not be collocated or operated in conjunction with any other antenna or transmitter. R The handset may be carried and operated with only the specific provided belt-clip. Other non-tested belt-clips or similar body-worn accessories may not comply and must be avoided. Notice: R FCC ID can be found inside the battery compartment or on the bottom of the unit.

Compliance with TIA-1083 standard Compatible with Hearing Aid T-Coil Telephone handsets identified with this logo have reduced noise and interference when used with T-Coil equipped hearing aids and cochlear implants. Pdf 7 2013/11/14 15:24:44 Installation Notice: L This product is designed for use in the United States of America. Sale or use of this product in other countries may violate local laws. Pdf 8 2013/11/14 15:24:44 Appendix Customer services Customer Services Directory (United States and Puerto Rico) Obtain Product Information and Operating Assistance; locate your nearest Dealer or Service Center; purchase Parts and Accessories; or make Customer Service and Literature requests by visiting our Web Site at: <http://www.com/contactinfo> For hearing or speech impaired TTY users, TTY: 1-877-833-8855 Accessory Purchases (United States and Puerto Rico) Purchase Parts, Accessories and Owner's Manual online for all Panasonic Products by visiting our Web Site at: <http://www>.

) For hearing or speech impaired TTY users, TTY: 1-866-605-1277 For assistance, please visit <http://www>.



[You're reading an excerpt. Click here to read official PANASONIC](#)

[KX-TGDA20 user guide](#)

<http://yourpdfguides.com/dref/5646268>

Pdf 9 2013/11/14 15:24:44 Appendix Warranty (For United States and Puerto Rico) Panasonic Telephone Products Limited Warranty Limited Warranty Coverage If your product does not work properly because of a defect in materials or workmanship, Panasonic Corporation of North America (referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase (âLimited Warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished equivalent value product, or (c) refund your purchase price. The decision to repair, replace or refund will be made by the warrantor. Parts Labor One (1) Year One (1) Year During the "Labor" Limited Warranty period there will be no charge for labor. During the "Parts" Limited Warranty period, there will be no charge for parts. @@@@Mail-In Service--Online Online Repair Request To submit a new repair request and for quick repair status visit our Web Site at <http://www.panasonic.com/repair> When shipping the unit carefully pack in a padded shipping carton, include all accessories, and send it prepaid. Include a letter detailing the complaint, a return address and provide a day time phone number where you can be reached. Keep the tracking number for your records. A copy of valid registered receipt is required under the 1 year parts and labor Limited Warranty. For Limited Warranty service for headsets if a headset is included with this product please follow instructions above. The Limited Warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, bug infestation, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, .



[You're reading an excerpt. Click here to read official PANASONIC KX-TGDA20 user guide](#)  
<http://yourpdfguides.com/dref/5646268>