



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PHILIPS DVP2880. You'll find the answers to all your questions on the PHILIPS DVP2880 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual PHILIPS DVP2880**  
**User guide PHILIPS DVP2880**  
**Operating instructions PHILIPS DVP2880**  
**Instructions for use PHILIPS DVP2880**  
**Instruction manual PHILIPS DVP2880**

For product support, visit  
 Para obtener asistencia técnica, visite  
 Pour en savoir plus sur l'assistance sur les produits, visitez le site

[www.hd.philips.com](http://www.hd.philips.com)

DVP2880



|                      |    |                    |    |
|----------------------|----|--------------------|----|
| User manual          | 7  | Manual del usuario | 25 |
| Manuel d'utilisation | 15 |                    |    |

EN: For further assistance, call the customer support service in your country.  
 • To obtain assistance in the U.S.A., Canada, Puerto Rico, or the U.S. Virgin Islands, contact Philips Customer Care Center at 1-866-319-8744  
 • To obtain assistance in Mexico, contact Philips Customer Care Center at 01 888 584 6288

ES: Para obtener más información, llame al servicio de soporte al cliente de su país.  
 • Para obtener asistencia en los Estados Unidos, en Canadá, Puerto Rico o en las Islas Vírgenes de los Estados Unidos, comuníquese con el Centro de atención al cliente de Philips al 1-866-319-8744  
 • Sólo para México: CENTRO DE ATENCIÓN A CLIENTES LAD A, 01 888 584 62 88 Sólo Para México.

FR: Pour obtenir de l'aide supplémentaire, communiquez avec le centre de service à la clientèle de votre pays.  
 • Pour obtenir de l'aide aux États-Unis, au Canada, à Puerto Rico ou aux îles Vierges américaines, communiquez avec le centre de service à la clientèle Philips au 1-866-319-8744  
 • Pour obtenir l'aide au Mexique, contactez le centre de soin de client de Philips à 01 888 584 62 88

For Product recycling info in aese, please visit - [www.recycle.philips.com](http://www.recycle.philips.com)  
 Para obtener información de productos reciclaje, por favor visite - [www.recycle.philips.com](http://www.recycle.philips.com)  
 Para obtener información de productos reciclaje, por favor visite - [www.recycle.philips.com](http://www.recycle.philips.com)

P&F USA, Inc.

**PHILIPS**



[You're reading an excerpt. Click here to read official PHILIPS DVP2880 user guide](http://yourpdfguides.com/dref/5096644)  
<http://yourpdfguides.com/dref/5096644>

**Manual abstract:**

Com User manual Manuel d'utilisation 7 15 Manual del usuario 25 EN: For further assistance, call the customer support service in your country. Indb 1 2013/1/11 15:00:16 1 Hookup and play EN FR ES Before you connect this DVD player, read and understand all accompanying instructions. HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI licensing LLC in the United States and other countries. manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. Indb 6 2013/1/11 15:00:21 1 Hookup and play □ 2 Use your DVD player □ Basic play control □ Video options □ Control photo play □ Repeat play □ Skip play □ Use Philips EasyLink □ 2-6 8 8 9 9 9 9 10 10 11 11 11 12 13 14 3 Change settings □ General (sleep, standby. Indb 7 2013/1/11 15:00:21 English Contents 2 Use your DVD player Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www. During play, press the following buttons to control the player. Access more options during video play. Skip to the previous or next track, chapter or file.

Fit the picture display to the TV screen. Indb 8 2013/1/11 15:00:23 During video play, press OPTIONS to access the following options. □ [Info]: Display the current play information. □ [PBC]: Display or skip the content menu for VCD and SVCD. @@» The repeat play of the marked section starts.

To cancel repeat play, press REPEAT/REPEAT A-B until [Off] is displayed. @@@@Skip play You can skip play to a specific title, chapter or track. @@ press OK. » The play skips to the selected title, chapter or track. OK Repeat play During play, press REPEAT/REPEAT A-B repeatedly to select a repeat play option.

@@@Philips does not guarantee 100% interoperability with all HDMI CEC devices. 1 2 3 4 Connect the HDMI CEC compliant devices through HDMI, and turn on the HDMI CEC operations on the TV and other connected devices (see the user manual of the TV or other devices for details). 3 Change settings This section helps you change the settings of this player. 1 2 General Disc Setup One Touch Play When you play a disc on this player, the TV automatically switches to the correct video input source. One Touch Standby When a connected device (for example TV) is put to standby with its own remote control, this player is put to standby automatically. 3 Video Audio Preference Disc Lock OSD Language Sleep Timer Auto Standby Unlock English Off On Note •• You cannot change a menu option that is grayed out. ••To access [Preference], stop the disc play. □•To return to the previous menu, press . To play a locked disc, you need to input your password: press to enter a digit, and press / to change a digit position. @@ • [Auto Standby]: Enable or disable auto standby.

@@□ [TV System]: Select a TV system that matches your TV. By default, this setting matches the common TVs in your country. @@@@Applicable only when both a disc and a TV support this feature. @@@@ • [Wide Screen]: Select a display format for wide screen videos. □ [EasyLink Setup]: See "Use your DVD player" > "Use Philips EasyLink" for details. Note ••Night mode is only available for Dolby encoded DVD discs. □ [Analogue Output]: Select an audio format for sound output when this player is connected through the AUDIO OUT L/R connectors. □ [Digital Audio]: Select an audio format for sound output when this player is connected through the COAXIAL connector. The higher the sampling rate, the better the sound quality. [LPCM Output] is enabled only when [PCM Only] is selected under [Digital Output].

@@@@@□ [PBC]: Display or skip the content menu for VCD and SVCD. @@@@□ [Version Info]: Display the software version for this player. @@@@@@Write down the model name and the software version number. @@@@@@ •• The rating levels are country-dependent. To allow all discs to be played, select [8 Adult].

@@@@@The model number and serial number are on the back of this player. □ The TV video input channel is not correctly selected (see the TV's user manual). □ If you have changed a TV system setting, switch back to the default setting: 1) Press to open the disc compartment. □ If this player is connected to an unauthorized display device, the audio/video signal cannot be output. □ If the HDMI cable is faulty, replace it with a new HDMI cable. □ If you have changed the setting for HDMI video resolution, switch to its default mode. No sound output from the TV. □ Make sure that the audio cables are correctly connected between this player and the TV. no sound on HDMI connection. □ If the connected device is non-HDCP compliant or only DVI-compatible, no sound can be heard from the HDMI output. •Make sure that [HDMI Audio] is set to [On]. @@@@@ disc cannot be read. @@□ For a recorded disc, make sure that the disc is finalized. files cannot be displayed or read. @@@@@ easyLink feature does not work.

□ Make sure that this player is connected to the Philips brand EasyLink TV, and the EasyLink option is turned on (see "Use your DVD player" > "Use Philips EasyLink"). WHO IS COVERED: This product is warranted to the original purchaser or the person receiving the product as a gift against defects in materials and workmanship as based on the date of original purchase ("Warranty Period") from an Authorized Dealer. The original sales receipt showing the product name and the purchase date from an authorized retailer is considered such proof. WHAT IS COVERED: This warranty covers new products if a defect in material or workmanship occurs and a valid claim is received within the Warranty Period. At its option, the company will either (1) repair the product at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new, or serviceable used parts and is at least functionally equivalent or most comparable to the original product in current inventory, or (3) refund the original purchase price of the product. The Company warrants replacement products or parts provided under this warranty against defects in materials and workmanship from the date of the replacement or repair for ninety (90) days or for the remaining portion of the original product's warranty, whichever provides longer coverage for you. @@@@Note: Any product sold and identified as refurbished or renewed carries a ninety (90) day limited warranty. @@Failure to follow all requirements can result in delay. @@@@Non-Philips manufacturers, suppliers, or publishers may provide a separate warranty for their own products packaged with the bundled product. The Company is not liable for any damage to or loss of any programs, data, or other information stored on any media contained within the product, or any non-Philips product or part not covered by this warranty.



[You're reading an excerpt. Click here to read official PHILIPS DVP2880 user guide](http://yourpdfguides.com/dref/5096644)

*Recovery or reinstallation of programs, data or other information is not covered under this Limited Warranty. This warranty does not apply (a) to damage caused by accident, abuse, misuse, neglect, misapplication, or non-Philips product, (b) to damage caused by service performed by anyone other than an Authorized Service Location, (c) to a product or a part that has been modified without written permission, or (d) if any serial number has been removed or defaced, or (e) product, accessories or consumables sold "AS IS" without warranty of any kind by including refurbished Philips product sold "AS IS" by some retailers. This Limited Warranty does not cover: Shipping charges to return defective product. Labor charges for installation or setup of the product, adjustment of custome.*



[You're reading an excerpt. Click here to read official PHILIPS](#)

[DVP2880 user guide](#)

<http://yourpdfguides.com/dref/5096644>