




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID 600. You'll find the answers to all your questions on the POLAROID 600 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual POLAROID 600
User guide POLAROID 600
Operating instructions POLAROID 600
Instructions for use POLAROID 600
Instruction manual POLAROID 600



Questions? Need Help?
Contact Polaroid Customer Care Center
Toll Free at: 1-800-343-5000
8am - 6pm EST Mon - Fri (USA only)



AF	AF Model Cameras:	Non-AF	Non-AF Model Cameras:
	636 AF		637
	OneStep AF		OneStep
	OneStep AF SE		OneStep Express
	600 AF		600 Extreme
			600 CL
			Cool Cam
			JobPro 2
			600 Business Edition 2



[You're reading an excerpt. Click here to read official POLAROID 600 user guide](http://yourpdfguides.com/dref/442218)
<http://yourpdfguides.com/dref/442218>

Manual abstract:

Flash Override Button (Not on AF model cameras) AF Model Cameras: 636 AF OneStep AF OneStep AF SE 600 AF Snap the camera shut when not in use. Non-AF Model Cameras: 637 OneStep OneStep Express 600 Extreme 600 CL Cool Cam JobPro 2 600 Business Edition 2 1 Loading Film 2 Taking a Photo a 4 ft 1.2m 2 4 ft .6 1.2m a Pull up the flash unit and snap it into place. @@Frame your subject(s) in the viewfinder. b Open the film door. b b Hold the camera still and press the shutter button. c Insert the film pack as shown. Hold the film pack by the edges. Push the film pack in until a "click" is heard. b c c The photo automatically ejects. c d Close the film door. @@Always return the control to the normal position after using. e The camera ejects the paper film cover. e f Check the picture counter on the back of the camera. @@@@Do not shake Do not bend b 55 F 13 C 2 4 ft .6 1.2m b Position your subject 2 - 4 feet from the camera. Frame your subject in the oval area of the viewfinder. @@@@Hold the camera still and press the flash override button. To clean the developer rollers, dampen a clean cloth with tap water. Open the film door and thoroughly clean the rollers. .



[You're reading an excerpt. Click here to read official POLAROID 600 user guide](http://yourpdfguides.com/dref/442218)
<http://yourpdfguides.com/dref/442218>