



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID I-ZONE INSTANT POCKET CAMERA. You'll find the answers to all your questions on the POLAROID I-ZONE INSTANT POCKET CAMERA in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual POLAROID I-ZONE INSTANT POCKET CAMERA  
User guide POLAROID I-ZONE INSTANT POCKET CAMERA  
Operating instructions POLAROID I-ZONE INSTANT POCKET CAMERA  
Instructions for use POLAROID I-ZONE INSTANT POCKET CAMERA  
Instruction manual POLAROID I-ZONE INSTANT POCKET CAMERA

**Polaroid i-zone**  
Instant Pocket Camera

Use Polaroid I-Zone instant pocket films.  
Save this sheet for reference

**Load Film**

- 1 Press button.
- 2 Load film.
- 3 Close door. Make sure it's closed.
- 4 Pull tab straight, firmly, and quickly. Do not stop.

**Take picture**

- 5 Select  
Indoors: 2-8 ft (.6 m - 2.4 m)  
Outdoor: Sunny: 2 ft - ∞ (.6 m - ∞)  
Outdoor: Cloudy: 2 ft - ∞ (.6 m - ∞)
- 6 Wait. Ready light glows.
- 7 Aim. Best pictures from 2-8 ft (.6-2.4 m).
- 8 Press the button.
- 9 Shade from bright sun and pull tab straight, firmly, and quickly. Do not stop.
- 10 Have Fun! DO NOT CUT INTO PHOTOS. To prevent exposure to caustic paste, cut where indicated.



[You're reading an excerpt. Click here to read official POLAROID I-ZONE INSTANT POCKET CAMERA user guide](http://yourpdfguides.com/dref/3866486)  
<http://yourpdfguides.com/dref/3866486>

**Manual abstract:**

*Ready light glows. Aim. Best pictures from 28 ft. (.62.4 m). Load film. Press the button. Pull tab straight, firmly, and quickly. Do not stop. Close door. Make sure it's closed. Shade from bright sun and pull tab straight, firmly, and quickly. Do not stop. Have Fun! DO NOT CUT INTO PHOTOS. To prevent exposure to caustic paste, cut where indicated. Load batteries Use two AA alkaline batteries. Change the batteries when the ready light does not glow, or if it takes longer than 20 seconds to glow. To save battery power, the camera shuts off after each picture. Limited Warranty: Polaroid will, at our option, repair or replace any camera found defective in manufacture within the warranty period (12 months).*

*The warranty period is determined by the date of camera purchase. Keep the receipt as proof of purchase. Otherwise the warranty period is determined by the date of manufacture. @@@@Caution: This camera is battery operated. @@@@. When pulling tab, pull straight and firmly. Do not stop. Picture too dark · Too far from subject or wrong setting. @@@@If you get some paste on your skin, wipe it off immediately and wash with water to avoid an alkali burn. If eye or mouth contact occurs, quickly wash the area with plenty of water and see a doctor. © Copyright 1999 Polaroid Corporation, Cambridge, MA 02139 U.*

*S.A., owner of the trademarks "Polaroid" and "Polaroid I-Zone" (and design). If you need information or help, please call Polaroid Customer service or visit us at [www.polaroid.com](http://www.polaroid.com) or [izone.polaroid.com](http://izone.polaroid.com).*



[You're reading an excerpt. Click here to read official POLAROID I-ZONE INSTANT POCKET CAMERA user guide](http://yourpdfguides.com/dref/3866486)  
<http://yourpdfguides.com/dref/3866486>