# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID IS2132. You'll find the answers to all your questions on the POLAROID IS2132 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual POLAROID IS2132
User guide POLAROID IS2132
Operating instructions POLAROID IS2132
Instructions for use POLAROID IS2132
Instruction manual POLAROID IS2132

Quick Start Guide

ENGLISH

Camera Views

Front View **Back View**

1. Self-timer LED/ AF Assist Lamp
2. Microphone
3. Lens
4. LCD monitor
5. LED indicator
6. Movie button
7. Playback button
8. OK button/4-way navigation control
9. Function/Delete button
10. Menu button

Top View

11. Flash
12. Zoom lever
13. Shutter button
14. ON/OFF (Power button)
15. Mode dial

ON/OFF

You're reading an excerpt. Click here to read official POLAROID IS2132 user guide

http://yourpdfguides.com/dref/5132977

Manual abstract:

2. 3. 4. 5. 6. 7. 8. 9. 10. Self-timer LED/ AF Assist Lamp Microphone Lens LCD monitor LED indicator Movie button Playback button OK button/4-way navigation control Function/Delete button Menu button Top View 11.

12. 13. 14. Flash Zoom lever Shutter button ON/OFF (Power button) 15. Mode dial Bottom View 16.

Battery/Memory card compartment 17. Tripod screw hole Right View 18. Strap ring Left View 19. Strap ring 20. Speaker 21.

USB AV/Out Step 1. Inserting the Battery 1. @@Insert the battery into the compartment with the terminal facing inside the camera. 3. Close and lock the battery/memory card compartment Step 2. Inserting an SD/SDHC/SDXC Memory Card 1. @@2. @@3. Push the SD/SDHC/SDXC card into the memory slot until it clicks into place. 4.

Close and lock the Battery/memory card compartment. NOTE: To remove the SD/SDHC/SDXC card: Gently push the card until it pops out. Pull the card out and lock the battery cover. Step 3. Setting the Language/Date/Time 1. Turn on the power by pressing Power button. 2. Use 4-way navigation control to move and change the settings. 3. Press OK button to finish.

Step 4. Taking Images 1. 2. 3. 4.

Turn on the camera by pressing the Power button. Compose your image in the LCD monitor. Spin the Zoom lever to adjust view angle. Pressing Shutter button down halfway automatically focuses and adjusts the exposure, and pressing the Shutter button down fully captures the images. When activating flashlight, the Flash won't pop up automatically.

Please open the Flash manually by lifting the protruding grip on the Flash cover. Step 5. Recording Videos 1. 2. 3. 4. 5. 6. Press the Movie button to start recording. Focus your camera on the subject that you want to take.

Use the Zoom lever to zoom in and zoom out an image. . To pause recording, press the key again. @@Viewing images, videos and audio clips 1. Press the Playback button on the camera. or 2. The LCD screen displays an image. Use the to view previous/next image or video. 3. Press the OK button to play a video/audio clip.

keys Step 7. Using the Setup Menu 1. Press Menu button to launch the Record/Playback Menu. or keys to change the menu tab to Setup 2. Use the menu. 3. Use the or keys to move through the menu selections. 4. @@@@@@Your product will be repaired or replaced at no charge for parts or labor for a period of one year. What Is Not Covered by Warranty Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To obtain Warranty Service and Troubleshooting information: Call 877-408-0033 or Visit our website at www.polaroid.com. To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. @@@@@@@@@@@@@@EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. @@@@Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. @@@@@@@PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support. E-Waste - PLR IP Holdings, LLC, its licensees, affiliates, and Sakar International, Inc. fully supports all electronic waste initiatives.

As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product. @@@@@@You may also check with your local recycling facility to determine their data sanitization procedures during the recycling process. .