



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID XSU-01220B. You'll find the answers to all your questions on the POLAROID XSU-01220B in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual POLAROID XSU-01220B**  
**User guide POLAROID XSU-01220B**  
**Operating instructions POLAROID XSU-01220B**  
**Instructions for use POLAROID XSU-01220B**  
**Instruction manual POLAROID XSU-01220B**

Digital Photo Picture Frame



User's Manual



**Questions? Need some help?**

This manual should help you understand your new product. If you have questions, call our toll-free number found on the insert with this icon:



Or visit [www.polaroid.com](http://www.polaroid.com).

20071002



[You're reading an excerpt. Click here to read official POLAROID XSU-01220B user guide](http://yourpdfguides.com/dref/443029)  
<http://yourpdfguides.com/dref/443029>

**Manual abstract:**

polaroid.com. 20071002 Controls Up and Navigation Set and Basic Instructions CONGRATULATIONS on your purchase of a Polaroid digital photo frame. Please read carefully and follow all instructions in the manual and those marked on the product before first use. Failing to follow these warnings could result in personal injury or damage to the device. Also, remember to keep this User's Manual in a convenient location for future reference. Important: Save the original box and all packing material for future shipping needs. Controls AUTO: Press & Hold (under normal mode): Automatically adjusts the position of the display area of the LCD screen. Press (under "Display Screen Adjustment Menu"): Exit. AUTO MENU MENU: Press (under normal mode): Enter into "Display Screen Adjustment Menu".

Press (under "Display Screen Adjustment Menu"): Select items in the menu. UP ARROW Press (under normal mode): Increase music volume Press (under "Display Screen Adjustment Menu"): Move up or go to previous DOWN ARROW Press (under normal mode): Decreases music volume Press (under "Display Screen Adjustment Menu"): Move down or go to next POWER: Turns power on/off V Installing a Flash Media Card Power Power SM Card AVAV Out Out USB Port USB MS/SD/MMC CardCard MS/SD/MMC V SM Card 1. Find the slot that fits your flash media card. 2. Insert the card in the correct slot.

3. @@@@2. Remove old battery and dispose of correctly. 3. Insert new battery taking note of correct polarity (+/-).

4. Replace cover. Caution: 1. Only use a 3V CR2025 battery. 2. Dispose of used batteries according to local ordinance regulations. @@SETUP button Press to open menu for changing settings. CARD SELECTION button Press to choose a different memory card. MUSIC button Press to go to and display music files. PHOTO button Press to go to and display photo files.

@@ button Press to move left when selecting files on your screen. @@ button Press to move down when selecting files on your screen. @@@@2. @@3. Turn the power switch to "ON". As a default the first file of the card will be displayed first. @@The Digital Picture Frame has a built-in mini-USB port.

@@@@2. It is recommended that you turn off your USB device and the Digital Picture Frame before connecting the USB device. 3.

This Digital Picture Frame cannot be connected to a computer. Questions? Need some help? Call our toll-free number found on the insert with this icon: Or visit [www.polaroid.com](http://www.polaroid.com). WEEE: This product contains electrical or electronic materials.

The presence of these materials may, if not disposed of properly, have potential adverse effects on the environment and human health. Presence of this label on the product means it should not be disposed of as unsorted waste and must be collected separately. As a consumer, you are responsible for ensuring that this product is disposed of properly. To find out how to properly dispose of this product, please go to [www.polaroid.com](http://www.polaroid.com) and click on "Company" or call the customer service number for your country listed in the instruction manual. @@.



[You're reading an excerpt. Click here to read official POLAROID](#)

[XSU-01220B user guide](#)

<http://yourpdfguides.com/dref/443029>