



# Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for SANYO RM-6860. You'll find the answers to all your questions on the SANYO RM-6860 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SANYO RM-6860**  
**User guide SANYO RM-6860**  
**Operating instructions SANYO RM-6860**  
**Instructions for use SANYO RM-6860**  
**Instruction manual SANYO RM-6860**

**SANYO**

**INSTRUCTION MANUAL      RM-6860**

**AM/FM Digital Alarm Clock Radio**



[You're reading an excerpt. Click here to read official SANYO RM-6860 user guide](http://yourpdfguides.com/dref/3241972)  
<http://yourpdfguides.com/dref/3241972>

**Manual abstract:**

@@Do not play your earphone at a high volume level. Hearing experts advise against continuous extended play. If you experience a ringing in your ears, reduce the volume or discontinues use. To keep the cabinet clean, wipe off dust and stains with a soft damp cloth. DO NOT USE A SOLUTION CONTAINING BENZOL OR PETROLEUM PRODUCTS. Do not install this equipment in a confined space, such as a book case or built in cabinet. @@1) 1. ALARM 1 BUZZ/RADIO/OFF 2. ALARM 2 BUZZ/RADIO/OFF 3. RADIO AUX/ON/OFF 4.

AUX IN socket (AUX IN) 5. Earphone socket (EAR) 6. Volume knob (VOLUME) 7. Band switch (BAND AM/FM) 8. Tuning control ( TUNING ) 9. Alarm 2 button (AL2) 10. Alarm 1 button (AL1) 11. LED display 12. Alarm stop button (ALARM STOP) 13. Time set button (TIME SET) 14. Slow down button (SLOW DOWN) 15. Fast up button (FAST UP) 16. Snooze button (SNOOZE) 17. Sleep button (SLEEP) 3 BACK-UP BATTERY INSTALLATION (Fig. @@@@BATTERY BACK-UP SYSTEM This unit incorporates a battery back-up system which protects the clock, sleep timer and wake-up alarm functions from the mains failure with the battery installed. During the mains interruption, the clock display will go out, but the clock movement remains in operation. The time display will be resumed when the mains return. Reset the time if the display time is incorrect. @@@@- The RADIO AUX/ON/OFF switch is mounted on the secondary side. @@@@Set the RADIO AUX/ON/OFF switch to OFF.

. 2. @@3. Release the TIME SET button. 4 LISTENING TO THE RADIO 1. 2. 3. 4. 5. Set the RADIO AUX/ON/OFF switch to ON. Set the BAND switch to AM or FM. Turn the TUNING control to tune in a station. Adjust the VOLUME control as desired. To turn the radio off, set the RADIO AUX/ON/OFF switch to OFF. @@- For FM reception, a short wire aerial is provided. @@Set the ALARM1 or ALARM 2 switch to the appropriate position. For the first alarm time setting, set the ALARM switch to ALARM 1. For the second alarm time setting, set the ALARM switch to ALARM 2. 3. @@4. Release the ALARM 1 or ALARM 2 button. @@1. 2. 5 USING THE ALARM 1. @@2. Set the wake-up time. (See "SETTING THE ALARM".) 3. Set the ALARM BUZZ/RADIO/OFF switch to ALARM-RADIO or ALARM-BUZZER. .

ALARM 1/2-RADIO: Wake up with the radio ALARM 1/2 -BUZZER: Wake up with the buzzer. The ALARM 1/2 indicator lights. The timer is set. 4. Set the ALARM 1/2 switch to the appropriate position. a) For ALARM 1 to sound. Set the ALARM 1 switch to ALARM 1RADIO or ALARM 1BUZZER, the ALARM 1 indicator will be displayed on the left bottom of the LED, b) For ALARM 2 to sound. @@The alarm timer will function every day unless it is released. . To turn off the alarm immediately, press ALARM STOP button. To temporarily silence the alarm buzzer or radio, press SNOOZE. This silences the alarm for about 6 minutes. You can repeat this cycle as many times as you like. @@@@2. Set the RADIO AUX/ON/OFF switch to OFF.

Push the SLEEP button. "0:59" (59 minutes) appears. The radio turns on and will turn off automatically after 59 minutes. - To select the desired time, while holding the SLEEP button down, push the FAST UP or SLOW DOWN button repeatedly to select the sleep time. Release the SLEEP button. NOTES: - To release the sleep timer while in operation, set the sleep time to 00:00. @@(If you hold the SLEEP button for more than 2 seconds, it will count down automatically. AUX IN FUNCTION 1. Set the RADIO AUX/ON/OFF switch to AUX. 2. Simple connected the plug to AUX. IN socket in the back of the radio. 3. @@.



[You're reading an excerpt. Click here to read official SANYO](#)

[RM-6860 user guide](#)

<http://yourpdfguides.com/dref/3241972>