



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SENNHEISER RS 120 II. You'll find the answers to all your questions on the SENNHEISER RS 120 II in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SENNHEISER RS 120 II
User guide SENNHEISER RS 120 II
Operating instructions SENNHEISER RS 120 II
Instructions for use SENNHEISER RS 120 II
Instruction manual SENNHEISER RS 120 II



[You're reading an excerpt. Click here to read official SENNHEISER RS 120 II user guide](http://yourpdfguides.com/dref/4066179)
<http://yourpdfguides.com/dref/4066179>

Manual abstract:

1 Connecting the transmitter to an audio output of your audio source Choose a suitable place near your audio source (e.g. TV, stereo or home cinema system). as this can decrease the transmitter's range. Connect the transmitter's audio connection cable: - either directly to the headphone socket or - to the 1/4" (6.3 mm) adapter and a corresponding headphone socket. Set the volume for the headphone output of your audio source to a medium level. If necessary, change this setting via the operating menu of your TV. Plug the mains unit into a wall socket. The transmitter switches on and the ON/OFF LED lights up green.

Preparing the headphones for use 2 Opening the battery compartments Turn the ear pads in the direction of the arrow until you overcome a slight resistance and lift them off the ear cups. 3 Inserting and replacing the rechargeable batteries CAUTION Only use NiMH rechargeable batteries, never use standard batteries! Insert the supplied rechargeable batteries. Secure the ear pads to the ear cups. Charge the rechargeable batteries for at least 24 hours prior to first time use. Switch on the headphones and set the volume to the desired level.

Some electronic devices (e.g. If this happens, increase the distance between the transmitter and the interference source. Specifications and Frequently Asked Questions (FAQ's) Visit our website at www.sennheiser.com.

EN Manufacturer declarations Warranty Sennheiser electronic GmbH & Co. KG gives a warranty of 24 months on this product. For the current warranty conditions, please visit our website at www.sennheiser.com or contact your Sennheiser partner. In order to protect the environment, only dispose of exhausted batteries. In compliance with: Europe/UK 4 RS 120 II RS 115 II RS 119 II Sennheiser electronic GmbH & Co. 04/11, 545188/A01 .



[You're reading an excerpt. Click here to read official SENNHEISER RS 120 II user guide](http://www.sennheiser.com)
<http://yourpdfguides.com/dref/4066179>