



Your PDF Guides


You can read the recommendations in the user guide, the technical guide or the installation guide for SILVERCREST SFB 10.1 B2. You'll find the answers to all your questions on the SILVERCREST SFB 10.1 B2 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SILVERCREST SFB 10.1 B2
User guide SILVERCREST SFB 10.1 B2
Operating instructions SILVERCREST SFB 10.1 B2
Instructions for use SILVERCREST SFB 10.1 B2
Instruction manual SILVERCREST SFB 10.1 B2

SILVERCREST®
HOME TECH

GB
FI
SE

10-in-1 Remote Control



SFB 10.1 B2

- GB **10-in-1 Remote Control**
Operating manual
- FI **Yleiskaukosäädin**
Käyttöohje
- SE **Universalfjärrkontroll**
Bruksanvisning

KOMPERNASS GMBH
BURGSTRASSE 21 · D-44667 BOCHUM
www.kompernass.com
ID-Nr.: SFB 10.1 B2-06/11-V3



[You're reading an excerpt. Click here to read official SILVERCREST SFB 10.1 B2 user guide](http://yourpdfguides.com/dref/4124412)
<http://yourpdfguides.com/dref/4124412>

Manual abstract:

The time of day and date will, however, be lost in either case. @@ press and hold for 3 seconds to access the configuration menu or press briefly to show the date. @@@@To access the EPG function of the target device first press briefly the S button . Settings for the menu language, time of day, date, display contrast, background illumination, volume, lock function as well as system reset. For the device menu display you can select from 5 languages: English, German, Spanish, French and Italian. 1. Hold down the S button for a little longer than 3 seconds. Carry out entries in the menu quickly because after approx. With the buttons select the desired language and confirm with the OK button . 4.

With the EXIT button you exit the menu. the device menu is now displayed in the selected language. @@Hold down the S button for a little longer than 3 seconds. "LANGUAGE SETUP" appears in the LCD display . @@@@ "LANGUAGE SETUP" appears in the LCD display .

@@@You move back one level in the Hold down the S button for a little longer than 3 seconds. "LANGUAGE SETUP" appears in the LCD display . @@ While the code search is activated none of the buttons will function apart from OK and EXIT . Hold the S button down for a little longer than 3 seconds. With the or button select "SYSTEM SETUP" and confirm with the OK button .

3. @@@@ @@@@ @@@@ 1. @@ 2. @@@@ @@@@With the lock function you can block access to all configuration menus. 1. Hold down the S button for a little longer than 3 seconds. 2. With the or button select „SYSTEM SETUP" and confirm with the OK button . 3. @@@@ 5.

With the OK button you save the setting. If you now press the S button play below on the left. @@@@During the displayed "LEARNING" simply allow 30 seconds to pass without any operation and the device will then exit the menu. By default the Macro commands are sent in intervals of 1 every second. Since many devices react sluggishly it is possible that the sequence of the Macro commands are sent too quickly to the device. Then you have the option of programming, before a button command, a pause of between 5 - 21 seconds. For this purpose press, if necessary repeatedly, the MACRO button .

@@@@@However, this does not apply to the following devices: "AMP", "DVD", "ASAT", and "DSAT" since it can be assumed that these devices are equipped with their own volume control If you press the S button the date is superimposed for 10 seconds in the LCD display below and on the right. .



[You're reading an excerpt. Click here to read official SILVERCREST](http://yourpdfguides.com/dref/4124412)

[SFB 10.1 B2 user guide](http://yourpdfguides.com/dref/4124412)

<http://yourpdfguides.com/dref/4124412>