



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SILVERCREST SNS 45 A1. You'll find the answers to all your questions on the SILVERCREST SNS 45 A1 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SILVERCREST SNS 45 A1
User guide SILVERCREST SNS 45 A1
Operating instructions SILVERCREST SNS 45 A1
Instructions for use SILVERCREST SNS 45 A1
Instruction manual SILVERCREST SNS 45 A1

SILVERCREST®

PERSONAL CARE

Nail Studio Set SNS 45 A1



- Nail Studio Set**
Operating instructions
- Nagelstudioset**
Bruksanvisning
- Nagelstudio-Set**
Bedienungsanleitung
- Kynsistudio**
Käyttöohje
- Sæt neglestudie**
Betjeningsvejledning

KOMPENASS GMBH
BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: SNS 45 A1.08/10-V4
IAN: 54334



[You're reading an excerpt. Click here to read official SILVERCREST SNS 45 A1 user guide](http://yourpdfguides.com/dref/4121984)
<http://yourpdfguides.com/dref/4121984>

Manual abstract:

@@@@@@@Any copying or reproduction, including as extracts, as well as the reproduction of images, also in an altered state, is only permitted with the written authorisation of the manufacturer. The manufacturer assumes no responsibility for damage caused by failure to observe these instructions, improper use, incompetent repairs, making unauthorised changes or for using unapproved replacement parts. This appliance is intended only for the application and fixating of artificial finger nails for manicure purposes in indoor areas and is only for domestic use. This appliance is not intended for any other use or for uses beyond those mentioned here. **wARNING Risks from unintended use!** Risks can be engendered by the appliance if it is used for unintended purposes and/or other types of use. Claims of any kind resulting from damage caused by improper use, incompetent repairs, unauthorized modifications or the use of non-approved spare parts will not be acknowledged. In the existing operation instructions the following warnings are used: **DANGER** A warning at this risk level indicates a threateningly dangerous situation. If the dangerous situation is not avoided it could lead to death or serious physical injuries. Observe the directives in this warning notice to avoid the risk of deaths or serious physical injuries. **WARNING** A warning at this risk level indicates a possibly dangerous situation.

If the dangerous situation is not avoided, this could lead to personal injury. Follow the instructions in this warning to avoid personal injuries. **IMPORTANT** A warning at this risk level signifies possible property damage. If the situation is not avoided it can lead to property damage. The directives in this warning are there to avoid property damage.

This appliance complies with the statutory safety regulations. Incorrect usage can, however, lead to personal and property damage. UV appliances may not be used by: People who suffer from skin cancer or are predisposed to it, People, who are taking light-sensitivity enhancing drugs, People under 18 years of age, People with a tendency towards freckles, People with a naturally red hair colour, People with unusual skin discolourations, People with more than 16 moles (with a minimum diameter of 2 mm) on their body, People with atypical moles (atypical moles are asymmetrical moles with a diameter of more than 5 mm and different pigmentation plus irregular border areas; if in doubt, consult your doctor), People who are suffering from sunburn, People who do not tan in the sun without skin burns, People who quickly suffer from skin burns in direct sunlight, People who have frequently suffered from a severe sunburn during their childhood, People who suffer from skin cancer or are suffering from this disease or are susceptible to skin cancer, People with a first-degree relative who is suffering or has already suffered from a melanoma (skin cancer), People who, due to a light sensitivity ailment, are in physicianly or medical treatment, People who absolutely cannot tan at all, or who cannot tan without getting sunburned, when they are exposed to the sun, People who are easily sunburned when they are exposed to the sun, during pregnancy. If erythema (skin redness) occurs several hours after irradiation there should be no further applications made. In this case, the next irradiation should not take place before one week after the date of the skin redness.

If unexpected side effects such as itching occur within 48 hours after the first application of the UV appliance, you should consult a doctor before receiving further UV irradiation. recommended irradiation timetable, stating the time-period and intervals. The appliance may not be used if the timer is not working properly. use only lamps of the specified type. The use of a UV lamp from another manufacturer or of a different type will lead to the revocation of the warranty. UV radiation from the sun or from UV appliances can cause both skin and eye damage, which may be irreversible. These biological effects depend on the quality and quantity of the radiation and on the skin and eye sensitivity of the individual person. The skin can suffer from sunburn after excessive exposure to radiation. Too frequent UV radiation from the sun or UV appliances can lead to premature skin aging and cause an increased risk of skin cancer. This risk increases with increasingly cumulative UV exposures.

UV radiation at a young age increases the subsequent risk of skin cancer. UV radiation can lead to injuries to the eyes and skin, such as premature skin aging and even skin cancer. The unprotected eye can suffer superficial inflammation and, in some cases, excessive exposure may cause damage to the retina. frequently repeated exposures can lead to cataracts. In the event of individually identified sensitivity or allergic reactions to UV radiation, you should first seek medical advice before beginning the irradiation. certain ailments or the side effects of certain drugs may be exacerbated by UV irradiation. If in doubt, consult your doctor. There should be a period of at least 48 hours between the first two exposures. This could lead to skin irritation. Pay heed to the instructions on the irradiation time, time intervals for the irradiation and the distance to be from the lamp.

If you do not, it could lead to skin irritation. Consult your doctor if persistent tumours or ulcers form, or changes in moles come about or sores develop. Protect sensitive skin areas, such as scars, tattoos and the genitals, from irradiation. Do not carry out more than 5 treatments per day. This could lead to skin irritation.

Remove cosmetics and sun care products before using the appliance. If you do not, it could lead to skin irritation. **NOTICE** If in any doubt, consult your doctor about the possible applications before using the appliance. The power cable on this appliance cannot be replaced. In the event of it being damaged the whole appliance must be disposed of.

A repair to the appliance during the warranty period may only be carried out by a customer service firm authorised by the manufacturer, otherwise no additional warranty claims can be considered for subsequent damages. **NEVER** immerse the appliance in water or place the appliance in the close vicinity of water and **DO NOT** place objects filled with liquids (e. Do not place any objects on the appliance. Do not operate the appliance close to open flames (e.

Always pull the plug itself out of the mains power socket, do not pull it with the power cable. In the case of a malfunction occurring or a thunderstorm, disconnect the plug from the mains power socket. Do not put into operation an appliance that is damaged or has been dropped. This appliance is not intended for use by individuals with restricted physical, physiological or intellectual abilities or deficiencies in experience and/or knowledge unless they are supervised by a person responsible for their safety or receive from this person instruction in how the appliance is to be used.



[You're reading an excerpt. Click here to read official SILVERCREST](http://yourpdfguides.com/dref/4121984)

[SNS 45 A1 user guide](http://yourpdfguides.com/dref/4121984)

<http://yourpdfguides.com/dref/4121984>

Children should be supervised to ensure that they do not play with the appliance. Never look directly into the UV lamps.

it could cause injury to the eyes! Always keep the appliance and all accessories out of the reach of children. Pay heed to the instructions given on the containers of all substances used. Repairs should only be carried out by authorised specialist companies or by the Customer Service Department. Defective components may only be replaced with original replacement parts. Only by using these replacement parts can it be guaranteed that they comply with the safety requirements. @@ Pay heed to the following safety information to avoid a potentially fatal risk from electrical power: The power cable on this appliance cannot be replaced. In the event of it being damaged the appliance must be disposed of. Do not touch the appliance and the plug with wet hands. @@ Risks from ultraviolet light (UV-Light) WARNING Risk of injury from ultraviolet light (UV-Light)! Looking directly into the UV light from the UV lamps in this appliance can cause eye injuries and diminish the power of your vision! NEVER look directly into the ultraviolet light from the UV lamps. If the UV lamps are not in use, switch them off.

Non-users, and especially children, may not be present during the operation of the appliance. The inhalation of solvent-containing substances and vapours can damage your health! Do not breathe in the vapours from solvent-containing substances (e. Ensure there is adequate ventilation when interacting with solvent-containing substances. pay heed to the instructions on the containers of the solvent-containing substances. WARNING Risks of health damage from chemical substances! The improper handling of chemical substances can lead to serious health damage! In the event of contact with the eyes or mucous membranes, contact a doctor immediately! 1 UV appliance with 4 built-in UV lamps 2 On/Off switch 3 Operating indicator "POWER"/Standby 4 Operating indicator "180 seconds" 5 Time preselect button "180 seconds" 6 Operating indicator "120 seconds" 7 Time preselect button "120 seconds" 8 Operating indicator "90 seconds" 9 Time preselect button "90 seconds" 0 Start button q Nail clippers w Cuticle pusher e Brush r Sanding block t Polishing file fine (for clipping the nail-tips) (to push back the cuticle) (for applying the UV Gel) (for smoothing of unevenness) (for polishing the nails "shine") WARNING During the commissioning of the appliance personal injury and property damage could occur! Observe the following safety information to avoid these risks:

Packaging material should not be used as a play thing.

There is a risk of suffocation. To avoid damage to people and property, pay heed to the requirements for the installation site and the electrical connection of the appliance. The appliance is supplied with the following components as standard: UV appliance with 4 UV lamps and mains power cable Polishing files, one each of coarse, medium and fine Sand sheet file Sanding block Nail Tips Cuticle pusher Brush Nail clippers 2 Pots of UV Gel ("UV Gel") Finishing solution ("Finishing") 2 Bottles of Nail Glue ("Glue") Nail Oil ("Nail Care") Storage bag Operating Instructions NOTICE Check the contents to ensure everything has been provided, and for signs of visible damage. Remove all parts of the appliance and these operating instructions from the box.

@@Do not touch the appliance and the plug with wet hands.

@@ Before you connect the appliance, compare the connection ton swab or a paper towel. @@@@ ensure that no air bubbles or white spots form under the nail tip o. @@@@ press the nail clippers q together in one squeeze. If you press too slowly, it may happen that the nail tips o splitter. File them into shape with the sand sheet file i. @@@@@@ file only the nail tips o! Do not damage your natural nail. @@ Repeat this step for each individual nail. Remove the sanding dust with a paper towel. @@ Apply a thin coating of UV-Gel s onto the complete nail. Apply a little more UV Gel s to the lower part of the nail, as hereby is how the offset between the natural and the artificial nail is created.

Furthermore, the transition from natural to artificial nails is especially sensitive to pressure and knocks, thus more UV Gel s must be applied here. INFORMATION When you are doing the application do not press too heavily on the brush e, since the brush e could otherwise cause streaking. Model the first layer of the UV Gel s very carefully, as this determines the future shape of the nail. model the best possible natural nail shape. Maintain a distance of about 1 mm from the cuticle during the application. NOTICE Should any UV Gel s inadvertently come onto the cuticle or the nail bed, remove it before the hardening, for example, with a cotton wool swab. Repeat the above process for all nails. NOTICE Ensure that the nail is covered evenly with UV Gel s. Now select the desired treatment time and then press the appropriate time preselect button 9, 7 or 5. for the first hardening we recommend the time setting of 180 seconds.

Hold your hand with the nails upward for the duration of the set treatment time in the opening of the UV appliance 1. Treat the thumbnail separately because, when you hold your hand in the UV unit, the UV light only shines on the side of it. Repeat the application of the UV Gel s and the hardening in the UV appliance 1 as described above once more. NOTICE After the expiry of the preselected treatment time the UV lamps are switched off automatically. The Start button 0 and a time preselect button (9, 7 or 5) must be activated again for each new treatment.

Examine each nail, after the application and hardening of all coatings, for unevenness, small scratches or ridges. If you discover unevenness, apply a further thin layer of UV Gel s and harden the nail with the setting of 120 seconds or 90 seconds (depending on the amount of applied UV Gel s). Even after the last hardening of the Gel layer, the nails may feel a feel sticky ("sweat-layer" or polymerization layer). Moisten a cottonwool ball or paper towel with finishing solution p and wipe it over the nail. Afterwards, delustre each nail with the sanding block r.

Finally, using the polishing files u, z and t, polish each individual nail until the nail surface is shiny. For this reason the gap between the cuticle and the nail attachment must be topped up from time to time. a topping up is required about every 2 - 3 weeks. Using the sand sheet file i, file around the attachments of the hardened gel. Use the sanding block r until the nail is no longer shiny. Do not break the nail tips o off of the natural nails. Remove the nail tips o only in accordance with the following description. First trim the nails all the way back with the nail clippers q. Then file the nail tips o off with the sand sheet file i. Afterwards, polish your natural nails with the various polishing files u, z and t.



[You're reading an excerpt. Click here to read official SILVERCREST SNS 45 A1 user guide](http://yourpdfguides.com/dref/4121984)
<http://yourpdfguides.com/dref/4121984>

Finally, apply a little nail oil d to care for your natural nails. Every night apply nail oil d to the nails and also rub it in and around the cuticles. Use a hand cream regularly. When applying nail varnish, use both a lower layer and an upper layer. Do not use an acetone-based nail polish remover for removing nail polish, because this would loosen and damage the artificial nails. Wear rubber gloves when using detergents or bleaching agents. Wear a pair of rubber gloves for all work/activities that may damage the nails. Disconnect the plug from the mains power socket before you start cleaning the appliance.

IMPORTANT Damage to the appliance! To avoid irreparable damage, ensure that no moisture can penetrate inside the UV appliance 1 when you are cleaning it. Clean the surfaces of the UV appliance 1 only with a soft and dry cloth.

Always close all bottles and tubs after use. Hold the brush e in the finishing solution p and then wipe it off on a paper towel. Afterwards, swirl the brush e in the nail oil d, so as to keep its bristles supple. **NOTICE** Remove the nail oil d before each new utilisation of the brush e. To remove the nail oil d dip the brush e in the finishing solution p and then wipe it on a paper towel.

Disconnect the plug from the mains power socket before you start with the exchange of the UV lamps! **NOTICE** The UV lamps may **ONLY** be replaced with lamps of the same type. the specifications for the precise lamp type are given in the chapter "Technical Data". Unscrew the two screws on the sides of the appliance with a cross-head screwdriver. Pull the front appliance cover with the ultraviolet lamps carefully from the appliance, thereby paying heed to the cable connection on the side. Carefully pull the defective UV lamp out of its socket.

Insert the new UV lamp into the socket. Slide the appliance cover with the UV lamps back onto the appliance, thereby ensuring that the cable connection on the side does not get snagged or trapped. Re-attach the appliance cover with the two side screws. In this chapter you will receive important information for malfunction localization and remedies. @@@@ possible cause The plug is not connected. Mains power socket does not supply any voltage. the selected treatment time too short. One or more UV lamps UV Gel s does not are defective. Pressure on the brush e too high when applying the UV Gel s. Solution Insert the plug into the mains power socket.

@@Apply a further and thinner layer of UV Gel s and then harden it. **NOTICE** If you cannot solve the problem with the aforementioned solutions, please contact Customer Services. Solvent-containing substances and their vapours can damage your health! Carefully close all containers holding the accompanying substances. Store the accompanying substances out of the reach of children. Should you decide not use the appliance for an extended period, disconnect it from the mains power supply and store it in a clean and dry location away from direct sunlight and out of the reach of children. Store all substances in a clean, dry and cool location away from direct sunlight and out of the reach of children. **UNDER NO CIRCUMSTANCES** should you throw the appliance or the substances into normal household waste. This product is subject to the provisions of the European Directive 2002/96/EC-WEEE (Waste Electrical and Electronic Equipment). Dispose of the appliance and the substances via an approved waste disposal company or your communal waste disposal centre. The chemical substances are subject to special waste treatment.

observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre. With regard to conformity with essential requirements and other relevant provisions, this appliance complies with the guidelines of the Electromagnetic Compatibility Directive 2004/108/EC and the Low Voltage Directive 2006/95/EC. The complete original declaration of conformity can be obtained from the importer. Model Operating voltage Power consumption Operating temperature Humidity (no condensation) Dimensions (W x H x D): Weight Number of UV Lamps UV Lamp Type UV-type of the appliance Automatic switch-off times +5 - +45 5 - 90 23 x 27.

5 x 14 1777 4 UV-9W-L 365 nm, 9 W UV-A Lamp after 90, 120 and 180 seconds Nail Studio SNS 45 A1 220 - 240 V / ~ 50 Hz 45 W °C % cm g The warranty for this appliance is for 3 years from the date of purchase. The appliance has been manufactured with care and meticulously examined before delivery. Please retain your receipt as proof of purchase. In the case of a warranty claim, please make contact by telephone with our service department. Only in this way can a post-free despatch for your goods be assured.

NOTICE The warranty covers only claims for material and manufacturing defects, not for transport damages, wearing parts or for damage to fragile components, e. This product is for domestic use only and is not intended for commercial applications. The warranty is void in the case of abusive and improper handling, use of force and internal tampering not carried out by our authorised service branch. Your statutory rights are not restricted in any way by this warranty. The warranty period is not extended by repairs made under the warranty. this applies also to replaced and repaired parts. Damages and defects extant at the time of purchase must be reported immediately after unpacking, resp. No later than two days after the date of purchase. Repairs made after the lapse of the warranty period are subject to charge. Upprepa samma procedur tills alla naglar har klippts av till rätt längd och filats till rätt form.



[You're reading an excerpt. Click here to read official SILVERCREST SNS 45 A1 user guide](http://yourpdfguides.com/dref/4121984)
<http://yourpdfguides.com/dref/4121984>