



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY NSG-MR7U. You'll find the answers to all your questions on the SONY NSG-MR7U in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SONY NSG-MR7U User guide SONY NSG-MR7U Operating instructions SONY NSG-MR7U Instructions for use SONY NSG-MR7U Instruction manual SONY NSG-MR7U

SONY

©2008 Sony Corporation
Printed in China
4-4529-670-10(1)



Remote Control for NSZ-G57

Operating Instructions

NOTICE:

Network Media Player (NSZ-G57) can only be paired with ONE remote. If you pair the player with this remote, the previously paired remote cannot be used.

Sony Customer Support

<http://esupport.sony.com/> | 1-800-222-SONY
Please Call Before Returning the Product to the Store.

NSG-MR7U

Owner's Record

The model and serial numbers are inside the battery cover. Record the serial number in the space provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. NSG-MR7U
Serial No.



Serial No.

WARNING

Batteries or batteries installed apparatus shall not be exposed to excessive heat such as sunshine, fire or the like.

FCC WARNING

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC/C Radiation Exposure Statement:

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR).

This device complies with Industry Canada licence-exempt RSS (standards).

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-008.

Precautions

On placement

- Do not place the remote in a location near heat sources, or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- Do not place the remote outdoors, in vehicles, on ships, or in other vessels.
- If the remote is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may form on the outer surface and on interior of the remote. Should this occur, the remote may not operate properly. In this case, leave the remote for about half an hour until the moisture evaporates.
- Do not place the remote in a place where medical equipment is in use. It may cause a malfunction of medical instruments.
- If you use a pacemaker or other medical device, consult your physician or the manufacturer of your medical device before using the remote.
- Do not place heavy or unstable objects on the remote.
- Do not expose this apparatus to rain or moisture. Do not open the cabinet. Refer servicing to qualified personnel only. Do not place objects filled with liquids, such as vases, on the apparatus. They cause a malfunction.
- The nameplate is located inside the battery cover.

Trademark Information

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- Other system and product names are generally trademarks or registered trademarks of the manufacturers.™ and ® marks are not indicated in this document.



[You're reading an excerpt. Click here to read official SONY NSG-MR7U user guide](http://yourpdfguides.com/dref/5026755)
<http://yourpdfguides.com/dref/5026755>

Manual abstract:

.. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. @@This equipment has very low levels of RF energy that are deemed to comply without testing of specific absorption ratio (SAR). NOTICE: Network Media Player (NSZ-GS7) can only be paired with ONE remote. If you pair the player with this remote, the previously paired remote cannot be used. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. @@Record the serial number in the space provided below. @@Model No. @@Should this occur, the remote may not operate properly. In this case, leave the remote for about half an hour until the moisture evaporates. .. Do not place the remote in a place where medical equipment is in use. It may cause a malfunction of medical instruments. @@.. Do not place heavy or unstable objects on the remote. .. Do not expose this apparatus to rain or moisture. Do not open the cabinet. Refer servicing to qualified personnel only. @@They cause a malfunction. @@@@and any use of such marks by Sony Corporation is under license. @@@@Hold the right side of the battery cover and slide it to the left. @@@@See above for instructions on how to pair a remote. ēē Update the Network Media Player (NSZ-GS7) software to the latest version. Press (HOME) and select [All Apps] - [Settings] - [About] [System updates] - [Check now]. Pairing the remote Press the CONNECT button located on the bottom of the player, with a thin, sharp object such as the point of a pen, etc., and release it within 3 seconds. The instructions will appear on the screen. @@ēē The remote with microphone needs to be paired with the player. @@@@x 2 1/2 in. x 7/8 in.) 103 g (3.7 oz) Size AA batteries* (2) operate the player using this remote.

This remote is not paired by default. Follow the instructions above to pair this remote with the player. .. After finishing this operation, the supplied remote cannot be used with the player. @@.. The LED on the remote continues to flash after pairing is complete because the remote is connecting with the player. This is not a malfunction. @@@@http://www.sony.net/helpguide/r/networkplayer/.



[You're reading an excerpt. Click here to read official SONY NSG-MR7U user guide](http://yourpdfguides.com/dref/5026755)
<http://yourpdfguides.com/dref/5026755>