




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THERMADOR C301BW. You'll find the answers to all your questions on the THERMADOR C301BW in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual THERMADOR C301BW
User guide THERMADOR C301BW
Operating instructions THERMADOR C301BW
Instructions for use THERMADOR C301BW
Instruction manual THERMADOR C301BW



Thermador *An American Icon*

The **Extendable Rack** is designed to allow easier access to cooking foods. The slide arms extend as far as the standard flat rack. The top section then extends even further, bringing the food closer to the cook.



Caution:
When the rack is outside of the oven, slide arms do not lock. They could unexpectedly extend if the rack is carried incorrectly. Extending slide arms could cause injury. **Rack should only be held or carried by grasping the sides (Fig. A) or the pan stops (Fig. B).**

Figure A Figure B




Use:
Grasp the front of the rack and pull straight out or push straight in. The rack will stop when fully extended or closed.

Caution: Always place oven racks in desired location while oven is cool. If rack must be moved while oven is hot, use a potholder or oven mitt on both hands. Do not let potholder touch hot heating element(s). Always use two hands when removing or replacing an oven rack.

Placing the Rack in the Ovens:

1. With rack in the closed position, grasp rack from both sides.
2. Slide back brackets (1 on each side) over desired rack guide.



(Over)



[You're reading an excerpt. Click here to read official THERMADOR C301BW user guide](http://yourpdfguides.com/dref/355322)
<http://yourpdfguides.com/dref/355322>

Manual abstract:

The top section then extends even further, bringing the food closer to the cook. Rack Guides Pan Stops Slide Arms Rack Brackets (2 on each side) Caution: When the rack is outside of the oven, slide arms do not lock. They could unexpectedly extend if the rack is carried incorrectly. Extending slide arms could cause injury. Rack should only be held or carried by grasping the sides (Fig. A) or the pan stops (Fig. B). Figure A Figure B Use: Grasp the front of the rack and pull straight out or push straight in. @@@@Do not let potholder touch hot heating element(s). @@With rack in the closed position, grasp rack from both sides.

2. Slide back brackets (1 on each side) over desired rack guide. (Over) 3. @@@@5. Test rack operation.

Pull out until it stops. The rack should glide easily and be straight, not crooked. It should not come all the way out of the oven. Verify that back brackets straddle rack guide. @@With rack in the closed position, grasp both sections, lift front of rack up and pull out until first bracket is beyond the rack guide.

Lift at front bracket 2. @@3. Lift last bracket over rack guide. Pull up and out. 9000004268 Rev A (ECO# 5V0280) 06/04 .



[You're reading an excerpt. Click here to read official THERMADOR C301BW user guide](http://yourpdfguides.com/dref/3553222)

<http://yourpdfguides.com/dref/3553222>