



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THOMSON DPL907VD. You'll find the answers to all your questions on the THOMSON DPL907VD in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual THOMSON DPL907VD
User guide THOMSON DPL907VD
Operating instructions THOMSON DPL907VD
Instructions for use THOMSON DPL907VD
Instruction manual THOMSON DPL907VD

DPL907VD - 001 Radio 4/11/04 6:20 PM Page 2


Radio

Operating the Radio



The receiver has a built-in tuner that allows for FM radio function.

Manual tuning

1. Connect the FM antenna accordingly.
2. Press **SOURCE** on the front of the unit until the tuner mode is selected. You may also directly press **TUNER** on the remote control.



3. When the FM station broadcasts Stereo sound, ST is displayed.
4. Tune the station by pressing **TUNER +** or **TUNER -** on the remote control repeatedly until the desired station is found.



Alternatively, you can press and hold the same button for about one second to activate the automatic search function. In this mode the receiver will automatically tune frequencies until it finds a station.

5. Repeat steps 4 to tune to another radio station.


Note:
If there is interference, modify the location of the antenna until the optimal sound is heard. TV and other electronic devices could be the cause of interferences so try to position the antenna away from them.

Storing radio stations:


The receiver can store up to 40 radio stations in memory. You can enter every single radio station on yourself or the receiver can store all available radio stations automatically in an ascending order.

Automatic preset programming :

1. Press **SOURCE** on the main unit or **TUNER** on the remote repeatedly to select **TUNER** mode.



2. Press and hold **TUNER** for 3 seconds to start the automatic preset programming.



Note:
A weak signal can affect the "Automatic preset programming function" efficiency. Adjust the antenna for a better reception and for a more efficient search. No Automatic preset programming function for AM mode.

3. Radio frequencies will be browsed and radio stations stored automatically. When all the available radio stations are stored or if all 40 memory locations are full, the auto preset programming will stop.

38



[You're reading an excerpt. Click here to read official THOMSON DPL907VD user guide](http://yourpdfguides.com/dref/431979)
<http://yourpdfguides.com/dref/431979>

Manual abstract:

Manual tuning 1. Connect the FM antenna accordingly. 2. Press SOURCE on the front of the unit until the tuner mode is selected. You may also directly press TUNER on the remote control. Automatic preset programming : 1. Press SOURCE on the main unit or TUNER on the remote repeatedly to select TUNER mode. PR PR 3. When the FM station broadcasts Stereo sound, ST is displayed. 4. Tune the a station by pressing TUNER + or TUNER - on the remote control repeatedly until the desired station is found. 2. @@@@5. @@@@No Automatic preset programming function for AM mode. 3. @@@@Press MENU on the remote control. "PRESET" will appear on the display. RDS (Radio Data System) for FM Only The RDS icon shows on display when RDS data are received. The following information may be available on certain stations: · Frequency station, · Station name, · Program type, · Clock, · Radio text Press INFO-RDS on the remote control repeatedly to select the type of information you want to display. SURROUND SUBWOOFER EN 3. While the word "PROG" is still flashing, input your desired preset number (1-40) using the UP/DOWN on the remote control, then press OK again to store it. SURROUND SUBWOOFER SURROUND SUBWOOFER Retrieving preset stations 1. Press SOURCE on the unit or TUNER on the remote control to enter the tuner mode. 2. .



[You're reading an excerpt. Click here to read official THOMSON DPL907VD user guide](http://yourpdfguides.com/dref/431979)
<http://yourpdfguides.com/dref/431979>