




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THOMSON INTUIVA 420 GPS. You'll find the answers to all your questions on the THOMSON INTUIVA 420 GPS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual THOMSON INTUIVA 420 GPS**  
**User guide THOMSON INTUIVA 420 GPS**  
**Operating instructions THOMSON INTUIVA 420 GPS**  
**Instructions for use THOMSON INTUIVA 420 GPS**  
**Instruction manual THOMSON INTUIVA 420 GPS**



### Upgrading to European Map

The user needs to perform two steps in order to use the EU, UK and/or Scandinavian map on his/her device. First, he/she needs to put the map file(s) onto an SD card. Below are the current map sizes. The user has to ensure the card has enough free space to store the maps he/she wants:

- EU - 1 GB
- UK - 1 GB
- Scandinavian - 213 MB
- DACH MII guide - 185 MB
- France MII guide - 159 MB

**Loading the map files onto SD card**  
There are two ways to load the files onto an SD card: through the device, or a separately purchased SD card reader.

Loading through the device requires the computer to have ActiveSync installed (included on the DVD-ROM already), and will take a long time (up to 5 hours for EU map). It does not require the user to purchase additional hardware.

Loading through a USB 2.0 hi-speed card reader is much faster. It could take as little as 5 minutes to load the EU map.

**1. Loading through SD card reader (more advance)**

1. Put the card with enough free space into the SD card reader.
2. Put the DVD-ROM inside the computer.
3. From Explorer, find the EU map file under "Regions" directory.
4. Copy the file called "europe\_1gb\_nobld\_nobmp\_nopoi\_map.cdc".
5. On the SD card, create a directory called "Cities".
6. Copy the map file into this "Cities" directory.
7. Depending on the speed of your USB port, card reader and card, this process can take as little as 5 minutes.

**2. Loading through Device**

1. Ensure user has installed ActiveSync on the computer (Windows 2000 / XP only).
2. Select the "no partnership" option when the question appears.
3. Ensure the device is fully charged.
4. Put the DVD-ROM inside the computer. Connect the device to the computer through the USB port.
5. Insert the SD card with enough free space into the device.
6. A webpage should show automatically. Follow the steps to load EU map.

**Enabling the map**

Now that the user has the EU map on the SD card, he/she can now go to our website ([www.thomsonlink.com](http://www.thomsonlink.com)) and activate it. To do this, he/she will need the following information:

- Serial Number - This should be included inside the package of the "E" versions.
- Device ID (DID) - This 18-digit ID is unique to each device, and can be access by the following key sequence:  
**MENU + Change Settings + Choose Maps + Barcode icon** (at lower right-hand corner of display)


Enter these two pieces of information at the Registration Section (Digital Store) of the website [www.thomsonlink.com](http://www.thomsonlink.com). The website will ask you to download a small program. Connect your device to your computer. Run this small program, and the appropriate map(s) will be unlocked.

**To use the newly activated EU map**

Press the following key sequence to choose EU map.

- **MENU + Change Settings + Choose Maps**
- **Europe cont.**
- **Scandinavian**
- **United Kingdom/Ireland**

You might have to go to the Multimedia menu and then back to GPS Navigator in order for the device to recognize the newly loaded map.



7. The user can also run "Thomson\_regions.asex" directly from the root directory of the DVD-ROM.

8. Follow the steps to the EU map onto the SD card.

9. This process will take up to 5 hours to complete.



[You're reading an excerpt. Click here to read official THOMSON INTUIVA 420 GPS user guide](http://yourpdfguides.com/dref/601500)  
<http://yourpdfguides.com/dref/601500>

**Manual abstract:**

*Below are the current map sizes. The user has to ensure the card has enough free space to store the maps he/she wants: - EU 1 GB - UK 1 GB - Scandinavian 213 MB - DACh MII guide 185 MB - France MII guide 159 MB Loading the map files onto SD card There are two ways to load the files onto an SD card: through the device, or a separately purchased SD card reader. Loading through the device requires the computer to have ActiveSync installed (included on the DVD-ROM already), and will take a long time (up to 5 hours for EU map). It does not require the user to purchase additional hardware. Loading through a USB 2.0 hi-speed card reader is much faster. It could take as little as 5 minutes to load the EU map. 1. Loading through SD card reader (more advance) 1.*

*Put the card with enough free space into the SD card reader.*

*2. Put the DVD-ROM inside the computer. 3. From Explorer, find the EU map file under "\Regions" directory. 4.*

*Copy the file called "europe-1gb\_nobld\_nobmp\_nopoi\_map.cdt". 5. On the SD card, create a directory called "Cities". 6.*

*Copy the map file into this "Cities" directory. 7. @@2. Loading through Device 1. @@2. @@Ensure the device is fully charged. 4. Put the DVD-ROM inside the computer. Connect the device to the computer through the USB port. 5.*

*Insert the SD card with enough free space into the device. 6. A webpage should show automatically. @@@@8. Follow the steps to the EU map onto the SD card. 9. @@@@@com. The website will ask you to download a small program. Connect your device to your computer. Run this small program, and the appropriate map(s) will be unlocked.*

*To use the newly activated EU map Press the following key sequence to choose EU map. · MENU ñ Change Settings ñ Choose Maps ñ Europe cont. .*



**[You're reading an excerpt. Click here to read official THOMSON INTUIVA 420 GPS user guide](http://yourpdfguides.com/dref/601500)**  
**<http://yourpdfguides.com/dref/601500>**