



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for THOMSON ROC1309. You'll find the answers to all your questions on the THOMSON ROC1309 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual THOMSON ROC1309
User guide THOMSON ROC1309
Operating instructions THOMSON ROC1309
Instructions for use THOMSON ROC1309
Instruction manual THOMSON ROC1309



[You're reading an excerpt. Click here to read official THOMSON ROC1309 user guide](http://yourpdfguides.com/dref/3044284)
<http://yourpdfguides.com/dref/3044284>

Manual abstract:

3 The coloured buttons can be used to select categories when teletext is activated, and specific functions depending on the make. 6 Setup: Allows you to program your remote before the first use. 5. 6. Should the set not switch off, press key G repeatedly, until the set switches off. Direct the remote control towards the TV set and try to switch it off by simply pressing the key G. 4. 5. Should the set not switch off, repeat step 2. Then type in the next 4-digit code.

Try to switch off the set by pressing key G once. Repeat this procedure by trying out each of the 4-digit codes. 4. 5. If you think that not all of the keys are active, repeat the procedure of this programming method to find out the code supporting a wider range of features.

Method D Automatic code search With this method, the remote control scrolls through the full code list by sending an IR signal to the set to be controlled remotely. After a few seconds, the remote control begins to scroll through the whole code list included in the library (at a rate of roughly 1 code per second). Press the P+ , G key once again to slow down the test speed (1 code every 3 seconds). As soon as the set changes channels (or turn off, or start to play the disk), you must press OK to save the code and stop the remote control scrolling through the list. If you do not react quickly enough, you can go back to the previous code by pressing P- as many times as necessary (you can go forward by pressing G , P+ if you have gone back too far).

As soon as the set responds again, press OK to save the code. Press the SETUP key again briefly, the indicator light blinks once. 3. 4. 5. Repeat step 3 to find out the 3 other numbers of the code. 6. When the fourth figure is found, the indicator lamp goes out. For a television or a satellite receiver: switch on and, for example, press 2 to change channels, etc. Try other remote control keys to find out the range of functions you can control.

Open the cover on the back of the remote control. Hence it is advisable to record the codes needed for your devices. När du har hittat koden till din apparat ska du skriva ner den så att du har den till hands om du skulle behöva den .



[You're reading an excerpt. Click here to read official THOMSON](#)

[ROC1309 user guide](#)

<http://yourpdfguides.com/dref/3044284>