



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER. You'll find the answers to all your questions on the TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER
User guide TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER
Operating instructions TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER
Instructions for use TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER
Instruction manual TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER

User's Manual

USB 3.0 ExpressCard Adapter



TS-PNU3

(Version 1.1)



[You're reading an excerpt. Click here to read official TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER user guide](http://yourpdfguides.com/dref/3700863)
<http://yourpdfguides.com/dref/3700863>

Manual abstract:

0 ExpressCard Adapter TS-PNU3 (Version 1.1) Table of Contents Introduction

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....1 Package Contents ...

.....
.....
.....

.....
.....
.....

...1 Features ..

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

2 System Requirements

.....
.....

.....
.....

.....
.....

....2 Safety Precautions

.....
.....
.....

.....
.....
.....

.....
.....
.....
..4 Hardware Installation ..

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

...5 Driver Installation

.....
.....
.....
.....
.....
.....
.....
.....
.....

6 Troubleshooting

.....
.....
.....
.....
.....
.....
.....
.....
.....

.....9 Specifications .

.....
.....
.....
.....
.....
.....
.....
.....
.....

10 Ordering Information

.....
.....
.....
.....
.....
.....
.....
.....

.....10 Transcend Limited Warranty .

.....
.....
.....
.....
.....
.....
.....

.....11 Introduction Congratulations on purchasing Transcend's USB 3.0 ExpressCard Adapter. This easy-to-install card allows you to add revolutionary new USB 3.0 ports to any laptop with a PCI Express slot. Its ExpressCard/34 interface is compatible with virtually all current notebook computers, and guarantees unrestricted two-way communication between your PC and any USB devices you plug into the adapter.

With two SuperSpeed USB 3.0 ports offering bandwidth up to 5Gbits per second, Transcend's USB 3.0 ExpressCard Adapter is ideal for use with new USB 3.0 high-capacity external storage devices. This User's Manual is designed to help you install and use your new USB 3.0 ExpressCard Adapter. Package Contents

The USB 3.0 ExpressCard Adapter package includes the following items: USB 3.0 ExpressCard Adapter USB Power Cable Driver CD Quick Installation Guide 1 Features Add USB 3.0 compatibility to any laptop with an ExpressCard/34 slot Connection bandwidth up to 5Gbits per second (in USB 3.0 mode) Backwards compatible with USB 2.0 and USB 1.1 devices Efficient power management to help save battery life Unrestricted simultaneous two-way data transfer Supports Plug and Play and hot swapping Two SuperSpeed USB 3.0 ports xHCI compliant System Requirements One of following operating systems: · · · Windows XP Windows Vista Windows 7 2 Safety Precautions These usage and safety guidelines are IMPORTANT! Please follow them carefully. General Use · · · · To prevent damage cause by electrostatic discharge (ESD), always touch a grounded or large metal object before handling the USB 3.0 ExpressCard Adapter. During operation, avoid exposing the card to extreme temperatures above 35(95), or below 5(41). @@@@To ensure Super-Speed 5Gb/s data transfer rates when connecting a USB 3.0 storage device, please make sure the USB 3.0 ExpressCard Adapter drivers are correctly installed.

Please refer to the driver installation section of this manual. · Power · The power provided by your computer's ExpressCard/34 slot might be insufficient to power devices with high power consumption, such as 2.5" external hard drives. Always connect the USB Power Cable to USB 3.0 ExpressCard Adapter when connecting any device with high USB power consumption. To ensure proper functionality of USB-powered devices, always be sure to connect the USB Power Cable to the USB 3.0 Express Card. 3 Product Overview Two USB 3.0 Ports DC Power Input 4 Hardware Installation 1. Plug the USB 3.

0 Adapter (curved side up) into your notebook's ExpressCard/34 slot. Ensure that the card is fully inserted into the slot. Note: Some notebooks have ExpressCard/54 slots, which are also compatible with ExpressCard/34 devices. Please consult the owner's manual of your notebook for details 2. Connect the included USB Power Cable to the USB 3.0 ExpressCard Adapter and to one of your notebook's USB ports. WARNING 1. Disconnect all USB devices from the USB 3.0 ExpressCard Adapter before plugging in the Power Cable. 2.

To ensure proper functionality of USB-powered devices, always be sure to connect the USB Power Cable to the USB 3.0 ExpressCard Adapter. 3. Do NOT use a power cable other than the one provided with Transcend USB 3.0 ExpressCard Adapter. 3. Install the driver (see Driver Installation below). 4. Plug a USB device into one of the USB 3.0 ExpressCard Adapter's ports. @@Insert the Driver CD into your CD-ROM drive. 2. The AutoPlay window should appear. Click on "Driver" to begin the installation. 3. The installation wizard will start. Click "Next" to continue. 6 4. @@@@Click "Install." 7 7.

@@@@@@@@@@If not, unplug it and plug it in again. @@2. Ensure that the driver has been installed successfully. 3. Is the ExpressCard/34 slot disabled in the BIOS settings? @@4. Have you attached the USB Power Cable? @@@@5. @@@@Try unplugging the adapter and reconnecting it. 2. Ensure that computer's boot drive (HDD) is connected properly. 3.

@@@@@@@@During the warranty period should your Transcend USB 3.0 ExpressCard Adapter fail under normal use in the recommended environment due to improper workmanship or materials, Transcend will repair the product or replace it with a comparable one. This warranty is subject to the conditions and limitations set forth herein. Duration of Warranty: The Transcend USB 3.0 ExpressCard Adapter is covered by this warranty for a period of two (2) years from the date of purchase.

Proof of purchase including the date of purchase is required to collect on the warranty. Transcend will inspect the product and decide whether to repair or replace it. Transcend reserves the right to provide a functional equivalent product, or a refurbished replacement product. Limitations: This warranty does not apply to product failure caused by accidents, abuse, mishandling, improper installation, alteration, acts of nature, improper usage, or problems with electrical power. In addition, opening or tampering with the product casing, or any physical damage, abuse or alteration to the product's surface, including all warranty or quality stickers, product serial or electronic numbers will also void the product warranty.

Transcend is not responsible for recovering any data lost due to the failure of a hard drive device. Transcend's USB 3.0 ExpressCard Adapter must be used with devices that conform to the recommended industry standards. Transcend will not be liable for damages resulting from a third party device that causes the Transcend USB 3.0 ExpressCard Adapter to fail. @@@@Disclaimer: The foregoing limited warranty is exclusive. There are no other warranties, including any implied warranty of merchantability or fitness for a particular purpose. This warranty is not affected in any part by Transcend providing technical support or advice. Online Registration: To expedite the warranty service, please register your Transcend Product within 30 days of purchase. Register online at www.

transcend.com.tw/register The specifications mentioned above are subject to change without notice. Transcend Information, Inc. www.transcend.com.tw *The Transcend logo is a registered trademark of Transcend Information, Inc. *All logos and marks are trademarks of their respective companies. 11 .



[You're reading an excerpt. Click here to read official TRANSCEND PNU3 USB3.0 EXPRESSCARD ADAPTER user guide http://yourpdfguides.com/dref/3700863](http://yourpdfguides.com/dref/3700863)