



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRANSCEND PORTABLE DVD WRITER. You'll find the answers to all your questions on the TRANSCEND PORTABLE DVD WRITER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRANSCEND PORTABLE DVD WRITER
User guide TRANSCEND PORTABLE DVD WRITER
Operating instructions TRANSCEND PORTABLE DVD WRITER
Instructions for use TRANSCEND PORTABLE DVD WRITER
Instruction manual TRANSCEND PORTABLE DVD WRITER

User's Manual

Slim Portable CD/DVD Writer



TS8XDVRW

(Version 1.3)

 **Transcend®**



[You're reading an excerpt. Click here to read official TRANSCEND PORTABLE DVD WRITER user guide](http://yourpdfguides.com/dref/3700891)
<http://yourpdfguides.com/dref/3700891>

Manual abstract:

3) Table of Contents Introduction

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....1 Package Contents

.....
.....
.....

.....
.....
.....

.....1 Features ...

.....
.....

.....
.....
.....

.....
.....
.....

.....2 System Requirements .

.....
.....

.....
.....
.....

.....
.....
.....

.....2 General Use.....

.....
.....
.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
... 2 Writing Data..

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
... 3 Power ..

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....
... 3 Reminders ..

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

4 Product Overview

.....
.....
.....
.....
.....
.....
.....
.....
.....

.5 Basic Operation

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

6 Plugging in the CD/DVD Writer.....

.....
.....
.....
.....
.....
.....
.....
.....

.... 6 Inserting a Disc .

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

... 6 Ejecting a Disc

.....
.....
.....
.....
.....
.....
.....

..15 Ordering Information ...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.15 Recycling & Environmental Considerations

.....
.....
.....

..16 Transcend Limited Warranty

.....
.....
.....
.....
.....
.....

...17 Introduction Congratulations on purchasing Transcend's 8X Slim Portable CD/DVD Writer. This slim, elegant high-speed portable CD/DVD writer is perfect for playing, backing up your vital data and discs.

With its slim easy-to-carry size and advanced high-speed media writing capabilities, the CD/DVD Writer is ideal for playing movies, installing software, or backing up your files, folders, documents, photos, music and videos when using a compact notebook computer or netbook. @@@@ One of following Operating Systems: . . . Windows® XP Windows Vista® Windows® 7 Mac OS® 10.4 or later Safety Precautions These usage and safety guidelines are IMPORTANT! Please follow them carefully. Please ensure that you connect the USB cable to the CD/DVD Writer and your computer correctly (small end CD/DVD Writer, large end PC) General Use . . . During operation, avoid exposing your CD/DVD writer to extreme temperatures above 40 or below 5. Never drop your CD/DVD Writer. Only use the CD/DVD Writer face-up, on a stable flat surface Do not allow your CD/DVD Writer to come in contact with water or any other liquids. 2 . . . Do not use a damp/wet cloth to wipe or clean the exterior case. Never look directly into the laser lens, as it can be harmful to your eyes. Do not attempt to open the outer case (doing so will void your product warranty). Do not store your CD/DVD Writer in any of the following environments: o o o Direct sunlight Next to an air conditioner, electric heater or other heat sources In a closed car that is in direct sunlight In an area with strong magnetic fields or excessive vibration · Never touch the laser lens.

Writing Data · Do not touch, pick up, or move the CD/DVD Writer during the write process. This can damage the device and will cause errors on the disc being written Transcend does not take any responsibility for data loss or damage resulting from use of this product. If using this product to backup data, we strongly advise using high-quality recordable media, and that you fully test and verify the contents of all written discs. It is also a good idea to regularly backup important data to a different computer or other storage medium. To ensure High-Speed USB 2.0 data transfer rates when using your CD/DVD Writer with a computer, please check that the computer has the relevant USB drivers. If you are unsure about how to check this, please consult the computer or motherboard User's Manual for USB driver information. · Power · The CD/DVD Writer is powered directly from your computer's USB port. However, the USB ports of certain computers may not supply enough power to use the CD/DVD Writer when using a single USB port. Please make sure to connect both large connector ends of the provided USB Cable to the USB ports on your computer.

This will ensure the CD/DVD Writer receives adequate power for stable operation. 3 The second USB connector provides additional power for the CD/DVD Writer. @NEVER use a cable that is frayed or damaged. @@@@2. @@@@The letter in your "My Computer" window may differ 4.

@@@Gently pull the disc tray out until it stops. 3. Place a CD or DVD onto the tray. 7 4. @@Push the disc tray back into the CD/DVD Writer. @@@@Gently pull the disc tray out until it stops. 9 3. @@Select the Hardware icon on the system tray. 2. The Safely Remove Hardware pop-up window will appear. Select it to continue. 3. @@Insert the Software CD. 2. @@@@ Is your CD/DVD Writer properly connected to the USB port? If not, unplug it and plug it in again.

If it is properly connected, try using another available USB port. 2. Are you using the USB cable that came in the CD/DVD Writer package? @@3. @@Please make sure to connect the USB cable to both USB ports on your computer. This will provide the additional power necessary to run the drive. Both USB connectors are required to provide adequate power. 4. Is the USB port enabled? If not, refer to the user's manual of your computer (or motherboard) to enable it. 5. If you have connected all ends of the USB cable and still have power-related problems while reading / writing data, we recommend that you purchase a Transcend USB Power Adapter (TS-PA2A) to provide the power necessary to operate the CD/DVD Writer.

(Please see the Transcend Website or contact your local dealer for availability) My computer does not recognize CD/DVD Writer 1. 2. A single USB port may not provide enough power for the CD/DVD Writer to function. Make sure you plug both large ends of the USB cable directly into your computer's USB ports. Avoid connecting the CD/DVD Writer through a USB hub.

13 The CD/DVD Writer does not Power On (LED does not flash) Check the following: 1. Ensure that the CD/DVD Writer is properly connected to the USB port(s) on your computer. 2. Ensure that the USB port is working properly. If not, try using n, alteration, acts of nature, improper usage, or problems with electrical power.

In addition, opening or tampering with the product casing, or any physical damage, abuse or alteration to the product's surface, including all warranty or quality stickers, product serial or electronic numbers will also void the product warranty. Transcend is not responsible for recovering any data lost due to the

failure of a hard drive device. Transcend's CD/DVD Writer must be used with devices that conform to the recommended industry standards. Transcend will not be liable for damages resulting from a third party device that causes the Transcend CD/DVD Writer to fail. @@@@Disclaimer: The foregoing limited warranty is exclusive. @@This warranty is not affected in any part by Transcend providing technical support or advice. Online Registration: To expedite the warranty service, please register your Transcend Product within 30 days of purchase. Register online at <http://www.transcendusa.com/productregister> Transcend Information, Inc.

<http://www.transcendusa.com/> *The Transcend logo is a registered trademark of Transcend Information, Inc. *The specifications mentioned above are subject to change without notice. *All logos and marks are trademarks of their respective companies. 17 .



[You're reading an excerpt. Click here to read official TRANSCEND PORTABLE DVD WRITER user guide](http://yourpdfguides.com/dref/3700891)
<http://yourpdfguides.com/dref/3700891>