



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRANSCEND STOREJET 2.5 SATA. You'll find the answers to all your questions on the TRANSCEND STOREJET 2.5 SATA in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual TRANSCEND STOREJET 2.5 SATA**  
**User guide TRANSCEND STOREJET 2.5 SATA**  
**Operating instructions TRANSCEND STOREJET 2.5 SATA**  
**Instructions for use TRANSCEND STOREJET 2.5 SATA**  
**Instruction manual TRANSCEND STOREJET 2.5 SATA**

**USB2.0**  
**StoreJet™ 2.5**

**User's Manual**

(Version 1.1.8)

 **Transcend**



[You're reading an excerpt. Click here to read official TRANSCEND STOREJET 2.5 SATA user guide](http://yourpdfguides.com/dref/3700330)  
<http://yourpdfguides.com/dref/3700330>

**Manual abstract:**

*5 User's Manual (Version 1.1.8) Table of Contents Introduction .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*. 1 Package Contents.....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.1 Features .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.....2 System Requirements ...*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
*2 Safety Precautions.....*

.....  
.....  
.....  
.....  
.....

.....  
.....  
.....

..... *3 General Use ..*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... *3 Backing Up Data ..*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*3 Transporting.....*

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

.....  
.....  
.....  
.....

.....  
.....

*.....3 Power .*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.....3 Reminders .*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.4 Product Overview .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*5 Installing a Hard Drive .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*.. 6 Driver Installation.....*

.....  
.....  
.....  
.....  
.....  
.....

*.. @@@@11 Removing the StoreJetTM 2.5 in Windows® 2000, XP and Vista .....*

.....  
.....  
.....

*.....11 Removing the StoreJetTM 2.*

*5 in MacTM OS 9.0, or Later.....*

.....  
.....  
.....

*.11 Remove the StoreJetTM 2.5 in LinuxTM Kernel 2.4, or Later.....*

.....  
.....  
.....  
.....

*.....11 Formatting the Hard Drive..*

.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 12 Windows® 2000/XP ...*

.....  
.....  
.....  
.....  
.....  
.....

.....12 Windows Vista™ .

....13 Troubleshooting.

..... 17 StoreJet™ 2.5 IDE series .....

.. @@@@ With a huge storage capacity and Hi-Speed USB 2.0 data transfer rates, the compact StoreJet™ 2.5 is ideal for storing and transferring your files, folders, documents, photos, music and e-work between it and any desktop, or notebook computer.

In addition, the StoreJet™ 2.5 comes with a very useful software (please see the Software User's Manual for detailed instructions) pack that can (used in Windows®) increase your productivity. The User's Manual and accompanying Software User's Guide are written to help you get the most from your new device, please read both in detail before using the StoreJet™ 2.5. Package Contents The StoreJet™ 2.5 package includes the following items: · StoreJet™ 2.5 · Mini USB to USB A-Type cable (USB Y cable) · Quick Instruction Guide 1 Introduction Introduction Introduction Features · · · · · Hi-Speed USB 2.0 compliant and USB 1.1 backwards compatible Easy Plug and Play installation Optional 2.5" Hard Disk Drive Ultra-Portability OneTouch Auto-Backup function Powered via the USB port.

No external power or battery needed Hi-Speed data transfer rates up to 480Mbps per second Additional StoreJet Software pack: StoreJet™ elite (helps you manage your data) LED indicates the status of power on, data transfer activity System Requirements Desktop or notebook computer with a working USB port.

@@@Please follow them carefully. @@@@Do not drop your StoreJet™ 2.5. @@Do not use a damp/wet cloth to wipe or clean the exterior case. @@@@To ensure High-Speed USB 2.0 data transfer rates when using your StoreJet™ 2.5 with a computer, please check that the computer has the relevant USB drivers. If you are unsure about how to check this, please consult the computer or motherboard User's Manual for USB driver information. Do not pack your StoreJet™ 2.

5 into luggage without the proper padded support. Other items in the luggage may damage your StoreJet™ 2.5 if it does not have the proper protection.

Avoid squeezing your StoreJet™ 2.5 to prevent damage to the internal HDD.

Avoid placing objects onto your StoreJet™ 2.5 to prevent damaging it. In this instance, please connect the other USB A-Type connector from the provided USB Y cable to a USB port on the computer, this will provide the additional power necessary to run the drive. Transporting Power The other USB A-Type connector is used to provide additional power. Please use the Mini USB to USB A-Type cable that came with the StoreJet™ 2.

5 to connect it 3 Safety to a computer, and always ensure that the cable you are using is in good condition. NEVER use a cable that is frayed or damaged. Reminders Always follow the procedures in the "Disconnecting from a Computer" section to remove your StoreJet™ from a computer. 4 Safety Ensure nothing is resting on the USB cable and that the cable is not located where it can be tripped over or stepped on. Product Overview Figure 1. StoreJet™ 2.5

Screws x 2 Mini USB Port OneTouch Auto-Backup Button 5 Product Overview Installing a Hard Drive Installing a Hard Drive If you purchased a StoreJet™ 2.5 that does not have a Hard Disk Drive already installed, please read this section, otherwise you can skip to the "Driver Installation" section. 1. Open the StoreJet™ 2.

5 by removing the two screws from either side of the top cover, as indicated in the diagram. Figure 2. Remove the screws from the top cover 2. Remove the cover revealing a control board adapter; this converts the IDE/SATA interface connector of the hard drive to a Mini USB 2.0 interface. Slide out the control board. Figure 3. Remove the top cover revealing the IDE/SATA adapter 3. Plug your StoreJet™ 2.5 into a USB port and mount it.

1. Then, mount the StoreJet™ 2.5. Mini USB to USB A-Type Cable (USB Y cable) 1. 2.

Connecting to a Computer 9 Use with a Computer 3. OneTouch Auto-Backup Button 6. Select the Hardware icon on the system tray. 2. The Safely Remove Hardware pop-up window will appear.

Select it to continue. Figure 11. Is your StoreJet™ 2.5 properly connected to the USB port? If not, unplug it and plug it in again. If it is properly connected, try using another available USB port. 2. Are you using the USB cable that came in the StoreJet™ 2.5 pack? 3. This will provide the additional power necessary to run the drive. The other USB A-Type connector is used to provide additional power.

4. Is your StoreJet™ 2.5 connected to the Mac™ keyboard? If yes, unplug it and plug it into an available USB port on your Mac™ Desktop. My computer does not recognize the StoreJet™ 2.5 1. 2. A single USB port may not provide enough power for the StoreJet™ 2.5 to function. Make sure you plug both large ends of the USB cable directly into your computer's USB ports. Avoid using a USB HUB to connect the StoreJet™ 2.

5. 17 Troubleshooting 5. Is the USB port enabled? If not, refer to the user's manual of your computer (or motherboard) to enable it. Cannot Power ON Check the following: 1. 2.

Check that the USB port is working properly. If you want to backup a Mac computer you will need to format the drive for HFS+ using the Mac Disk Utility. Cannot detect the StoreJet™ 2.5 in Linux The StoreJet™ 2.5's internal hard drive comes formatted for FAT32.

Linux CANNOT support the NTFS file system, please reformat the hard drive to the FAT file system. 18 Troubleshooting StoreJet™ 2.5 IDE series Specifications · Size (L x W x H): · Weight: · Storage Media: · Power Supply: · Max. Transfer Speeds: · Operating Temperature: · Certificates: · Warranty: 129 mm x 79.9 mm x 13 mm 88g (without hard drive) 2.5-inch IDE Hard Disk Drive 5V DC supplied from the USB port(s) 480Mbps per second 5 (41) to 55 (131) CE, FCC, BSMI 2-years Ordering Information Device Description StoreJet™ 2.5 Silver StoreJet™ 2.5 Red Memory Size 0GB 0GB Transcend P/N TS0GSJ25S TS0GSJ25R 19 Specifications StoreJet™ 2.5 SATA series Specifications 1 1 1 1 1 Size (L x W x H): Weight: Storage Media: Power Supply: Max. Transfer Speeds: Operating Temperature: Certificates: Warranty: 129 mm x 79.



[You're reading an excerpt. Click here to read official TRANSCEND STOREJET 2.5 SATA user guide](http://yourpdfguides.com/dref/3700330)  
<http://yourpdfguides.com/dref/3700330>

9 mm × 13 mm 186g (with hard drive) 2.5-inch SATA Hard Disk Drive 5V DC supplied from the USB port(s) 480Mbps per second 5 (41) to 55 (131) CE, FCC, BSMI 2-years 11 Ordering Information Device Description StoreJet™ 2.5 SATA Silver StoreJet™ 2.5 SATA Blue StoreJet™ 2.5 SATA Red StoreJet™ 2.5 SATA 160GB Blue StoreJet™ 2.5 SATA 250GB Silver Memory Size 0GB 0GB 0GB 160GB 250GB Transcend P/N TS0GSJ25S-S TS0GSJ25B-S TS0GSJ25R-S TS160GSJ25B-S TS250GSJ25S-S 20 Specifications Transcend Limited Warranty "Above and Beyond" is the standard we set ourselves for customer service at Transcend. We consistently position ourselves to be significantly above the industry norm, which is all part of our commitment to Customer Satisfaction. Please do not break or remove t.



[You're reading an excerpt. Click here to read official TRANSCEND STOREJET 2.5 SATA user guide](http://yourpdfguides.com/dref/3700330)  
<http://yourpdfguides.com/dref/3700330>