



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRANSCEND TS0GSJ35. You'll find the answers to all your questions on the TRANSCEND TS0GSJ35 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRANSCEND TS0GSJ35
User guide TRANSCEND TS0GSJ35
Operating instructions TRANSCEND TS0GSJ35
Instructions for use TRANSCEND TS0GSJ35
Instruction manual TRANSCEND TS0GSJ35

USB2.0
StoreJet™ 3.5

User's Manual

(Version 1.0)

Transcend
Exceeding Your Expectations

1



[You're reading an excerpt. Click here to read official TRANSCEND TS0GSJ35 user guide](http://yourpdfguides.com/dref/1307934)
<http://yourpdfguides.com/dref/1307934>

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.5 Product Overview

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.6 Installing a Hard Drive....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....7 Driver Installation .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..10 Driver Installation for Windows® 2000, XP and VISTA

.....
.....
.....
.....
.....
.....
.....

10 Driver Installation for Mac™ OS 9.0, or Later

.....
.....
.....
.....
.....
.....

....10 Driver Installation for Linux™ Kernel 2.4, or Later

.....
.....
.....
.....
.....
.....
.....

.10 Connecting to a Computer

.....
.....
.....
.....
.....
.....
.....
.....

....11 Disconnecting from a Computer

.....
.....
.....
.....

5 to prevent damaging it. Power The StoreJet™ 3.5 is powered from the mains using the Power Adapter. Ensure nothing is resting on the Power cables and that the cables are not located where they can be tripped over or stepped on. Reminders Always follow the procedures in the "Disconnecting from a Computer" section to remove your StoreJet™ from a computer. 5 Safety Safety Product Overview Figure 1. StoreJet 3.5 Screws x 2 Power ON/OFF Switch Power Jack LED USB B-Type Port 6 Product Overview Installing a Hard Drive Your StoreJet™ 3.5 HDD Enclosure is capable of supporting an IDE, or a SATA Hard Disk Drive. It is IMPORTANT! that you match and install the correct Hard Drive to the correct enclosure.

Installing a Hard Drive If you purchased a Transcend StoreJet™ 3.5 HDD Enclosure that does not have a Hard Disk Drive already installed, please read this section, otherwise you can skip to the "Driver Installation" section. Your Transcend StoreJet™ 3.5 HDD Enclosure is capable of supporting an IDE, or a SATA Hard Drive, it is important that you match and install the correct hard drive to the correct enclosure. You can identify the type of enclosure by its part number.

Enclosures with the Transcend part number TS0GSJ35-S support SATA Drives, while enclosures with the part number TS0GSJ35 support IDE Drives. Figure 2. Remove the screws from the top cover 2. Remove the cover revealing a control board adapter; this converts the IDE, or SATA interface connector of the hard drive to a USB 2.0 B-Type interface.

Slide out the control board. Figure 3. Remove the top cover revealing the IDE/SATA adapter 7 Installing a Hard Drive 1. Open the StoreJet™ 3.5 by removing the two screws from either side of the top cover, as indicated in the diagram. 3. IDE Connection: Carefully line up and plug in the IDE connector on the control board to the hard drive. Do NOT force the IDE connector into the hard drive and do NOT insert the connector at an angle, otherwise you may damage it. After you have connected the control board, attach the power cable to the IDE hard drive. Figure 4.

@@@Connect the SATA hard drive to the SATA adapter 5. @@@@Plug your StoreJet™ into an available USB port. @@@Plug your StoreJet™ 3.5 into an available USB port. @@@@Plug your StoreJet™ 3.5 into a USB port. @@1. First create a directory for the StoreJet™ 3.5. Example: mkdir /mnt/Storejet 2.

Then, mount the StoreJet™ 3.5. @@1. @@USB B-Type to USB A-Type Cable 2. @@WARNING! @@Connecting to a Computer 3.

11 Use with a Computer 4. @@@@At this stage the StoreJet™ 3.5 is a Per that all the cables are connected properly and the power switch is on, try plugging the power cable into another power outlet. Cannot back up my Mac™ The StoreJet™ 3.5's internal hard drive comes formatted for NTFS.

@@Linux CANNOT support the NTFS file system, please reformat the hard drive to the FAT file system. 16 Troubleshooting Troubleshooting StoreJet™ 3.5 series Specifications · Size (L x W x H): · Weight: · Storage Media: · Power Supply: · Max. Transfer Speeds: · Operating Temperature: · Storage Temperature: · Humidity: · Certificates: · Warranty: 198.5mm × 123.4mm × 35mm Max. 450g (without hard drive) 3.5 inch IDE, or SATA Hard Disk Drive AC input: 100V-240V DC output: 12V/5V Switching Power Adapter 480Mbps (60MB) per second 5 (41) to 60 (140) -40 (-40) to 70 (158) 8% to 90% RH CE, FCC, BSMI 2-years Ordering Information Device Description StoreJet™ 3.



[You're reading an excerpt. Click here to read official TRANSCEND](#)

[TS0GSJ35 user guide](#)

<http://yourpdfguides.com/dref/1307934>

5 IDE StoreJet™ 3.5 IDE StoreJet™ 3.

5 SATA StoreJet™ 3.5 SATA Memory Size 0GB 0GB 0GB 0GB Transcend P/N TS0GSJ35 TS0GSJ35-EU TS0GSJ35-S TS0GSJ35-SEU 17 Specifications
Transcend Limited Warranty "Above and Beyond" is the standard we set ourselves for customer service at Transcend. We consistently position ourselves to be significantly above the industry norm, which is all part of our commitment to Customer Satisfaction. All Transcend information, Inc. (Transcend) products are warranted and tested to be free from defects in material and workmanship and to conform to the published specifications. During the warranty period should your Transcend StoreJet™ 3.5 fail under normal use in the recommended environment due to improper workmanship or materials, Transcend will repair the product or replace it with a comparable one. This warranty is subject to the conditions and limitations set forth herein. Duration of Warranty: The Transcend StoreJet™ 3.5 is covered by this warranty for a period of two (2) years from the date of purchase.

Proof of purchase including the date of purchase is required to collect on the warranty. Transcend will inspect the product and decide whether to repair or replace it. Transcend reserves the right to provide a functional equivalent product, or a refurbished replacement product. Limitations: This warranty does not apply to product failure caused by accidents, abuse, mishandling, improper installation, alteration, acts of nature, improper usage, or problems with electrical power. In addition, opening or tampering with the product casing, or any physical damage, abuse or alteration to the product's surface, including all warranty or quality stickers, product serial or electronic numbers will also void the product warranty.

Transcend is not responsible for recovering any data lost due to the failure of a hard drive device. Transcend's StoreJet™ 3.5 must be used with devices that conform to the recommended industry standards. @@@@Disclaimer: The foregoing limited warranty is exclusive. There are no other warranties, including any implied warranty of merchantability or fitness for a particular purpose.

This warranty is not affected in any part by Transcend providing technical support or advice. Online Registration: To expedite the warranty service, please register your Transcend Product within 30 days of purchase. Register online at <http://www.transcendusa.com/registration> The specifications mentioned above are subject to change without notice. www.transcendusa.com *The Transcend logo is a registered trademark of Transcend Information, Inc. *All logos and marks are trademarks of their respective companies. 18 Warranty Transcend Information, Inc.



[You're reading an excerpt. Click here to read official TRANSCEND TS0GSJ35 user guide](http://yourpdfguides.com/dref/1307934)
<http://yourpdfguides.com/dref/1307934>