



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRENDNET TEW-650AP. You'll find the answers to all your questions on the TRENDNET TEW-650AP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRENDNET TEW-650AP
User guide TRENDNET TEW-650AP
Operating instructions TRENDNET TEW-650AP
Instructions for use TRENDNET TEW-650AP
Instruction manual TRENDNET TEW-650AP



[You're reading an excerpt. Click here to read official TRENDNET TEW-650AP user guide](http://yourpdfguides.com/dref/3180864)
<http://yourpdfguides.com/dref/3180864>

Manual abstract:

01 Table of Contents English 1. Before You Start 2. Hardware Installation 1 1 2 Troubleshooting 8 Version 08.04.2010 1. Before You Start Package Contents TEW-650AP Y Y Multi-Language Quick Installation Guide Y CD-ROM (Utility and User's Guide) Y Power Adapter (12V DC, 0.5A) Y 5 Ethernet Cable (0.6m / 2ft.) Cat. System Requirements Web Browser: Internet Explorer (6 or higher) Y Y computer with a network adapter or wireless adapter properly installed A Y router with an available network LAN port A Y available DHCP Server routers usually have a built-in DHCP server An 1 2.

Hardware Installation Note: 1. Locate an optimum location for the Access Point. The best place for the Access Point is usually at the center of your wireless network. 2. Disable any anti-virus and firewall programs before starting hardware installation.

For Windows Users 1. Insert Utility CD-ROM into your computer's CD-ROM drive. 2. Click Run Setup.exe (Windows 7/Vista only) 3.

Click Setup Wizard. 4. Click I accept the terms in the License Agreement and then click Next. 2 5. Connect the provided RJ-45 cable from a LAN port on your Router to the LAN port on the TEW-650AP. Then click Next. 6. Connect a RJ-45 cable from a LAN port on your Router to the Ethernet port on your computer. 7. Connect the Power Adapter to the Access Point and then to a power outlet and then click Next.

8. Select the TEW-650AP from the list and then click Configure. 9. Enter a password and then click Login. By default, there is no password. 3 10. Select Access Point and then click Next. Note: For AP Client setup, please refer to the User's Guide for step by step instructions. @@@@Select Manual setup and then click Next. 13.

Enter a SSID and then click Next. By default, the SSID is TRENDnet650. 4 14. Select the desired Wireless Mode and then click Next. 15.

@@@For WPA-PSK or WPA2-PSK, the Pre-Shared Key must be between 8 and 63 ASCII or 64 HEX characters. Make sure to copy down the Pre-Shared Key. 17. Click Save (optional). This saves your configuration settings, which can be reloaded when needed.

5 18. Give the file a name, then click Save (optional). 19. Click Configure to apply the settings. 20. Click Exit. 21. Click Yes to exit. 6 22. Connect the 2dBi detachable antennas to the TEW-650AP.

Note: to connect a wireless computer to the TEW-650AP, please refer to the first question in the troubleshooting section. Your Installation is complete For detailed information regarding the TEW-650AP's configuration and advanced settings, please refer to the Troubleshooting section, User's Guide on the Utility CD-ROM, or TRENDnet's website at <http://www.trendnet.com>. Register Your Product To ensure the highest level of customer service and support, please take a moment to register your product Online at: www.trendnet.com/register Thank you for choosing TRENDnet 7 Troubleshooting 1. All the settings are correct, but I can not make a wireless connection to the Access Point. 1. Double check that the wireless LED on the Access Point is lit.

2. Power cycle the Access Point. Unplug the power to the Access Point. Wait 15 seconds, then plug the power back in. 3.

Contact the manufacturer of your wireless network adapter. Make sure the wireless network adapter is configured with the proper SSID. The default SSID of the Access Point is TRENDnet650AP. If you have enabled any encryption on the Access Point, make sure to configure the wireless network adapter with the same security key. 2.

I am trying to connect additional wireless adapters, but I don't remember the encryption (network) key. What should I do? From a wired computer, log on to the access point configuration page. Click Wireless ' Security. The encryption key will be listed here. 3. I have a wireless adapter that supports WiFi Protected Setup (WPS) push button setup. How do I setup WPS between the TEW-650AP and my wireless adapter? 1. Press on the WPS button on the front of the TEW-650AP for 10 seconds. 2. Refer to your wireless adapters for instructions on setting up WPS.

4. I inserted the Utility CD-ROM into my computer's CD-ROM Drive but the installation menu does not appear automatically. What should I do? 1. For Windows 7, if the installation menu does not appear automatically, click on the Windows Icon on the bottom left hand corner of the screen, click the "Search programs and files" box, and type D:\autorun.exe, where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Driver, and then press the ENTER key on your keyboard 2. For Windows Vista, if the installation menu does not appear automatically, click on the Windows Icon on the bottom left hand corner of the screen, click on the "Start Search" box, and type D:\autorun.exe, where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard. 3.

For Windows XP/2000 if the window does not appear automatically, click Start, click Run and type D:\autorun.exe where "D" in "D:\autorun.exe" is the letter assigned to your CD-ROM Drive, and then press the ENTER key on your keyboard. 8 5. I do not have a DHCP server or DHCP is disabled on my network and I am unable to configure the TEW-650AP.

What should I do? 1. Go to the TCP/IP settings on your computer's network's adapter. Assign a static IP address of 192.168.10.

7 with a subnet mask of 255.255.255.0. Since the default IP address of the TEW-650AP is 192.168.10.100, do not assign a static IP address of 192.168.10.

100 on your computer's network adapter. 2. Open Internet Explorer or web browser and enter <http://192.168.10.100> into the address bar. The default login for the TEW-650AP is username:admin/ Password: (blank). 6. How do I configure AP Client mode on the TEW-650AP? Please refer to the User Guide. The User Guide is on the provided CD-ROM.

If you still encounter problems or have any questions regarding the TEW-650AP, please contact TRENDnet's Technical Support Department. 9 Wireless Tips The following are some general wireless tips to help minimize the impact of interference within an environment. Assign your network a unique SSID Do not use anything that would be identifying like "Smith Family Network". @@@@Change the channel bandwidth to 20/40MHz.

@@@@@I.

@@@@Keep the number of obstructions to a minimum. Each obstruction can reduce the range of a wireless device. @@@3. Building materials can have a large impact on your wireless signal. @@@@4.

Antenna orientation can also have a large impact on your wireless signal. Use the wireless adapter's site survey tool to determine the best antenna orientation for your wireless devices. 5. Interference from devices that produce RF (radio frequency) noise can also impact your signal. Position your wireless devices away from anything that generates RF noise, such as microwaves, HAM radios, Walkie-Talkies and baby monitors.



[You're reading an excerpt. Click here to read official TRENDNET TEW-650AP user guide](http://yourpdfguides.com/dref/3180864)
<http://yourpdfguides.com/dref/3180864>

6. Any device operating on the 2.4GHz frequency will cause interference. Devices such as 2.4GHz cordless phones or other wireless remotes operating on the 2.

4GHz frequency can potentially drop the wireless signal. Although the phone may not be in use, the base can still transmit wireless signals. Move the phone's base station as far away as possible from your wireless devices. If you are still experiencing low or no signal consider repositioning the wireless devices or installing additional access points. The use of higher gain antennas may also provide the necessary coverage depending on the environment. 11 GPL/LGPL General Information This TRENDnet product includes free software written by third party developers. These codes are subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). These codes are distributed WITHOUT WARRANTY and are subject to the copyrights of the developers. TRENDnet does not provide technical support for these codes. The details of the GNU GPL and LGPL are included in the product CD-ROM.

Please also go to (<http://www.gnu.org/licenses/gpl.txt>) or (<http://www.gnu.org/licenses/lgpl.txt>) for specific terms of each license. The source codes are available for download from TRENDnet's web site (http://trendnet.com/downloads/list_gpl.asp) for at least three years from the product shipping date.

You could also request the source codes by contacting TRENDnet, 20675 Manhattan Place, Torrance, CA 90501, USA. Tel: +1-310-961-5500 Fax: +1-310-961-5511. Informations générales GPL/LGPL Ce produit TRENDnet comprend un logiciel libre écrit par des programmeurs tiers. Ces codes sont sujet à la GNU General Public License ("GPL" Licence publique générale GNU) ou à la GNU Lesser General Public License ("LGPL" Licence publique générale limitée GNU). Ces codes sont distribués SANS GARANTIE et sont sujets aux droits d'auteurs des programmeurs. TRENDnet ne fournit pas d'assistance technique pour ces codes. Les détails concernant les GPL et LGPL GNU sont repris sur le CD-ROM du produit. Veuillez également vous rendre en (<http://www.gnu.org/licenses/gpl.txt>)

ou en (<http://www.gnu.org/licenses/lgpl.txt>) pour les conditions spécifiques de chaque licence. Les codes source sont disponibles au téléchargement sur le site Internet de TRENDnet web site (http://trendnet.com/downloads/list_gpl.asp) durant au moins 3 ans à partir de la date d'expédition du produit. @20675 Manhattan Place, Torrance, CA 90501, USA. Tel: +1-310-961-5500 Fax: +1-310-961-5511 Allgemeine Informationen zu GPL/LGPL Dieses Produkt enthält die freie Software "netfilter/iptables" (© 2000-2004 netfilter project <http://www.netfilter.org>) und dloads/list_gpl.asp) por pelo menos três anos da data de embarque do produto. @@@@ @Koode vahendatakse ILMA GARANTIIA ja need on allutatud arendajate poolt. TRENDnet ei anna koodidele tehnilist tuge.

Detailsemat infot GNU GPL ja LGPL kohta leiate toote CD-ROMil. Infot mõlema litsentsi spetsiifiliste terminite kohta leiate (<http://www.gnu.org/licenses/gpl.txt>) või (<http://www.gnu.org/licenses/lgpl.txt>). Infot mõlema litsentsi spetsiifiliste terminite kohta leiate (<http://www.gnu.org/licenses/gpl.txt>) või (<http://www.gnu.org/licenses/lgpl.txt>).

Lähtekoodi on võimalik alla laadida TRENDneti kodulehelt (http://trendnet.com/langen/downloads/list_gpl.asp) kolme aasta jooksul alates toote kättesaamise kuupäevast. Samuti võite lähtekoodi paluda TRENDneti'lt, 20675 Manhattan Place, Torrance, CA 90501, USA. Tel: +1-310-961-5500, Fax: +1-310-961-5511. Copyright © 2010. All Rights Reserved. TRENDnet. .



[You're reading an excerpt. Click here to read official TRENDNET TEW-650AP user guide](#)
<http://yourpdfguides.com/dref/3180864>